

Clavinova®

CVP-609 / CVP-605

Data List

Daten-Liste

Liste des données

Lista de datos

Voice List 2	Chord Types Recognized in the Fingered Mode 40
Voice-Liste	Im Fingered-Modus erkannte Akkordarten
Liste des voix	Types d'accords reconnus en mode Fingered
Lista de voces	Tipos de acordes reconocidos en el modo Fingered (digitado)
Mega Voice Map 23	Effect Type List 41
Sound-Zuordnungen der Mega Voices	Liste der Effektypen
Carte des voix Mega	Liste des types d'effet
Mapa de Mega Voice	Lista de tipos de efecto
Drum/key Assignment List 27	Parameter Chart 49
Liste der Tastenzuordnungen der Schlaginstrumente	Parametertabelle
Liste d'assignation instrument de batterie/touche du clavier	Tableau des paramètres
Lista de asignación de teclas/batería	Gráfico de parámetros
Style List 35	
Liste der Styles	
Liste des styles	
Lista de estilos	

Voice List / Voice-Liste / Liste des voix / Lista de voces

CVP-609

Main Category: PIANO

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Grand Piano	Concert Grand	108	0	1	Natural!
	Studio Grand	108	16	1	Live!
	Grand Piano	108	17	1	Natural!
	Mellow Piano	108	18	1	Natural!
	Pop Grand 1	108	17	2	Natural!
	Pop Grand 2	108	18	2	Natural!
	Rock Piano	108	16	3	Natural!
	Stage Piano	108	17	3	Natural!
	Ambient Piano	108	18	3	Natural!
	Cocktail Piano	108	24	4	Natural!
	Grand Piano 1octave	108	22	2	Natural!
	Grand Piano 2octave	108	23	2	Natural!
	Bright Piano	108	16	2	Natural!
	Upright Piano	Upright Piano	108	16	4
Pop Upright		108	19	4	Natural!
70s Ballad Piano		108	17	4	Natural!
Chill Out Piano		108	18	4	Natural!
Honky Tonk Upright		108	20	4	Natural!
Saloon Upright		108	21	4	Natural!
Upright 1octave		108	22	4	Natural!
Upright 2octave		108	23	4	Natural!
Piano Layer		Ballad Grand 1	108	25	5
	Ballad Grand 2	108	26	5	Natural!
	MIDI Grand	108	22	3	Natural!
	MIDI Grand Pad	108	23	3	Natural!
	Piano & Strings	108	23	1	Natural!
	Piano Orchestra	108	22	1	Natural!
	Grand Pad Layer	108	32	3	Natural!
	Piano Sweeper	108	22	100	Regular
	MIDI Grand Syn	108	24	3	Natural!
	Pianosphere	108	22	89	Regular
	Piano & EP 1	108	25	3	Natural!
	Piano & EP 2	108	26	3	Natural!
	Piano & Choir	108	25	1	Natural!
	Piano & Pad	108	24	1	Natural!
Electric Piano	Suitcase EP	108	16	5	Cool!
	Vintage EP	108	19	5	Regular
	Electric Piano 1	108	17	5	Cool!
	Electric Piano 2	108	21	5	Natural!
	Stage EP	108	20	5	Regular
	Funky EP	108	24	5	Natural!
	Tremolo Suitcase EP	108	18	5	Cool!
	Tremolo Stage EP	108	23	5	Natural!
	Smooth Tine	108	16	6	Regular
	CP80 Studio	108	20	3	Natural!
	Magnetics	108	22	5	Regular
	CP80 Stage	108	19	3	Regular
	FM E.Piano	Studio Ballad DX	104	9	6
Sparkle Stack		0	121	6	Cool!
Sweet DX		104	0	6	Cool!
Ballad DX		0	124	6	Cool!
DX Dynamics		0	123	6	Cool!
Ballad Bells		104	2	6	Cool!
Galaxy EP		0	114	5	Cool!
DX7 EP		0	122	6	Natural!
Dream DX		104	3	6	Cool!
Midnight DX		104	1	6	Cool!
Clavi	Clavi 1	0	112	8	Regular
	Clavi 2	0	122	8	Natural!
	Wah Clavi	0	113	8	Regular
	Funk Clavi	0	123	8	Natural!
	Phase Clavi	0	115	8	Regular
Harpsichord	Harpsichord 1	0	122	7	Natural!
	Harpsichord 2	8	32	113	S.Articulation!
	Harpsichord 3	0	125	7	Natural!
	Harpsichord Coupler	0	123	7	Natural!
	Grand Harpsichord	0	113	7	Live!
	Harpsichord & Strings	0	124	7	Natural!

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Tonewheel Organ	Whiter Bars	8	32	30	S.Articulation!	
	Curved Bars	0	121	17	Cool!	
	All Bars Out	8	32	31	S.Articulation!	
	Even Bars	0	111	17	Cool!	
	Jazz Rotary	8	32	114	S.Articulation!	
	Vintage Fast	0	127	17	Cool!	
	Classic Bars	8	34	30	S.Articulation!	
	Organ	0	118	19	Cool!	
	Rock Rotary	8	33	114	S.Articulation!	
	Organ-a-Gogo	104	0	17	Cool!	
	Prog Rock Organ	8	33	30	S.Articulation!	
	Organ Accom 1	0	108	18	Regular	
	R&B Tremolo	0	111	19	Cool!	
	Organ Accom 2	0	107	18	Regular	
	Jazz Organ	0	117	17	Cool!	
	Organ Accom 3	0	106	18	Regular	
	Hold It Fast	0	111	18	Cool!	
	Organ Accom 4	0	105	18	Regular	
	Full Rocker	0	115	19	Cool!	
	Organ Accom 5	0	104	18	Regular	
	Whiter Bars Slow	104	1	18	Cool!	
	Whiter Bars Fast	104	0	18	Cool!	
	Jazz Slow	0	126	18	Cool!	
	Jazz Fast	0	127	18	Cool!	
	All Bars Out Slow	104	1	19	Cool!	
	All Bars Out Fast	104	0	19	Cool!	
All Bars Phase	104	2	19	Cool!		
Rotor Organ	0	117	19	Cool!		
Mellow Draw	0	115	18	Regular		
Two Channels	0	109	18	Cool!		
Transistor Organ	60s Combo 1	104	32	17	Cool!	
	60s Combo 2	104	33	17	Cool!	
	60s Combo 3	104	34	17	Cool!	
	60s Combo 4	104	35	17	Cool!	
	Euro Organ	0	118	17	Regular	
Classical Pipe	Pipe Organ	0	112	20	Regular	
	Pipe Organ Flute 1	0	124	20	Natural!	
	Chapel Organ 1	0	113	20	Regular	
	Pipe Organ Flute 2	0	125	20	Natural!	
	Chapel Organ 2	0	114	20	Regular	
	Pipe Organ Tutti 1	0	126	20	Natural!	
	Chapel Organ 3	0	115	20	Regular	
	Pipe Organ Tutti 2	0	122	20	Natural!	
	Pipe Organ Principal	0	123	20	Natural!	
	Theatre Pipe	Full Theatre	0	127	19	Regular
		Tibia 8	104	6	18	Regular
		Sweet Theatre	0	126	19	Regular
Tibia 8&4		104	9	17	Regular	
Ballroom Organ		0	115	4	Regular	
Tibia 16&4		104	8	17	Regular	
Tibia Full		104	5	18	Regular	
Vox 8		104	7	18	Regular	
Vox & Tibia		104	10	17	Regular	
Trumpet 8		0	124	17	Regular	
Kinura 8		0	123	17	Regular	
Tp & Kinura		0	125	18	Regular	
Trumpet 16&8		0	124	18	Regular	
Organ Flutes	Organ Flutes	0	126	17	OrganFlutes	
	USD Smile	0	126	17	OrganFlutes	
	Reggae Bars	0	126	17	OrganFlutes	
	Warm Theatre	0	126	17	OrganFlutes	
	Organ Pops	0	126	17	OrganFlutes	
	Rock Organ	0	126	17	OrganFlutes	
	Soul Percussion	0	126	17	OrganFlutes	
	Gospel Truth	0	126	17	OrganFlutes	
	Pad Organ	0	126	17	OrganFlutes	
	Full Organ	0	126	17	OrganFlutes	
	String Bars	0	126	17	OrganFlutes	
	Latin Spin	0	126	17	OrganFlutes	
	Shady Bars	0	126	17	OrganFlutes	
	Funk Organ	0	126	17	OrganFlutes	

CVP-609

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Organ Flutes	Ballad Organ	0	126	17	OrganFlutes
	Rich Bars	0	126	17	OrganFlutes
	Trumpet Bars	0	126	17	OrganFlutes
	Soul Bars	0	126	17	OrganFlutes
	Clari Bars	0	126	17	OrganFlutes
	Jazz Squabble	0	126	17	OrganFlutes
	Euro Perc	0	126	17	OrganFlutes
	Ballad Euro	0	126	17	OrganFlutes
	Euro Reeds	0	126	17	OrganFlutes
	Even Warmth	0	126	17	OrganFlutes
	Bright Euro	0	126	17	OrganFlutes
	Euro Pops	0	126	17	OrganFlutes
	Full Euro	0	126	17	OrganFlutes
	Euro Accom 1	0	126	17	OrganFlutes
	Euro Accom 2	0	126	17	OrganFlutes
Euro Accom 3	0	126	17	OrganFlutes	
Harmonica	Harmonica	8	64	105	S.Articulation2!
	Blues Harp	8	65	105	S.Articulation2!
	Harmonica	0	112	23	Sweet!
Accordion	Master Accord	0	118	22	Regular
	Full Register	104	2	22	Regular
	Cassotto	104	0	22	Regular
	Clari 8&4	104	1	22	Regular
	Jazz Accordion	0	120	22	Regular
	Cajun	104	3	22	Regular
	Tango Accordion	0	114	24	Regular
	Bandoneon	0	113	24	Regular
	French Musette	0	119	22	Regular
	Steirisch	0	117	22	Regular
	Master Bass	0	122	22	Regular
	FullReg Bass	104	5	22	Regular
	Accordion Bass	0	121	22	Regular
	Cajun Bass	104	6	22	Regular
	Musette Bass	0	123	22	Regular
Tango Bass	0	115	24	Regular	

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Nylon Acoustic	Concert Guitar	8	32	1	S.Articulation!
	Dynamic Nylon	0	116	25	Live!
	Flamenco Guitar	8	33	1	S.Articulation!
	Hard Flamenco	0	118	25	Live!
	Nylon Guitar	8	34	1	S.Articulation!
	Classical Guitar	0	115	25	Live!
	Slide Nylon	0	117	25	Live!
	Nylon Mute	0	119	25	Live!
	Electro Acoustic	8	35	1	S.Articulation!
	Steel Acoustic	Steel Guitar	8	32	2
Slide Steel		0	118	26	Live!
Folk Guitar		8	33	2	S.Articulation!
Dynamic Steel		0	116	26	Live!
Steel Guitar		0	117	26	Live!
Steel Mute		0	120	26	Live!
12String Guitar		0	113	26	Live!
Clean Solid	Finger Chorus	8	42	4	S.Articulation!
	Warm Solid	8	33	4	S.Articulation!
	Single Coil Clean	8	39	4	S.Articulation!
	Clean Solid	8	34	4	S.Articulation!
	Bright Chorus	8	45	4	S.Articulation!
	Vintage Slap	8	48	4	S.Articulation!
	Ballad Delay	8	46	4	S.Articulation!
	Vintage Pure	8	47	4	S.Articulation!
	Jazz Vintage	8	38	7	S.Articulation!
	Jazz Artist	8	39	7	S.Articulation!
	Finger Bright	8	50	4	S.Articulation!
	Slide Clean	0	117	29	Cool!
	Warm Electric	8	32	4	S.Articulation!
	Slide Warm	104	6	28	Cool!
	Clean Electric	8	35	4	S.Articulation!
Slide Pick	104	7	28	Cool!	

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Clean Solid	Vintage Amp	8	41	4	S.Articulation!
	Country Pick	8	44	4	S.Articulation!
	Jazz Solo Guitar	0	116	27	Cool!
	Semi Acoustic	8	33	7	S.Articulation!
	Electric Guitar	0	114	29	Cool!
	Chorus Solid	0	107	28	Cool!
	Dynamic Mute	0	118	29	Cool!
	Slide Solid	0	110	28	Cool!
	CoolWah Guitar	104	4	28	Regular
	Slap Solid	0	108	28	Cool!
	Finger Amp	8	43	4	S.Articulation!
	Lite Chorus	8	53	4	S.Articulation!
	Jazz Clean	8	32	7	S.Articulation!
	Smooth Jazz Guitar	8	35	7	S.Articulation!
	Slide Finger	104	5	28	Cool!
	Slide Pick Amp	104	8	28	Cool!
	Vintage Muted Guitar	104	0	29	Cool!
	Slapback	104	0	28	Cool!
	Vintage Muted Echo	0	115	29	Regular
	Vintage Open	0	123	28	Regular
	Vintage Strum	0	126	28	Regular
	Funk Guitar	0	116	29	Cool!
	70s Solid Guitar	8	38	4	S.Articulation!
	Vintage Spring	8	54	4	S.Articulation!
	Jazz Guitar	0	115	27	Cool!
	Slide Jazz	104	0	27	Cool!
	Lounge Guitar	104	1	27	Regular
	Clean Guitar	0	112	28	Cool!
	Muted Guitar	0	119	29	Cool!
	60s Clean	0	117	28	Regular
Tremolo Solid	0	111	28	Cool!	
Ballad Solid	0	109	28	Cool!	
Funk Slap	8	49	4	S.Articulation!	
Octave Guitar	0	113	27	Regular	
Distortion Solid	Rock Hero	8	35	6	S.Articulation!
	Stage Lead	8	38	6	S.Articulation!
	Grunge Guitar	8	40	6	S.Articulation!
	Overdrive Wah	8	39	6	S.Articulation!
	Pure Vintage	8	42	6	S.Articulation!
	Bluesy Night	8	55	4	S.Articulation!
	Rock Legend	8	34	6	S.Articulation!
	Guitar Hero	8	32	6	S.Articulation!
	Classic Stack	8	41	6	S.Articulation!
	Vintage Rock	8	36	6	S.Articulation!
	Blues Bright	8	35	5	S.Articulation!
	Finger Slap Slide	8	51	4	S.Articulation!
	Metal Master	0	120	31	Regular
	Blues Slap Slide	8	36	5	S.Articulation!
	Crunch Guitar	8	33	6	S.Articulation!
	Vintage Blues	8	37	6	S.Articulation!
	Heavy Rock	8	32	5	S.Articulation!
	Blues Warm	8	34	5	S.Articulation!
	Half Drive	8	37	4	S.Articulation!
	Feedbacker	8	33	5	S.Articulation!
	Stereo Rock	104	2	31	Cool!
	Crunch Guitar	0	113	31	Regular
	Vintage Lead	0	125	28	Cool!
	Vintage Amp	0	115	30	Regular
	Blues Guitar	0	117	30	Cool!
Heavy Stack	0	114	31	Regular	
Power Lead	0	115	31	Cool!	
World	Pedal Steel Amp	8	52	4	S.Articulation!
	Mandolin	0	114	26	Sweet!
	Pedal Steel	8	36	4	S.Articulation!
	Zither 1	104	1	16	Regular
	Banjo	104	0	106	Regular
	Zither 2	104	0	16	Regular
	Shamisen	0	112	107	Regular
	Dulcimer	0	112	16	Regular
	Koto	0	112	108	Regular
	Hackbrett	104	2	47	Regular
Aloha Guitar	0	118	27	Regular	

CVP-609

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
World	Sitar	104	0	105	Regular	
	Pedal Steel	0	115	28	Regular	
Bass	Vintage Round	8	32	18	S.Articulation!	
	Acoustic Bass	8	32	17	S.Articulation!	
	Vintage Flat	8	33	18	S.Articulation!	
	Soft Acoustic Bass	8	33	17	S.Articulation!	
	Vintage Mute	8	32	19	S.Articulation!	
	Bass & Cymbal	0	114	33	Regular	
	Vintage Pick	104	1	35	Regular	
	Fusion Bass	0	113	37	Regular	
	Fretless Bass	8	32	20	S.Articulation!	
	Slap Bass	0	112	37	Regular	
	Vintage Round	104	1	34	Cool!	
	Soft Acoustic Bass	104	2	33	Cool!	
	Vintage Flat	104	2	34	Cool!	
	Acoustic Bass	104	1	33	Cool!	
	Vintage Mute	104	3	34	Cool!	
	Ballroom Bass	104	0	33	Cool!	
	Vintage Pick Mute	104	0	35	Cool!	
	Half Mute	0	115	34	Cool!	
	Fretless Bass	0	112	36	Cool!	
	Vintage Dyno	104	2	35	Cool!	
	Rock Bass	0	114	35	Regular	
	Electric Bass	0	114	34	Cool!	
	Dyno Pick Bass	0	113	35	Cool!	
	Mellow Finger	0	112	34	Regular	
	Super Fretless	0	113	36	Regular	
	Pick Bass	0	112	35	Regular	
	Funk Bass	0	112	38	Regular	
	Synth Bass	Lo Bass	104	0	40	Regular
		Fat Pulse	104	2	40	Regular
		Dark Bass	104	1	40	Regular
		Wazzo Saw	104	3	81	Regular
		Moon Bass	104	0	39	Regular
		Deep Point	104	3	39	Regular
		Kick Bass	104	1	39	Regular
		Tight Bass	104	3	40	Regular
		Club Bass	104	2	39	Regular
		Competitor	104	4	39	Regular
		1o1 Sub	104	5	39	Regular
		Trance Bass	104	9	39	Regular
		Little Bass Synth	104	6	39	Regular
		Sub Cut Bass	104	5	40	Regular
		Tekno Bass	104	7	39	Regular
		Dyno Acid Bass	104	10	39	Regular
		Perc Punch	104	8	39	Regular
		Mini Sub	104	6	40	Regular
		Square Bass	104	4	40	Regular
		Fat Sine Res	104	11	39	Regular
Ballad Bass		104	7	40	Regular	
House Bass		0	116	39	Regular	
Velo Master		104	17	82	Regular	
Big Drone		0	118	39	Regular	
Sub Bass		0	114	40	Regular	
Hard Bass		0	114	39	Regular	
Reso Bass		0	112	39	Regular	
TB Bass		0	117	40	Regular	

Main Category: STRINGS&VOCAL

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
String Solo	Jazz Violin	8	64	49	S.Articulation2!	
	Viola	0	112	42	Regular	
	Celtic Violin	8	65	49	S.Articulation2!	
	Cello	0	122	43	Natural!	
	Violin	0	113	41	Sweet!	
	Cello	0	112	43	Regular	
	Solo Violin	0	112	41	Regular	
	Contrabass	0	112	44	Regular	
	Fiddle	0	112	111	Regular	
	String Ensemble	Real Strings	8	33	50	S.Articulation!
		Broadway Strings	8	38	49	S.Articulation!
Classical Strings		8	36	49	S.Articulation!	
Concert Strings		8	32	50	S.Articulation!	
Theatre Strings		8	37	49	S.Articulation!	
Pizzicato		0	113	46	Live!	
Lush Strings		8	41	49	S.Articulation!	
Real Tremolo		104	0	45	Live!	
Ballroom Strings		8	35	50	S.Articulation!	
Real Spiccato		104	6	49	Live!	
Studio Strings		8	32	49	S.Articulation!	
Strings		0	122	49	Natural!	
Movie Strings		0	123	49	Live!	
Disco Strings 1		0	123	50	Live!	
Ballad Strings		8	34	50	S.Articulation!	
Disco Strings 2		0	124	50	Live!	
Warm Strings		8	39	49	S.Articulation!	
Tremolo Strings		0	113	45	Live!	
Big Strings		8	40	49	S.Articulation!	
Spiccato		8	33	49	S.Articulation!	
Strings		0	117	50	Live!	
Real Strings f		8	40	50	S.Articulation!	
Allegro		0	122	50	Live!	
Real Strings mf		8	41	50	S.Articulation!	
Dynamic Strings		0	124	49	Live!	
Real Strings p		8	42	50	S.Articulation!	
Chamber Strings		0	112	50	Regular	
Real Tremolo Sfz		104	1	45	Live!	
Tremolo Bowing		8	34	49	S.Articulation!	
Spiccato		0	120	49	Live!	
Strings f		0	119	49	Live!	
Real Strings f		104	4	50	Live!	
Strings mf		0	118	49	Live!	
Real Strings mf	104	5	50	Live!		
Strings p	0	117	49	Live!		
Real Strings p	104	6	50	Live!		
Orchestral Layers	Horns & Strings	8	38	50	S.Articulation!	
	Symphonic Unison	104	0	50	Regular	
	Tutti	0	120	50	Regular	
Theatre Orchestra	104	1	50	Regular		
Pop Vocals	Haa	8	32	40	S.Articulation!	
	Doo	8	38	41	S.Articulation!	
	Wah	8	38	40	S.Articulation!	
	Yoo	8	42	41	S.Articulation!	
	Baa	8	41	40	S.Articulation!	
	Ooh Boys	8	34	41	S.Articulation!	
	Daa	8	45	40	S.Articulation!	
	Ooh Girls	8	36	41	S.Articulation!	
	Ooh	8	32	41	S.Articulation!	
	Pop Ensemble	8	40	56	S.Articulation!	
	Haa Vibrato	8	33	40	S.Articulation!	
	Doo Vibrato	8	39	41	S.Articulation!	
	Wah Vibrato	8	39	40	S.Articulation!	
	Yoo Vibrato	8	43	41	S.Articulation!	
	Baa Vibrato	8	42	40	S.Articulation!	
	Ooh Boys Vibrato	8	35	41	S.Articulation!	
	Daa Vibrato	8	46	40	S.Articulation!	
	Ooh Girls Vibrato	8	37	41	S.Articulation!	
	Ooh Vibrato	8	33	41	S.Articulation!	
	Bee Vibrato	104	4	53	Live!	
	Haa	104	9	53	Live!	
	Doo	104	16	54	Live!	

CVP-609

Main Category: STRINGS&VOCAL

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Pop Vocals	Wah	104	10	53	Live!	
	Yoo	104	18	54	Live!	
	Baa	104	12	53	Live!	
	Doo Boys	8	40	41	S.Articulation!	
	Daa	104	13	53	Live!	
	Doo Girls	8	41	41	S.Articulation!	
	Ooh	104	17	54	Live!	
	Hoo Wah	8	39	56	S.Articulation!	
	AahOoh Auto	8	49	41	S.Articulation!	
	Soft Wah	8	40	40	S.Articulation!	
	Accomp Aah	104	15	53	Live!	
	Haa Boys	8	34	40	S.Articulation!	
	Accomp Ooh	104	15	54	Live!	
	Haa Girls	8	35	40	S.Articulation!	
	Mmh	0	117	53	Live!	
	HooWee Auto	8	56	56	S.Articulation!	
	Jazz Vocals	ShooBeeDooBah 1	8	32	56	S.Articulation!
		DoBeDoBe	8	48	56	S.Articulation!
		ShooBeeDooBah 2	8	47	56	S.Articulation!
YaBaDaBa		8	51	56	S.Articulation!	
BaDaYah		8	36	56	S.Articulation!	
WhoAreYou		8	54	56	S.Articulation!	
WhtShouldWeDo		8	53	56	S.Articulation!	
DoWeYoBe		8	52	56	S.Articulation!	
ShooBeeDynamic		8	35	56	S.Articulation!	
ShooBaDooBa		8	55	56	S.Articulation!	
Scat Vocalists		8	42	56	S.Articulation!	
Latin Vocals		8	41	56	S.Articulation!	
Jazz Singers Shoo		8	45	56	S.Articulation!	
Baroque Scat		8	43	56	S.Articulation!	
Jazz Singers Dwee		8	46	56	S.Articulation!	
Scatman Legato		8	50	56	S.Articulation!	
Gospel Choir		Gospel Hmm	8	32	55	S.Articulation!
	WowHeyHmm	8	35	55	S.Articulation!	
	Gospel Wow	8	33	55	S.Articulation!	
	Gospel Hmm	104	12	54	Live!	
	Gospel Hey	8	34	55	S.Articulation!	
	Gospel Wow	104	13	54	Live!	
	Gospel MW 1	8	36	55	S.Articulation!	
	Gospel Hey	104	7	53	Live!	
	Gospel MW 2	8	37	55	S.Articulation!	
	Gospel MW 1	8	32	52	S.Articulation!	
Classical Choir	Boys Choir Ooh	8	32	52	S.Articulation!	
	Boys Choir Aah	8	33	52	S.Articulation!	
	Soft Choir Ooh	8	35	52	S.Articulation!	
	Soft Choir Aah	8	36	52	S.Articulation!	
	Boys Choir MW	8	34	52	S.Articulation!	
	Boys Choir OoAa	8	49	56	S.Articulation!	
	Choir	0	122	53	Natural!	
	Choir & Organ	0	123	53	Natural!	
	Gothic Vox	0	113	54	Regular	

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Brass Solo	Jazz Trumpet	8	64	66	S.Articulation2!	
	Classic Trumpet	8	65	66	S.Articulation2!	
	Trumpet	8	32	65	S.Articulation!	
	Cornet	0	119	57	Sweet!	
	Silver Trumpet	8	33	65	S.Articulation!	
	Muted Trumpet	0	114	60	Sweet!	
	Golden Trumpet	8	34	65	S.Articulation!	
	Flugel Horn	0	118	57	Sweet!	
	Big Band Trumpet	8	37	65	S.Articulation!	
	Trombone	0	117	58	Sweet!	
	Trumpet Fall	8	38	65	S.Articulation!	
	Trumpet	0	115	57	Sweet!	
	Trumpet Shake	8	35	65	S.Articulation!	
	Mellow Trumpet	0	120	57	Sweet!	
	SilverTrumpet	0	121	57	Sweet!	
	Muted Cornet	104	0	60	Sweet!	
	Golden Trumpet	0	122	57	Sweet!	
	Baritone Horn	0	113	59	Regular	
	Tuba	104	0	59	Regular	
	Bright Trombone	104	0	58	Sweet!	
	Baritone Hit	0	114	59	Regular	
	Alp Bass	0	113	34	Regular	
	Brass Ensemble	Horns	104	0	61	Live!
		Big Band Brass	8	37	57	S.Articulation!
		Soft Horns	8	32	61	S.Articulation!
		Smooth Brass	8	36	57	S.Articulation!
		Symphony Horns 1	104	1	61	Live!
		Dynamic Brass	0	127	62	Live!
		Symphony Horns 2	104	2	61	Live!
		Power Brass	0	121	63	Live!
		Warm Horns	8	33	61	S.Articulation!
Accent Brass		0	109	62	Live!	
Stopped Horns		104	3	61	Live!	
Brass Falls f		8	34	57	S.Articulation!	
Muted Horns		8	34	61	S.Articulation!	
Brass Falls mf		8	35	57	S.Articulation!	
Brass f		0	108	62	Live!	
Brass Band		0	123	57	Live!	
Brass mf		0	110	62	Live!	
Soft Horns		0	117	61	Live!	
Brass p		0	111	62	Live!	
Soft Trombones		0	118	61	Live!	
Brass Shake		8	32	57	S.Articulation!	
Pop Brass		0	117	63	Live!	
Accent Falls		8	38	57	S.Articulation!	
Hyper Brass		0	118	63	Live!	
Sforzando		0	105	62	Live!	
Small Brass		0	120	61	Live!	
Sforzando Fall		0	107	62	Live!	
Ballroom Brass		0	113	60	Regular	
Brass Dynamics		0	106	62	Live!	
Octave Brass		0	116	63	Live!	
Sax Solo		Jazz Sax	8	65	81	S.Articulation2!
	Pop Soprano	8	64	85	S.Articulation2!	
	Breathy Sax	8	64	81	S.Articulation2!	
	Ballad Soprano	8	65	85	S.Articulation2!	
	Saxophone	8	32	83	S.Articulation!	
	Alto Sax	8	32	67	S.Articulation!	
	Big Band Sax	8	35	83	S.Articulation!	
	Soft Alto	8	34	67	S.Articulation!	
	Rock Sax	8	33	83	S.Articulation!	
	Growl Sax	0	111	67	Sweet!	
	Soprano Sax	0	113	65	Sweet!	
	Pop Tenor	0	127	67	Sweet!	
	Alto Sax	104	0	66	Sweet!	
	Ballad Tenor	0	126	67	Sweet!	
	Tenor Sax	0	117	67	Sweet!	
	Jazz Tenor	0	125	67	Sweet!	
	Baritone Sax	104	0	68	Regular	
Sax Ensemble	Sax Section	0	116	67	Live!	
	Big Band Octave	0	108	67	Live!	
	Soft Saxes 1	8	38	83	S.Articulation!	

CVP-609

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Sax Ensemble	Big Band Unison	0	109	67	Live!
	Section Saxes	8	36	83	S.Articulation!
	Big Band Saxes	0	110	67	Live!
	Section Saxes Oct	8	37	83	S.Articulation!
	Ballad Section	0	119	67	Regular
	Soft Saxes 2	8	39	83	S.Articulation!
	Sax Appeal	0	123	67	Live!
	Sax Section Hard	0	122	67	Live!
	Moonlight	0	115	72	Regular
Sax Section Soft	0	121	67	Live!	
Woodwind Solo	Clarinet	8	65	93	S.Articulation2!
	Orch Flute	8	32	74	S.Articulation!
	Romance Clarinet	8	66	93	S.Articulation2!
	Flute	0	114	74	Sweet!
	Ballad Clarinet	8	64	93	S.Articulation2!
	Orch Oboe	8	32	69	S.Articulation!
	Orch Clarinet	104	0	72	Live!
	Clarinet	0	114	72	Sweet!
	German Clarinet	104	2	72	Regular
	Orch Bassoon	104	0	71	Sweet!
	Classical Flute	0	115	74	Sweet!
	Oboe	0	113	69	Sweet!
	Piccolo	0	112	73	Regular
English Horn	0	112	70	Regular	
Woodwind Ens	Flutes & Oboes	104	2	74	Regular
	Orch Woodwind	104	1	71	Regular
	Clarinet & Flutes	104	1	72	Regular
	Alto Flutes	104	1	74	Regular
	Clarinet & Oboe	104	1	69	Regular
	Flute Ensemble	0	116	74	Regular
	Oboe & Bassoon	104	2	69	Regular
	Irish Pipe Air	8	64	109	S.Articulation2!
Woodwind World	Pan Flute	0	113	76	Sweet!
	Irish Pipe Dance	8	65	109	S.Articulation2!
	Ocarina	0	112	80	Regular
	Celtic Duo	0	120	74	Regular
	Shakuhachi	0	112	78	Regular
	Bagpipe	0	112	110	Regular
	Recorder	0	112	75	Regular
	Whistle	0	112	79	Regular

Main Category: PERC&DRUMS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Chromatic Perc	Vibraphone	104	1	12	Sweet!	
	Xylophone	104	0	14	Regular	
	Jazz Vibes	0	113	12	Regular	
	Marimba	104	0	13	Regular	
	Tremolo Vibes	0	124	12	Natural!	
	Orchestral Marimba	0	122	13	Natural!	
	Vibes & JazzGtr	8	33	12	S.Articulation!	
	Glockenspiel	104	0	10	Regular	
	Vibes & Flutes	0	114	12	Regular	
	Steel Drums	0	112	115	Regular	
	Vibraphone	0	122	12	Natural!	
	Steel Drums	0	122	115	Natural!	
	Music Box	0	112	11	Regular	
	Kalimba	0	112	109	Regular	
	Orchestral Perc	Orchestral Harp	104	1	47	Regular
		Tubular Bells	0	112	15	Regular
		Mellow Harp	104	0	47	Regular
		Timpani	0	112	48	Regular
		Celesta	0	112	9	Regular
Orchestra Hit		0	112	56	Regular	
Drum Kits	Concert Celesta	0	122	9	Natural!	
	Real Drums	127	0	92	Live!Drums	
	Power Kit 1	127	0	88	Live!Drums	
	Real Brushes	127	0	42	Live!Drums	
	Power Kit 2	127	0	89	Live!Drums	
	Acoustic Kit	127	0	90	Live!Drums	
House Kit	127	0	61	Drums		

Main Category: PERC&DRUMS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Drum Kits	Rock Kit	127	0	91	Live!Drums
	Drum Machine	127	0	62	Drums
	Studio Kit	127	0	87	Live!Drums
	Analog T8 Kit	127	0	59	Drums
	Analog T9 Kit	127	0	60	Drums
	Jazz Kit	127	0	33	Drums
	Break Kit	127	0	58	Drums
	Hit Kit	127	0	5	Drums
	Hip Hop Kit	127	0	57	Drums
	Room Kit	127	0	9	Drums
	Dance Kit	127	0	28	Drums
	Electro Kit	127	0	25	Drums
	Analog Kit	127	0	26	Drums
	Symphony Kit	127	0	49	Live!Drums
World Perc Kits	Turkish Kit	126	0	68	Live!SFX
	Cuban Kit	126	0	41	Live!SFX
	Pop Latin Kit	126	0	44	Live!SFX
Vocal Effects	Gospel AdLibs	126	0	111	Live!SFX
	Vocal Effects Kit	126	0	110	Live!SFX
SFX	New SFX Kit 1	126	0	3	Live!SFX
	Helicopter	104	0	126	Live!
	New SFX Kit 2	126	0	4	Live!SFX
	Applause 1	104	0	127	Live!
	Noises Kit	126	0	9	SFX Kit
	Applause 2	104	1	127	Live!
	Sea Shore	104	0	123	Live!
	Gun Shot	104	0	128	Live!

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Synth Lead	Sub Lead	104	0	81	Regular	
	Wire Lead	0	120	82	Regular	
	Soft Saw	104	16	82	Regular	
	Soft R&B	0	119	81	Regular	
	Fusion Lead	104	15	82	Regular	
	Early Lead	0	118	82	Regular	
	Oxygen	0	122	82	Regular	
	Soft Square	104	5	81	Regular	
	Matrix	0	123	82	Regular	
	Detuned Vintage	104	1	85	Regular	
	PWM Lead	104	1	82	Regular	
	Hipa Lead	0	118	85	Regular	
	Brassy Lead	104	5	63	Regular	
	Punchy Hook	0	127	82	Regular	
	Punch Lead	104	7	82	Regular	
	Crying Lead	0	114	88	Regular	
	Flange Filter	104	2	82	Regular	
	Hip Lead	0	113	81	Regular	
	Mouth Lead	104	0	82	Regular	
	Hop Lead	0	117	81	Regular	
	Tech Lead	0	117	85	Regular	
	Analogon	0	115	82	Regular	
	Tekkline	0	116	85	Regular	
	Skyline	0	115	85	Regular	
	Soft Mini	0	124	81	Regular	
	Bleep Lead	104	0	85	Regular	
	Fire Wire	0	116	82	Regular	
	Synth Perc	New Heaven	104	10	89	Regular
		Heaven Pad	104	3	92	Regular
Fantasy Bells		104	11	89	Regular	
Breath Bells		104	15	89	Regular	
Itopia Bells		104	13	89	Regular	
Next Generation		104	9	52	Regular	
Sinesphere		104	18	89	Regular	
Organ Bells		104	12	89	Regular	
Spectrum Theme		104	14	89	Regular	
Sky Bells		104	16	89	Regular	
Flying Harmonics		104	1	100	Regular	
Perc Pad		104	0	102	Regular	
Nylon Heaven		104	2	100	Regular	

CVP-609

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Synth Perc	Mediterrain	0	114	100	Regular	
	Airy Harp	104	17	89	Regular	
	Lektro Codes	104	2	85	Regular	
	Nylon Pad	104	0	100	Regular	
	Simple Comp	104	12	82	Regular	
	Bellsphere	104	5	89	Regular	
	Ballad Comp	104	6	89	Regular	
	Heaven Bell	104	0	101	Regular	
	Digital Seq	104	2	88	Regular	
	Bright Pad Bell	104	7	89	Regular	
	Analog Seq	104	3	88	Regular	
	Wild PWM	104	4	81	Regular	
	Perc Seq FS	104	6	88	Regular	
	Resonant Clavi	104	2	91	Regular	
	Perc Seq FM 1	104	7	88	Regular	
	Resonance Comp	104	4	63	Regular	
	Perc Seq FM 2	104	8	88	Regular	
	Synth Sticks	104	0	107	Regular	
	Attack	104	4	82	Regular	
	Saz Feeze	104	0	98	Regular	
	PWM Percussion	104	6	82	Regular	
	Eastern Air	104	1	98	Regular	
	Nomad	104	1	105	Regular	
	Xtune	104	1	88	Regular	
	Stack Bell	104	8	89	Regular	
	Perc Seq Saw	104	11	82	Regular	
	Nice Bell	104	9	89	Regular	
	Synth Strings	Synth Strings 1	0	112	51	Regular
		Butter Strings	104	2	51	Regular
		Synth Strings 2	0	113	51	Regular
		Bright Saw Pad	0	113	91	Regular
		Ober Strings	0	113	52	Regular
Soft Ensemble		104	1	51	Regular	
Hipa Strings		0	114	96	Regular	
80s Pad		104	1	52	Regular	
Oct Strings		104	4	51	Regular	
Bright Pop Pad		104	3	51	Regular	
Doux Flange		104	3	96	Regular	
Premium Pad		104	0	52	Regular	
Light Pad		104	2	52	Regular	
Bright Pad Classic		104	3	91	Regular	
Medium Tune Pad		104	0	51	Regular	
Synth Brass		Analog Brass	0	112	64	Regular
	1984 Synth	104	20	82	Regular	
	Fat Synth Brass	0	116	64	Regular	
	80s Brass	0	113	63	Regular	
	Thinth Brass	104	0	63	Regular	
	Funky Analog	0	115	63	Regular	
	Brass Profit	104	1	63	Regular	
	Techno Brass	0	114	63	Regular	
	Ober Brass	0	113	64	Regular	
	Ober Horns	0	115	64	Regular	
	Slow PWM Brass	104	2	63	Regular	
	Soft Velo Brass	0	120	63	Regular	
	Fast PWM Brass	104	6	63	Regular	
	Soft Analog	0	114	64	Regular	
Synth Pad	All or Nothing	104	6	102	Regular	
	Whisper Gallery	104	0	93	Regular	
	Disisweeper	104	7	102	Regular	
	Hybrid Lines	104	4	92	Regular	
	Spectrum Pad	104	5	95	Regular	
	Midnight Special	104	3	102	Regular	
	Hybrid Pad	104	22	89	Regular	
	Atmo 5th	104	6	90	Regular	
	Deep Motion	104	4	96	Regular	
	Pad Voices	104	6	96	Live!	
	Skydiver	0	112	102	Regular	
	Aerosphere	104	1	95	Regular	
	Cross Phase	104	1	102	Regular	
	New Atmosphere	104	4	90	Regular	
	Galaxy Pad	104	3	89	Regular	
	VP Soft	104	0	90	Regular	

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Synth Pad	Night Motion	104	4	89	Regular	
	Hot Swell	104	2	96	Regular	
	Morning Dew	104	0	95	Regular	
	Dark Fat Saw	104	2	90	Regular	
	Vapor Pad	104	1	90	Regular	
	Dark Light	104	3	90	Regular	
	Space Rider	104	1	96	Regular	
	Ambient Pad	104	0	89	Regular	
	Pearls Pad	104	2	89	Regular	
	Bright Fat Saw	104	5	91	Regular	
	Breath Pad	104	0	92	Regular	
	Early Digital	104	0	94	Regular	
	Noble Man	104	1	89	Regular	
	Super Dark Pad	0	119	90	Regular	
	Analog Pad	0	120	90	Regular	
	Analog Swell	0	119	96	Regular	
	Dark Angel Pad	0	121	90	Regular	
	Big Octave Pad	0	115	91	Regular	
	Lite Pad	0	122	90	Regular	
	Golden Age	0	115	89	Regular	
	Pop Pad	0	112	91	Regular	
	Solaris	0	114	95	Regular	
	Glorious Phase	0	114	91	Regular	
	Insomnia	0	113	95	Regular	
	Ober Sweep	0	115	96	Regular	
	Neo Warm Pad	0	115	90	Regular	
	Time Travel	0	116	89	Regular	
	Cyber Pad	0	113	100	Regular	
	Bubblespace	0	113	102	Regular	
	Bright Ober	0	113	96	Regular	
	Mellow Pad	0	117	96	Regular	
	Dark Pad	0	118	96	Regular	
	Synth Dance	Ana Dayz	104	3	52	Regular
		HPF Dance	104	0	91	Regular
		Bright Pad Trance	104	4	91	Regular
		Detuned Saw Oct	104	8	82	Regular
		Chillin Chords	104	6	52	Regular
		Dancy Hook	104	9	82	Regular
		Trance MW	104	0	96	Regular
		Vinalog Saw	104	3	82	Regular
		Club Lead	104	3	63	Regular
		Talk Mod Lead	104	0	88	Regular
		Trance Perc	104	5	82	Regular
		Chorus Saw Lead	104	10	82	Regular
		Chordmaster	104	13	82	Regular
		Faaat Comp	104	4	52	Regular
		Trance Seq 1	104	4	88	Regular
		Fat Saw Hook	104	7	52	Regular
Trance Seq 2		104	5	88	Regular	
Tech Glide		104	14	82	Regular	
Trance Seq 3		104	1	91	Regular	
Dance Chords		104	5	52	Regular	
Dance Hook		0	112	87	Regular	
Trance Lead		0	121	81	Regular	
Octave Hook		0	113	87	Regular	
Synth Effects		Water Games	104	4	102	Regular
	Spectrais	104	4	95	Regular	
	My Generation	104	5	102	Regular	
	Metallic Rain	104	8	102	Regular	
	Rainy Day	104	5	90	Regular	
	Ambient Theme	104	20	89	Regular	
	Warped Waves	104	2	95	Regular	
	Reflecting Zone	104	21	89	Regular	
	Sound Pictures	104	3	95	Regular	
	The Fog	104	9	102	Regular	
	Mystic Pad	104	6	95	Regular	
	Sixth Sense	104	2	102	Regular	
	Randomizer	104	10	102	Regular	
	Pitch Fall	104	0	104	Regular	
Atlantis	104	11	102	Regular		
Perc Seq Hipa	104	9	88	Regular		
Tric-Trac	104	2	98	Regular		

CVP-609

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
Legacy	Piano	Grand Piano	0	113	1	Live!
		Warm Grand	0	114	1	Live!
		Bright Piano	0	112	2	Live!
		Honky Tonk	0	122	4	Natural!
		Grand Piano 1octave	104	2	4	Natural!
		Grand Piano 2octave	104	3	4	Natural!
		Pop Grand	104	5	1	Live!
		Rock Piano	104	4	1	Live!
		Ambient Piano	104	3	1	Live!
		Cocktail Piano	104	0	4	Live!
		MIDI Grand	0	112	3	Regular
		MIDI Grand	104	0	3	Live!
		MIDI GrandPad	104	1	3	Live!
		MIDI GrandSyn	104	1	1	Live!
		Octave Piano 1	0	113	4	Live!
		Octave Piano 2	0	114	4	Live!
		Piano Orchestra	104	2	1	Live!
		Honky Tonk	0	112	4	Regular
		Harpsichord	0	112	7	Live!
		E.Piano	Ballad Stack	0	114	3
	Jazz Chorus		0	118	6	Regular
	Hyper Tines		0	113	6	Regular
	Venus EP		0	114	6	Regular
	Super DX		0	117	6	Regular
	Polaris EP		0	115	5	Regular
	DX Modern		0	112	6	Regular
	New Tines		0	116	6	Regular
	Phase EP		0	120	5	Regular
	Modern EP		0	115	6	Regular
	Funk EP		0	112	5	Regular
	Chorus Bell		0	120	6	Regular
	Stereo Clavi		0	114	8	Regular
	Organ	Dance Organ	0	113	18	Regular
Click Organ		0	112	18	Regular	
Reed Organ		0	112	21	Regular	
Rotary Switch		0	110	18	Cool!	
Rotary Drive		0	116	19	Regular	
Full Rocker 2		104	3	19	Cool!	
Gospel Organ		0	119	17	Regular	
Purple Organ		0	114	19	Regular	
60s Organ		0	116	18	Regular	
Perc Organ		0	119	18	Regular	
Drawbar Organ 1		0	120	18	Regular	
Drawbar Organ 2		0	115	17	Regular	
Rock Organ 1		0	112	19	Regular	
Jazz Organ 1		0	112	17	Regular	
Rock Organ 2		0	119	19	Regular	
Jazz Organ 2		0	113	17	Regular	
Rock Organ 3		0	113	19	Regular	
Jazz Organ 3		0	120	17	Regular	
Bright Draw		0	116	17	Regular	
Electric Organ		0	118	18	Regular	
Tibia 8&4 Acmp		0	122	17	Regular	
Tibia 16&4 Acmp		0	114	17	Regular	
Tibia Full Acmp		0	114	18	Regular	
Tibia 8 Acmp		0	122	18	Regular	
Vox 8 Acmp		0	123	18	Regular	
Vox & Tibia Acmp		0	125	17	Regular	
Strings		Orch Strings	0	113	49	Regular
		Symphonic	0	114	49	Regular
		Slow Strings	0	113	50	Regular
		Strings	0	112	49	Regular
	Tremolo Strings	0	112	45	Regular	
	Bow Strings	0	116	49	Regular	
	Marcato	0	115	50	Regular	
	Pizzicato	0	112	46	Regular	
	String Falls	0	121	49	Live!	
	Analog Strings	0	112	52	Regular	
	Concerto Strings	0	115	49	Regular	
	Orchestra	0	116	50	Live!	
	Orch & Flute	0	119	50	Regular	
	Orch & Oboe	0	121	50	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Strings	Orch & Horns	0	118	50	Regular	
		String Quartet	0	114	50	Regular	
		Harp	0	112	47	Regular	
		Hackbrett 2	0	113	47	Regular	
		Banjo 2	0	112	106	Regular	
		Sitar 2	0	112	105	Regular	
		Choir	Voices	0	113	55	Regular
			Choir	0	112	53	Regular
	Air Choir		0	112	55	Regular	
	Vox Humana		0	112	54	Regular	
	Gospel Voices		0	116	53	Live!	
	Humming		0	118	53	Live!	
	Sweet Heaven		0	118	89	Regular	
	Dream Heaven		0	121	89	Regular	
	Bell Heaven		0	119	89	Regular	
	Pan Heaven		0	120	89	Regular	
	Pro Heaven		0	122	89	Regular	
	Sunbeam		0	123	89	Regular	
	Hah Choir		0	114	53	Regular	
	Uuh Choir		0	115	53	Regular	
	Boys Choir Aah		104	8	53	Live!	
	Boys Choir Ooh		104	8	54	Live!	
	Hah Pad		0	116	95	Regular	
	Brass		Brass Section	0	112	62	Regular
		Brass Combo	0	115	67	Regular	
		Natural Brass	0	124	62	Regular	
		Bright Brass	0	120	62	Regular	
		French Horns	0	112	61	Live!	
		Mellow Horns	0	119	62	Regular	
		Symphony Brass	0	119	61	Live!	
		Symphony Horns	0	115	61	Live!	
		Big Band Brass	0	113	62	Regular	
		Mellow Brass	0	116	62	Regular	
		Big Brass	0	121	62	Regular	
		Small Brass	0	117	62	Regular	
		Soft Brass	0	123	62	Regular	
		Sforzando	0	125	62	Regular	
		High Brass	0	115	62	Regular	
		Breath Brass	0	116	61	Regular	
		Full Horns	0	114	62	Regular	
		Trumpet Ens	0	122	62	Regular	
		Smooth Trombone	0	118	58	Regular	
		Tb Section	0	113	58	Regular	
		Hybrid Comp	0	119	63	Regular	
		Hybrihorn	0	113	61	Regular	
		Hybridpad	0	114	61	Regular	
		Pop Brass	0	118	62	Regular	
		Synth Brass	0	112	63	Regular	
		Brass Hit	0	126	62	Regular	
		Trumpet	Solo Trumpet	0	112	57	Regular
			Jazz Trumpet	0	116	57	Regular
	Muted Trumpet		0	112	60	Regular	
	Flugel Horn		0	113	57	Regular	
	Solo Trombone		0	112	58	Regular	
	Trombone		0	116	58	Regular	
	Soft Trombone		0	115	58	Regular	
	Mellow Trombone		0	114	58	Regular	
	Tuba 2		0	112	59	Regular	
	Saxophone		Soprano Sax	0	112	65	Regular
			Alto Sax	0	112	66	Regular
			Tenor Sax	0	112	67	Regular
		Baritone Sax	0	112	68	Regular	
		Alto Sax	0	114	66	Sweet!	
		Saxophone	104	0	67	Sweet!	
		Growl Sax	0	118	67	Regular	
		Sax Stack	0	124	67	Regular	
		Saxy Mood	0	120	67	Regular	
		Flute&Clarinet	Flute	0	112	74	Regular
	Oboe		0	112	69	Regular	
	Clarinet		0	112	72	Regular	
	Bassoon		0	112	71	Regular	
	Pan Flute		0	113	74	Regular	

CVP-609

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Flute&Clarinet	Ethnic Flute	0	112	76	Regular	
		Orch Flute	104	0	74	Sweet!	
		Orch Oboe	104	0	69	Sweet!	
		Woodwinds Ens	0	113	67	Regular	
	Guitar	Vintage Amp	8	40	4	S.Articulation!	
		70s Solid Guitar	104	1	28	Cool!	
		Warm Solid	104	2	28	Cool!	
		Clean Solid	104	3	28	Cool!	
		Muted Guitar	0	112	29	Regular	
		Funk Guitar	0	113	29	Regular	
		Solid Chord	0	121	28	Regular	
		Solid Guitar	0	118	28	Regular	
		Electric 12Str	0	119	28	Regular	
		DX Jazz Guitar	0	117	27	Regular	
		Tremolo Guitar	0	113	28	Regular	
		Wah Guitar	0	122	28	Regular	
		Chorus Guitar	0	124	28	Regular	
		Vintage Trem	0	120	28	Regular	
		Deep Chorus	0	114	28	Regular	
		Bright Clean	0	116	28	Regular	
		Half Drive	104	0	30	Cool!	
		Guitar Hero	104	0	31	Cool!	
		Heavy Rock	104	1	31	Cool!	
		Smooth Lead	0	119	27	Regular	
		Power Chord	0	117	31	Regular	
		Rock Guitar	0	116	30	Regular	
		Voodoo Lead	0	116	31	Regular	
		Lead Guitar	0	114	30	Regular	
		Distortion Guitar	0	112	31	Regular	
		Overdrive Guitar	0	112	30	Regular	
		Feedback Guitar	0	113	30	Regular	
		Folk Guitar	0	112	26	Regular	
		Campfire Guitar	0	115	26	Regular	
		18String	0	119	26	Regular	
		Bass	Click Bass	0	115	39	Regular
			Punchy Bass	0	117	39	Regular
			Analog Bass	0	112	40	Regular
	DX Funk Bass		0	113	38	Regular	
	Dry Synth Bass		0	116	40	Regular	
	80s Synth Bass		0	115	40	Regular	
	HiQ Bass		0	113	39	Regular	
	Acoustic Bass		0	112	33	Regular	
	Perc&Drum	Standard Kit 1	127	0	1	Live!Drums	
		Standard Kit 2	127	0	2	Live!Drums	
		Rock Kit	127	0	17	Drums	
		Brush Kit	127	0	41	Live!Drums	
		Vibraphone	0	112	12	Regular	
		Marimba	0	112	13	Regular	
		Xylophone	0	112	14	Regular	
		Glockenspiel	0	112	10	Regular	
		SFX Kit 1	126	0	1	SFX Kit	
		SFX Kit 2	126	0	2	SFX Kit	
		Arabic Kit	126	0	36	SFX Kit	
Accordion		Accordion	0	116	22	Regular	
		Small Accordion	0	115	22	Regular	
	Modern Harp	0	113	23	Regular		
	Blues Harp	0	114	23	Regular		
	Ballroom Acc	0	112	24	Regular		
	Soft Accordion	0	114	22	Regular		
	Tutti Accordion	0	113	22	Regular		
	Musette	0	112	22	Regular		
Pad	Psycho Pad	0	118	102	Regular		
	Far East	0	112	98	Regular		
	Disclosure	0	116	90	Regular		
	Mystery	0	113	98	Regular		
	Sirius	0	114	102	Regular		
	S&H Groove	0	115	102	Regular		
	Velo Ashrami	0	116	102	Regular		
	Evening Stars	0	117	102	Regular		
	Angel Vibes	0	114	99	Regular		
	Glass Pad	0	114	94	Regular		
	DX Pad	0	112	93	Regular		

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type		
			MSB	LSB	Prg			
Legacy	Pad	Symbiont	0	113	89	Regular		
		Dark Moon	0	113	90	Regular		
		Ionosphere	0	115	95	Regular		
		Millennium	0	117	89	Regular		
		Atmosphere	0	112	100	Regular		
		Equinox	0	112	95	Regular		
		Fantasia	0	112	89	Regular		
		Stargate	0	114	89	Regular		
		Area 51	0	112	90	Regular		
		Digital Pad	0	115	94	Regular		
		Dunes	0	114	90	Regular		
		Messenger	0	116	96	Regular		
		Wave 2001	0	112	96	Regular		
		Xenon Pad	0	112	92	Regular		
		Magic Bell	8	32	121	S.Articulation!		
		Synth	Pro Lead	0	113	84	Regular	
			Funky Lead	0	121	82	Regular	
			Portatone	0	112	85	Regular	
			Adrenaline	0	113	85	Regular	
			Stardust	0	112	99	Regular	
			Aero Lead	0	112	84	Regular	
			Mini Lead	0	114	81	Regular	
			Sun Bell	0	113	99	Regular	
			Hi Bias	0	116	81	Regular	
			Vinyl Lead	0	115	81	Regular	
			Pan Lead	0	122	81	Regular	
			String Bells	0	124	89	Regular	
			Padbells	0	126	89	Regular	
	Big Tune		0	118	90	Regular		
	Trumpet Saw		0	125	82	Regular		
	Paraglide		0	114	85	Regular		
	Robolead		0	124	82	Regular		
	Fargo		0	119	82	Regular		
	Big Lead		0	113	82	Regular		
	Warp		0	117	82	Regular		
	Impact		0	113	88	Regular		
	Under Heim		0	112	88	Regular		
	Crystal Eyes		0	125	89	Regular		
	Melody Maker		0	117	90	Regular		
	Attack Saw		0	126	82	Regular		
	Perc Square		0	123	81	Regular		
	Square Lead		0	112	81	Regular		
	Saw Lead		0	112	82	Regular		
	Pop Lead		0	120	81	Regular		
	Bright Mini		0	125	81	Regular		
	Orbit Sine		0	126	81	Regular		
	Blaster		0	114	82	Regular		
	Tiny Lead		0	118	81	Regular		
	StyleVoices		Piano	Concert Grand [Sty]	0	122	1	Natural!
				Studio Grand [Sty]	0	115	1	Live!
				Grand Piano [Sty]	0	122	2	Natural!
				Mellow Piano [Sty]	0	124	1	Natural!
				Pop Grand 1 [Sty]	104	6	1	Natural!
				Pop Grand 2 [Sty]	104	11	1	Natural!
		Rock Piano [Sty]		0	124	3	Natural!	
		Stage Piano [Sty]		104	10	1	Natural!	
		Ambient Piano [Sty]		104	9	1	Natural!	
		Cocktail Piano [Sty]		104	1	4	Natural!	
		Grand Piano 1octave [Sty]		0	123	4	Natural!	
		Grand Piano 2octave [Sty]		0	124	4	Natural!	
		Upright Piano [Sty]		104	13	1	Natural!	
		Pop Upright [Sty]		104	13	2	Natural!	
		70s Ballad Piano [Sty]		104	14	1	Natural!	
		Chill Out Piano [Sty]		104	15	1	Natural!	
		Honky Tonk Upright [Sty]		104	13	4	Natural!	
		Saloon Upright [Sty]		104	14	2	Natural!	
		Upright 1octave [Sty]		104	14	4	Natural!	
Upright 2octave [Sty]		104		15	4	Natural!		
Ballad Grand 1 [Sty]		104		4	5	Natural!		
Ballad Grand 2 [Sty]		104		5	5	Natural!		
MIDI Grand [Sty]		104		2	3	Natural!		
MIDI Grand Pad [Sty]		104		3	3	Natural!		

CVP-609

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
StyleVoices	Piano	Piano & Strings [Sty]	0	125	1	Natural!	
		Piano Orchestra [Sty]	104	12	1	Natural!	
		Grand Pad Layer [Sty]	104	5	3	Natural!	
		MIDI Grand Syn [Sty]	104	8	1	Natural!	
		Piano & EP 1 [Sty]	0	122	3	Natural!	
		Piano & Choir [Sty]	0	126	1	Natural!	
		Piano & EP 2 [Sty]	0	125	3	Natural!	
		Piano & Pad [Sty]	0	118	1	Natural!	
		Suitcase EP [Sty]	0	118	5	Cool!	
		Vintage EP [Sty]	0	116	5	Regular	
		Electric Piano 1 [Sty]	0	119	5	Cool!	
		Electric Piano 2 [Sty]	0	122	5	Natural!	
		Stage EP [Sty]	0	117	5	Regular	
		Funky EP [Sty]	0	123	5	Natural!	
		Tremolo Suitcase EP [Sty]	0	113	5	Cool!	
		Tremolo Stage EP [Sty]	0	124	5	Natural!	
		Smooth Tine [Sty]	0	119	6	Regular	
		CP80 Studio [Sty]	0	123	3	Natural!	
		Magnetics [Sty]	104	0	5	Regular	
		CP80 Stage [Sty]	0	113	3	Regular	
		Piano Sweeper [Sty]	104	3	100	Regular	
		Pianosphere [Sty]	104	19	89	Regular	
		Bright Piano [Sty]	0	123	1	Natural!	
		Organ	Harmonica [Sty]	8	80	105	S.Articulation2!
			Blues Harp [Sty]	8	81	105	S.Articulation2!
		Guitar&Bass	Nylon Guitar [Mega]	8	0	1	MegaVoice
			Steel Guitar [Mega]	8	0	2	MegaVoice
			12String Guitar [Mega]	8	1	3	MegaVoice
			Hi String Guitar [Mega]	8	0	3	MegaVoice
			Finger Guitar [Mega]	8	4	4	MegaVoice
			Finger Slap Guitar [Mega]	8	5	4	MegaVoice
			Vintage Pick Guitar [Mega]	8	6	4	MegaVoice
			Vintage Slap Guitar [Mega]	8	7	4	MegaVoice
	Slap Amp Guitar [Mega]		8	8	4	MegaVoice	
	Single Coil [Mega]		8	3	4	MegaVoice	
	Jazz Guitar [Mega]		8	0	7	MegaVoice	
	Solid Guitar 1 [Mega]		8	1	4	MegaVoice	
	Solid Guitar 2 [Mega]		8	2	4	MegaVoice	
	Clean Guitar [Mega]		8	0	4	MegaVoice	
	Overdrive Guitar [Mega]		8	0	5	MegaVoice	
	Distortion Guitar [Mega]		8	0	6	MegaVoice	
	Vintage Round [Mega]		8	1	18	MegaVoice	
	Vintage Flat [Mega]		8	2	18	MegaVoice	
	Vintage Pick [Mega]		8	1	19	MegaVoice	
	Acoustic Bass [Mega]		8	0	17	MegaVoice	
	Electric Bass [Mega]		8	0	18	MegaVoice	
	Pick Bass [Mega]		8	0	19	MegaVoice	
	Fretless Bass [Mega]		8	0	20	MegaVoice	
	Strings&Vocal		Jazz Violin [Sty]	8	80	49	S.Articulation2!
			Celtic Violin [Sty]	8	81	49	S.Articulation2!
			Classical Strings [Mega]	8	1	49	MegaVoice
			Real Strings [Mega]	8	1	50	MegaVoice
		Large Strings [Mega]	8	0	50	MegaVoice	
		Small Strings [Mega]	8	0	49	MegaVoice	
		Gospel Choir [Mega]	8	0	55	MegaVoice	
		Male Voice Choir [Mega]	8	0	52	MegaVoice	
		Pop Haa [Mega]	8	0	101	MegaVoice	
		Pop Daa [Mega]	8	0	102	MegaVoice	
		Pop Baa [Mega]	8	0	103	MegaVoice	
		Pop Hoo [Mega]	8	0	106	MegaVoice	
		Pop Doo [Mega]	8	0	107	MegaVoice	
		Pop Shoo [Mega]	8	0	104	MegaVoice	
		Pop Hee [Mega]	8	0	111	MegaVoice	
		Pop Bee [Mega]	8	0	108	MegaVoice	
		Pop Haa L2 [Mega]	8	0	116	MegaVoice	
		Pop Hoo L2 [Mega]	8	0	121	MegaVoice	
		Pop Hee L2 [Mega]	8	0	126	MegaVoice	
		Brass&Woodwind	Jazz Trumpet [Sty]	8	80	66	S.Articulation2!
	Classic Trumpet [Sty]		8	81	66	S.Articulation2!	
	Jazz Sax [Sty]		8	81	81	S.Articulation2!	
	Breathy Sax [Sty]		8	80	81	S.Articulation2!	
	Pop Soprano [Sty]		8	80	85	S.Articulation2!	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
StyleVoices	Brass&Woodwind	Ballad Soprano [Sty]	8	81	85	S.Articulation2!
		Clarinet [Sty]	8	81	93	S.Articulation2!
		Ballad Cl [Sty]	8	80	93	S.Articulation2!
		Irish Pipe Air [Sty]	8	80	109	S.Articulation2!
		Irish Pipe Dnc [Sty]	8	81	109	S.Articulation2!
		Romance Cl [Sty]	8	82	93	S.Articulation2!
		Trumpet [Mega]	8	0	65	MegaVoice
		Brass [Mega]	8	0	57	MegaVoice
		Tenor Sax [Mega]	8	0	83	MegaVoice

CVP-605

Main Category: PIANO

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Grand Piano	Concert Grand	108	0	1	Natural!
	Studio Grand	108	16	1	Live!
	Grand Piano	108	17	1	Natural!
	Mellow Piano	108	18	1	Natural!
	Pop Grand 1	108	17	2	Natural!
	Pop Grand 2	108	26	1	Live!
	Rock Piano	108	16	3	Natural!
	Stage Piano	108	27	1	Live!
	Ambient Piano	108	28	1	Live!
	Cocktail Piano	108	26	4	Live!
	Grand Piano 1octave	108	22	2	Natural!
	Grand Piano 2octave	108	23	2	Natural!
	Bright Piano	108	16	2	Natural!
	Upright Piano	Upright Piano	108	16	4
Pop Upright		108	19	4	Natural!
70s Ballad Piano		108	17	4	Natural!
Chill Out Piano		108	18	4	Natural!
Honky Tonk Upright		108	20	4	Natural!
Saloon Upright		108	21	4	Natural!
Upright 1octave		108	22	4	Natural!
Upright 2octave		108	23	4	Natural!
Piano Layer	Ballad Grand 1	108	25	5	Natural!
	Piano Orchestra	108	29	1	Live!
	Ballad Grand 2	108	26	5	Natural!
	Piano & Strings	108	23	1	Natural!
	Grand Pad Layer	108	32	3	Natural!
	Piano & EP	108	25	3	Natural!
Electric Piano	Suitcase EP	108	16	5	Cool!
	Vintage EP	108	19	5	Regular
	Electric Piano 1	108	17	5	Cool!
	Electric Piano 2	108	21	5	Natural!
	Stage EP	108	20	5	Regular
	Funky EP	108	24	5	Natural!
	Tremolo Suitcase EP	108	18	5	Cool!
	Tremolo Stage EP	108	23	5	Natural!
	Smooth Tine	108	16	6	Regular
	CP80 Stage	108	19	3	Regular
FM E.Piano	Studio Ballad DX	104	9	6	Regular
	Sparkle Stack	0	121	6	Cool!
	Sweet DX	104	0	6	Cool!
	Ballad DX	0	124	6	Cool!
	DX Dynamics	0	123	6	Cool!
	Ballad Bells	104	2	6	Cool!
	Galaxy EP	0	114	5	Cool!
	DX7 EP	0	122	6	Natural!
	Dream DX	104	3	6	Cool!
	Midnight DX	104	1	6	Cool!
Clavi	Clavi	0	112	8	Regular
	Wah Clavi	0	113	8	Regular
	Phase Clavi	0	115	8	Regular
Harpsichord	Harpsichord 1	0	122	7	Natural!
	Harpsichord 2	8	32	113	S.Articulation!
	Grand Harpsichord	0	113	7	Live!
	Harpsichord Coupler	0	123	7	Natural!
	Harpsichord & Strings	0	124	7	Natural!

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Tonewheel Organ	Whiter Bars	8	32	30	S.Articulation!
	Curved Bars	0	121	17	Cool!
	All Bars Out	8	32	31	S.Articulation!
	Even Bars	0	111	17	Cool!
	Jazz Rotary	8	32	114	S.Articulation!
	Vintage Fast	0	127	17	Cool!
	Classic Bars	8	34	30	S.Articulation!
	Organ	0	118	19	Cool!
	Rock Rotary	8	33	114	S.Articulation!
	Organ-a-Gogo	104	0	17	Cool!
	Prog Rock Organ	8	33	30	S.Articulation!
	Organ Accomp 1	0	108	18	Regular

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Tonewheel Organ	R&B Tremolo	0	111	19	Cool!
	Organ Accomp 2	0	107	18	Regular
	Jazz Organ	0	117	17	Cool!
	Organ Accomp 3	0	106	18	Regular
	Hold It Fast	0	111	18	Cool!
	Organ Accomp 4	0	105	18	Regular
	Full Rocker	0	115	19	Cool!
	Organ Accomp 5	0	104	18	Regular
	Whiter Bars Slow	104	1	18	Cool!
	Whiter Bars Fast	104	0	18	Cool!
	Jazz Slow	0	126	18	Cool!
	Jazz Fast	0	127	18	Cool!
	All Bars Out Slow	104	1	19	Cool!
	All Bars Out Fast	104	0	19	Cool!
	All Bars Phase	104	2	19	Cool!
	Rotor Organ	0	117	19	Cool!
	Mellow Draw	0	115	18	Regular
	Two Channels	0	109	18	Cool!
	Euro Organ	0	118	17	Regular
	Classical Pipe	Pipe Organ Principal	0	123	20
Chapel Organ 1		0	113	20	Regular
Pipe Organ		0	112	20	Regular
Chapel Organ 2		0	114	20	Regular
Pipe Organ Tutti 2		0	122	20	Natural!
Chapel Organ 3		0	115	20	Regular
Theatre Pipe	Full Theatre	0	127	19	Regular
	Tibia 8	104	6	18	Regular
	Sweet Theatre	0	126	19	Regular
	Tibia 8&4	104	9	17	Regular
	Ballroom Organ	0	115	4	Regular
	Tibia 16&4	104	8	17	Regular
	Tibia Full	104	5	18	Regular
	Vox 8	104	7	18	Regular
	Vox & Tibia	104	10	17	Regular
	Trumpet 8	0	124	17	Regular
	Kinura 8	0	123	17	Regular
	Tp & Kinura	0	125	18	Regular
	Trumpet 16&8	0	124	18	Regular
	Organ Flutes	Organ Flutes	0	126	17
USD Smile		0	126	17	OrganFlutes
Reggae Bars		0	126	17	OrganFlutes
Warm Theatre		0	126	17	OrganFlutes
Organ Pops		0	126	17	OrganFlutes
Rock Organ		0	126	17	OrganFlutes
Soul Percussion		0	126	17	OrganFlutes
Gospel Truth		0	126	17	OrganFlutes
Pad Organ		0	126	17	OrganFlutes
Full Organ		0	126	17	OrganFlutes
String Bars		0	126	17	OrganFlutes
Latin Spin		0	126	17	OrganFlutes
Shady Bars		0	126	17	OrganFlutes
Funk Organ		0	126	17	OrganFlutes
Ballad Organ	0	126	17	OrganFlutes	
Rich Bars	0	126	17	OrganFlutes	
Trumpet Bars	0	126	17	OrganFlutes	
Soul Bars	0	126	17	OrganFlutes	
Clari Bars	0	126	17	OrganFlutes	
Jazz Squabble	0	126	17	OrganFlutes	
Harmonica	Harmonica	0	112	23	Sweet!
	Blues Harp	0	114	23	Regular
	Modern Harp	0	113	23	Regular
Accordion	Master Accord	0	118	22	Regular
	Full Register	104	2	22	Regular
	Cassotto	104	0	22	Regular
	Clari 8&4	104	1	22	Regular
	Jazz Accordion	0	120	22	Regular
	Cajun	104	3	22	Regular
	Tango Accordion	0	114	24	Regular
	Bandoneon	0	113	24	Regular
	French Musette	0	119	22	Regular
	Steirisch	0	117	22	Regular
	Master Bass	0	122	22	Regular

CVP-605

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Accordion	FullReg Bass	104	5	22	Regular
	Accordion Bass	0	121	22	Regular
	Cajun Bass	104	6	22	Regular
	Musette Bass	0	123	22	Regular
	Tango Bass	0	115	24	Regular

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Nylon Acoustic Gtr	Concert Guitar	8	32	1	S.Articulation!	
	Dynamic Nylon	0	116	25	Live!	
	Flamenco Guitar	8	33	1	S.Articulation!	
	Hard Flamenco	0	118	25	Live!	
	Nylon Guitar	8	34	1	S.Articulation!	
	Classical Guitar	0	115	25	Live!	
	Slide Nylon	0	117	25	Live!	
	Nylon Mute	0	119	25	Live!	
	Electro Acoustic	8	35	1	S.Articulation!	
	Steel Acoustic Gtr	Steel Guitar	8	32	2	S.Articulation!
Slide Steel		0	118	26	Live!	
Folk Guitar		8	33	2	S.Articulation!	
Dynamic Steel		0	116	26	Live!	
Steel Guitar		0	117	26	Live!	
Steel Mute		0	120	26	Live!	
12String Guitar		0	113	26	Live!	
Clean Solid		Single Coil Clean	8	39	4	S.Articulation!
	Warm Solid	8	33	4	S.Articulation!	
	Warm Electric	8	32	4	S.Articulation!	
	Clean Solid	8	34	4	S.Articulation!	
	Clean Electric	8	35	4	S.Articulation!	
	Electric Guitar	0	114	29	Cool!	
	Jazz Vintage	8	38	7	S.Articulation!	
	Jazz Artist	8	39	7	S.Articulation!	
	Jazz Clean	8	32	7	S.Articulation!	
	Semi Acoustic	8	33	7	S.Articulation!	
	Chorus Solid	0	107	28	Cool!	
	Slide Clean	0	117	29	Cool!	
	Muted Guitar	0	119	29	Cool!	
	Slide Solid	0	110	28	Cool!	
	Dynamic Mute	0	118	29	Cool!	
	Vintage Open	0	123	28	Regular	
	Vintage Muted Echo	0	115	29	Regular	
	Clean Guitar	0	112	28	Cool!	
	Smooth Jazz Guitar	8	35	7	S.Articulation!	
	Slide Jazz	104	0	27	Cool!	
	Slap Solid	0	108	28	Cool!	
	Funk Guitar	0	116	29	Cool!	
	Vintage Strum	0	126	28	Regular	
	Tremolo Solid	0	111	28	Cool!	
	Ballad Solid	0	109	28	Cool!	
	60s Clean	0	117	28	Regular	
	Jazz Guitar	0	115	27	Cool!	
	Jazz Solo Guitar	0	116	27	Cool!	
	Octave Guitar	0	113	27	Regular	
	Distortion Solid	Stage Lead	8	38	6	S.Articulation!
		Bluesy Night	8	55	4	S.Articulation!
		Overdrive Wah	8	39	6	S.Articulation!
		Grunge Guitar	8	40	6	S.Articulation!
		Vintage Spring	8	54	4	S.Articulation!
		Pure Vintage	8	42	6	S.Articulation!
		Lite Chorus	8	53	4	S.Articulation!
		Classic Stack	8	41	6	S.Articulation!
		Heavy Rock	8	32	5	S.Articulation!
		Crunch Guitar	8	33	6	S.Articulation!
		Rock Legend	8	34	6	S.Articulation!
Guitar Hero		8	32	6	S.Articulation!	
Half Drive		8	37	4	S.Articulation!	
70s Solid Guitar		8	38	4	S.Articulation!	
Metal Master		0	120	31	Regular	
Feedbacker		8	33	5	S.Articulation!	
Blues Guitar		0	117	30	Cool!	

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
World	Distortion Solid	8	40	4	S.Articulation!	
	Pedal Steel Amp	8	52	4	S.Articulation!	
	Mandolin	0	114	26	Sweet!	
	Pedal Steel	8	36	4	S.Articulation!	
	Zither 1	104	1	16	Regular	
	Banjo	104	0	106	Regular	
	Zither 2	104	0	16	Regular	
	Shamisen	0	112	107	Regular	
	Dulcimer	0	112	16	Regular	
	Koto	0	112	108	Regular	
	Hackbrett	104	2	47	Regular	
	Aloha Guitar	0	118	27	Regular	
	Sitar	104	0	105	Regular	
	Pedal Steel	0	115	28	Regular	
	Bass	Vintage Round	104	1	34	Cool!
		Acoustic Bass	0	112	33	Regular
		Vintage Flat	104	2	34	Cool!
Bass & Cymbal		0	114	33	Regular	
Vintage Mute		104	3	34	Cool!	
Fusion Bass		0	113	37	Regular	
Vintage Pick		104	1	35	Regular	
Vintage Dyno		104	2	35	Cool!	
Fretless Bass		0	112	36	Cool!	
Slap Bass		0	112	37	Regular	
Rock Bass		0	114	35	Regular	
Mellow Finger		0	112	34	Regular	
Pick Bass		0	112	35	Regular	
Dyno Pick Bass		0	113	35	Cool!	
Electric Bass		0	114	34	Cool!	
Half Mute		0	115	34	Cool!	
Super Fretless		0	113	36	Regular	
Vintage Pick Mute		104	0	35	Cool!	
Funk Bass		0	112	38	Regular	
Synth Bass		Lo Bass	104	0	40	Regular
		Fat Pulse	104	2	40	Regular
		Dark Bass	104	1	40	Regular
		Wazzo Saw	104	3	81	Regular
	Moon Bass	104	0	39	Regular	
	Deep Point	104	3	39	Regular	
	Kick Bass	104	1	39	Regular	
	Tight Bass	104	3	40	Regular	
	Club Bass	104	2	39	Regular	
	Competitor	104	4	39	Regular	
	To1 Sub	104	5	39	Regular	
	Trance Bass	104	9	39	Regular	
	Little Bass Synth	104	6	39	Regular	
	Sub Cut Bass	104	5	40	Regular	
	Tekno Bass	104	7	39	Regular	
	Dyno Acid Bass	104	10	39	Regular	
	Perc Punch	104	8	39	Regular	
	Mini Sub	104	6	40	Regular	
	Square Bass	104	4	40	Regular	
	Fat Sine Res	104	11	39	Regular	
	Ballad Bass	104	7	40	Regular	
	House Bass	0	116	39	Regular	
	Velo Master	104	17	82	Regular	
Big Drone	0	118	39	Regular		
Sub Bass	0	114	40	Regular		
Hard Bass	0	114	39	Regular		
Reso Bass	0	112	39	Regular		
TB Bass	0	117	40	Regular		

CVP-605

Main Category: STRINGS&VOCAL

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
String Solo	Violin	0	113	41	Sweet!
	Solo Violin	0	112	41	Regular
	Viola	0	112	42	Regular
	Fiddle	0	112	111	Regular
	Cello	0	112	43	Regular
Contrabass	0	112	44	Regular	
String Ensemble	Concert Strings	8	32	50	S.Articulation!
	Movie Strings	0	123	49	Live!
	Studio Strings	8	32	49	S.Articulation!
	Dynamic Strings	0	124	49	Live!
	Strings	0	117	50	Live!
	Pizzicato	0	113	46	Live!
	Allegro	0	122	50	Live!
	Tremolo Strings	0	113	45	Live!
	Chamber Strings	0	112	50	Regular
	Spiccato	8	33	49	S.Articulation!
	Disco Strings 1	0	123	50	Live!
	Disco Strings 2	0	124	50	Live!
	Strings f	0	119	49	Live!
	Tremolo Bowing	8	34	49	S.Articulation!
	Strings mf	0	118	49	Live!
	Spiccato	0	120	49	Live!
	Strings p	0	117	49	Live!
	Orchestral Layers	Tutti	0	120	50
Theatre Orchestra		104	1	50	Regular
Symphonic Unison		104	0	50	Regular
Choir	Gothic Vox	0	113	54	Regular
	Gospel Voices	0	116	53	Live!
	Humming	0	118	53	Live!
	Hah Choir	0	114	53	Regular
	Mmh	0	117	53	Live!

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Brass Solo	Trumpet	8	32	65	S.Articulation!	
	Cornet	0	119	57	Sweet!	
	Silver Trumpet	8	33	65	S.Articulation!	
	Flugel Horn	0	118	57	Sweet!	
	Golden Trumpet	8	34	65	S.Articulation!	
	Muted Trumpet	0	114	60	Sweet!	
	Big Band Trumpet	8	37	65	S.Articulation!	
	Mellow Trumpet	0	120	57	Sweet!	
	Trumpet Fall	8	38	65	S.Articulation!	
	Trombone	0	117	58	Sweet!	
	Trumpet	0	115	57	Sweet!	
	Baritone Horn	0	113	59	Regular	
	Trumpet Shake	8	35	65	S.Articulation!	
	Tuba	104	0	59	Regular	
	Silver Trumpet	0	121	57	Sweet!	
	Baritone Hit	0	114	59	Regular	
	Golden Trumpet	0	122	57	Sweet!	
	Alp Bass	0	113	34	Regular	
	Brass Ensemble	French Horns	0	112	61	Live!
		Big Band Brass	8	37	57	S.Articulation!
Symphony Brass		0	119	61	Live!	
Smooth Brass		8	36	57	S.Articulation!	
Symphony Horns		0	115	61	Live!	
Dynamic Brass		0	127	62	Live!	
Pop Brass		0	117	63	Live!	
Power Brass		0	121	63	Live!	
Hyper Brass		0	118	63	Live!	
Accent Brass		0	109	62	Live!	
Sforzando		0	105	62	Live!	
Brass Falls f		8	34	57	S.Articulation!	
Sforzando Fall		0	107	62	Live!	
Brass Falls mf		8	35	57	S.Articulation!	
Brass f		0	108	62	Live!	
Brass Shake		8	32	57	S.Articulation!	
Brass mf		0	110	62	Live!	
Accent Falls		8	38	57	S.Articulation!	

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Brass Ensemble	Brass p	0	111	62	Live!
	Octave Brass	0	116	63	Live!
	Brass Band	0	123	57	Live!
	Small Brass	0	120	61	Live!
	Soft Horns	0	117	61	Live!
	Soft Trombones	0	118	61	Live!
	Brass Dynamics	0	106	62	Live!
	Ballroom Brass	0	113	60	Regular
	Saxophone	8	32	83	S.Articulation!
	Sax Solo	Soprano Sax	0	113	65
Big Band Sax		8	35	83	S.Articulation!
Alto Sax		0	114	66	Sweet!
Jazz Tenor		0	125	67	Sweet!
Tenor Sax		0	117	67	Sweet!
Rock Sax		8	33	83	S.Articulation!
Pop Tenor		0	127	67	Sweet!
Growl Sax		0	111	67	Sweet!
Ballad Tenor		0	126	67	Sweet!
Baritone Sax		0	112	68	Regular
Sax Ensemble	Sax Section	0	116	67	Live!
	Sax Section Hard	0	122	67	Live!
	Big Band Saxes	0	110	67	Live!
	Sax Section Soft	0	121	67	Live!
	Big Band Unison	0	109	67	Live!
	Sax Appeal	0	123	67	Live!
	Big Band Octave	0	108	67	Live!
	Moonlight	0	115	72	Regular
	Ballad Section	0	119	67	Regular
	Orch Flute	104	0	74	Sweet!
Woodwind Solo	Flute	0	114	74	Sweet!
	Orch Oboe	104	0	69	Sweet!
	Oboe	0	113	69	Sweet!
	Orch Clarinet	104	0	72	Live!
	Clarinet	0	114	72	Sweet!
	German Clarinet	104	2	72	Regular
	Classical Flute	0	115	74	Sweet!
	Orch Bassoon	104	0	71	Sweet!
	Piccolo	0	112	73	Regular
	Flute	0	112	74	Regular
Woodwind Ens	Oboe	0	112	69	Regular
	Clarinet	0	112	72	Regular
	English Horn	0	112	70	Regular
	Bassoon	0	112	71	Regular
	Flutes & Oboes	104	2	74	Regular
	Orch Woodwind	104	1	71	Regular
	Clarinet & Flutes	104	1	72	Regular
	Alto Flutes	104	1	74	Regular
	Clarinet & Oboe	104	1	69	Regular
	Flute Ensemble	0	116	74	Regular
Woodwind World	Oboe & Bassoon	104	2	69	Regular
	Pan Flute	0	113	76	Sweet!
	Pan Flute	0	113	74	Regular
	Celtic Duo	0	120	74	Regular
	Ethnic Flute	0	112	76	Regular
	Bagpipe	0	112	110	Regular
	Ocarina	0	112	80	Regular
	Recorder	0	112	75	Regular
	Shakuhachi	0	112	78	Regular
	Whistle	0	112	79	Regular

Main Category: PERC&DRUMS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Chromatic Perc	Jazz Vibes	0	113	12	Regular
	Xylophone	0	112	14	Regular
	Vibraphone	0	122	12	Natural!
	Marimba	0	112	13	Regular
	Tremolo Vibes	0	124	12	Natural!
	Glockenspiel	0	112	10	Regular
	Vibes & JazzGtr	8	33	12	S.Articulation!
	Steel Drums	0	112	115	Regular

CVP-605

Main Category: PERC&DRUMS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Chromatic Perc	Vibes & Flutes	0	114	12	Regular	
	Music Box	0	112	11	Regular	
	Kalimba	0	112	109	Regular	
Orchestral Perc	Celesta	0	112	9	Regular	
	Tubular Bells	0	112	15	Regular	
	Orchestral Harp	104	1	47	Regular	
	Mellow Harp	104	0	47	Regular	
	Timpani	0	112	48	Regular	
	Orchestra Hit	0	112	56	Regular	
Drum Kits	Real Drums	127	0	92	Drums	
	Studio Kit	127	0	87	Drums	
	Acoustic Kit	127	0	90	Drums	
	Hit Kit	127	0	5	Drums	
	Rock Kit	127	0	91	Drums	
	Room Kit	127	0	9	Drums	
	Power Kit 1	127	0	88	Drums	
	Jazz Kit	127	0	33	Drums	
	Power Kit 2	127	0	89	Drums	
	Brush Kit	127	0	41	Drums	
	Dance Kit	127	0	28	Drums	
	Analog T8 Kit	127	0	59	Drums	
	Analog Kit	127	0	26	Drums	
	Analog T9 Kit	127	0	60	Drums	
	Electro Kit	127	0	25	Drums	
	Break Kit	127	0	58	Drums	
	Symphony Kit	127	0	49	Drums	
	Hip Hop Kit	127	0	57	Drums	
	World Perc Kits	Pop Latin Kit	126	0	44	SFX Kit
		Cuban Kit	126	0	41	SFX Kit
Turkish Kit		126	0	68	SFX Kit	
SFX	SFX Kit 1	126	0	1	SFX Kit	
	SFX Kit 2	126	0	2	SFX Kit	
	Noises Kit	126	0	9	SFX Kit	
	Magic Bell	8	32	121	S.Articulation!	

Main Category: SYNTN

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Synth Lead	Sub Lead	104	0	81	Regular	
	Wire Lead	0	120	82	Regular	
	Soft Saw	104	16	82	Regular	
	Soft R&B	0	119	81	Regular	
	Fusion Lead	104	15	82	Regular	
	Early Lead	0	118	82	Regular	
	Oxygen	0	122	82	Regular	
	Soft Square	104	5	81	Regular	
	Matrix	0	123	82	Regular	
	Detuned Vintage	104	1	85	Regular	
	PWM Lead	104	1	82	Regular	
	Hipa Lead	0	118	85	Regular	
	Brassy Lead	104	5	63	Regular	
	Punchy Hook	0	127	82	Regular	
	Punch Lead	104	7	82	Regular	
	Crying Lead	0	114	88	Regular	
	Flange Filter	104	2	82	Regular	
	Hip Lead	0	113	81	Regular	
	Mouth Lead	104	0	82	Regular	
	Hop Lead	0	117	81	Regular	
	Tech Lead	0	117	85	Regular	
	Analogon	0	115	82	Regular	
	Tekline	0	116	85	Regular	
	Skyline	0	115	85	Regular	
	Soft Mini	0	124	81	Regular	
	Bleep Lead	104	0	85	Regular	
	Fire Wire	0	116	82	Regular	
	Orbit Sine	0	126	81	Regular	
	Synth Perc	Nylon Pad	104	0	100	Regular
		Simple Comp	104	12	82	Regular
		Bellsphere	104	5	89	Regular
		Ballad Comp	104	6	89	Regular
		Perc Pad	104	0	102	Regular

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Synth Perc	Heaven Bell	104	0	101	Regular	
	Mediterran	0	114	100	Regular	
	Bright Pad Bell	104	7	89	Regular	
	Lektro Codes	104	2	85	Regular	
	Wild PWM	104	4	81	Regular	
	Resonant Clavi	104	2	91	Regular	
	Perc Seq FM 1	104	7	88	Regular	
	Resonance Comp	104	4	63	Regular	
	Perc Seq FM 2	104	8	88	Regular	
	Digital Seq	104	2	88	Regular	
	Synth Sticks	104	0	107	Regular	
	Analog Seq	104	3	88	Regular	
	Saz Feeze	104	0	98	Regular	
	Perc Seq FS	104	6	88	Regular	
	Eastern Air	104	1	98	Regular	
	Xtune	104	1	88	Regular	
	Nomad	104	1	105	Regular	
	Perc Seq Saw	104	11	82	Regular	
	Stack Bell	104	8	89	Regular	
	Attack	104	4	82	Regular	
	Nice Bell	104	9	89	Regular	
	PWM Percussion	104	6	82	Regular	
	Synth Strings	Synth Strings 1	0	112	51	Regular
		Butter Strings	104	2	51	Regular
		Synth Strings 2	0	113	51	Regular
		Bright Saw Pad	0	113	91	Regular
		Light Pad	104	2	52	Regular
		Ober Strings	0	113	52	Regular
		Hipa Strings	0	114	96	Regular
		80s Pad	104	1	52	Regular
		Oct Strings	104	4	51	Regular
		Bright Pop Pad	104	3	51	Regular
		Medium Tune Pad	104	0	51	Regular
Doux Flange		104	3	96	Regular	
Premium Pad		104	0	52	Regular	
Bright Pad Classic		104	3	91	Regular	
Soft Ensemble		104	1	51	Regular	
Synth Brass		Analow Brass	0	112	64	Regular
		Slow PWM Brass	104	2	63	Regular
		Fat Synth Brass	0	116	64	Regular
		80s Brass	0	113	63	Regular
		Thinth Brass	104	0	63	Regular
	Funky Analog	0	115	63	Regular	
	Brass Profit	104	1	63	Regular	
	Techno Brass	0	114	63	Regular	
	Ober Brass	0	113	64	Regular	
	Ober Horns	0	115	64	Regular	
	Soft Analog	0	114	64	Regular	
	Soft Velo Brass	0	120	63	Regular	
	Fast PWM Brass	104	6	63	Regular	
	Synth Pad	Skydiver	0	112	102	Regular
		Aerosphere	104	1	95	Regular
Cross Phase		104	1	102	Regular	
New Atmosphere		104	4	90	Regular	
Galaxy Pad		104	3	89	Regular	
VP Soft		104	0	90	Regular	
Night Motion		104	4	89	Regular	
Hot Swell		104	2	96	Regular	
Morning Dew		104	0	95	Regular	
Dark Fat Saw		104	2	90	Regular	
Vapor Pad		104	1	90	Regular	
Dark Light		104	3	90	Regular	
Space Rider		104	1	96	Regular	
Ambient Pad		104	0	89	Regular	
Pearls Pad		104	2	89	Regular	
Bright Fat Saw		104	5	91	Regular	
Breath Pad		104	0	92	Regular	
Early Digital		104	0	94	Regular	
Noble Man		104	1	89	Regular	
Super Dark Pad		0	119	90	Regular	
Analog Pad		0	120	90	Regular	
Analog Swell		0	119	96	Regular	

CVP-605

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Pad	Dark Angel Pad	0	121	90	Regular
	Big Octave Pad	0	115	91	Regular
	Lite Pad	0	122	90	Regular
	Golden Age	0	115	89	Regular
	Pop Pad	0	112	91	Regular
	Solaris	0	114	95	Regular
	Glorious Phase	0	114	91	Regular
	Insomnia	0	113	95	Regular
	Ober Sweep	0	115	96	Regular
	Neo Warm Pad	0	115	90	Regular
	Time Travel	0	116	89	Regular
	Cyber Pad	0	113	100	Regular
	Bubblespace	0	113	102	Regular
	Bright Ober	0	113	96	Regular
Mellow Pad	0	117	96	Regular	
Dark Pad	0	118	96	Regular	
Synth Dance	Ana Dayz	104	3	52	Regular
	HPF Dance	104	0	91	Regular
	Bright Pad Trance	104	4	91	Regular
	Detuned Saw Oct	104	8	82	Regular
	Chillin Chords	104	6	52	Regular
	Dancy Hook	104	9	82	Regular
	Trance MW	104	0	96	Regular
	Vinalog Saw	104	3	82	Regular
	Club Lead	104	3	63	Regular
	Talk Mod Lead	104	0	88	Regular
	Trance Perc	104	5	82	Regular
	Chorus Saw Lead	104	10	82	Regular
	Chordmaster	104	13	82	Regular
	Faaat Comp	104	4	52	Regular
	Trance Seq 1	104	4	88	Regular
	Fat Saw Hook	104	7	52	Regular
	Trance Seq 2	104	5	88	Regular
	Tech Glide	104	14	82	Regular
	Trance Seq 3	104	1	91	Regular
	Dance Chords	104	5	52	Regular
	Dance Hook	0	112	87	Regular
	Trance Lead	0	121	81	Regular
	Octave Hook	0	113	87	Regular
	Synth Effects	Sixth Sense	104	2	102
Perc Seq Hipa		104	9	88	Regular
Pitch Fall		104	0	104	Regular

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
Legacy	Organ	Full Rocker 2	104	3	19	Cool!
		Rotary Drive	0	116	19	Regular
		Rotary Switch	0	110	18	Cool!
		Gospel Organ	0	119	17	Regular
		Purple Organ	0	114	19	Regular
		60s Organ	0	116	18	Regular
		Perc Organ	0	119	18	Regular
		Drawbar Organ 1	0	120	18	Regular
		Drawbar Organ 2	0	115	17	Regular
		Rock Organ 1	0	112	19	Regular
		Jazz Organ 1	0	112	17	Regular
		Rock Organ 2	0	119	19	Regular
		Jazz Organ 2	0	113	17	Regular
		Rock Organ 3	0	113	19	Regular
		Jazz Organ 3	0	120	17	Regular
		Bright Draw	0	116	17	Regular
		Electric Organ	0	118	18	Regular
		Tibia 8&4 Acmp	0	122	17	Regular
		Tibia 16&4 Acmp	0	114	17	Regular
		Tibia Full Acmp	0	114	18	Regular
		Tibia 8 Acmp	0	122	18	Regular
		Vox 8 Acmp	0	123	18	Regular
		Vox & Tibia Acmp	0	125	17	Regular
		Strings	Strings	0	112	49
	Slow Strings		0	113	50	Regular
	Orch Strings		0	113	49	Regular
	Symphonic		0	114	49	Regular
	Tremolo Strings		0	112	45	Regular
	Bow Strings		0	116	49	Regular
	Marcato		0	115	50	Regular
	Pizzicato		0	112	46	Regular
	String Falls		0	121	49	Live!
	Analog Strings		0	112	52	Regular
	Orchestra		0	116	50	Live!
	Concerto Strings		0	115	49	Regular
	Orch & Flute		0	119	50	Regular
	Orch & Oboe		0	121	50	Regular
	String Quartet	0	114	50	Regular	
Orch & Horns	0	118	50	Regular		
Choir	Harp	0	112	47	Regular	
	Hackbrett 2	0	113	47	Regular	
	Banjo 2	0	112	106	Regular	
	Sitar 2	0	112	105	Regular	
	Voices	0	113	55	Regular	
	Choir	0	112	53	Regular	
	Air Choir	0	112	55	Regular	
	Vox Humana	0	112	54	Regular	
	Sweet Heaven	0	118	89	Regular	
	Dream Heaven	0	121	89	Regular	
	Bell Heaven	0	119	89	Regular	
	Pan Heaven	0	120	89	Regular	
	Pro Heaven	0	122	89	Regular	
	Sunbeam	0	123	89	Regular	
Uuh Choir	0	115	53	Regular		
Hah Pad	0	116	95	Regular		
Brass	Brass Section	0	112	62	Regular	
	Brass Combo	0	115	67	Regular	
	Natural Brass	0	124	62	Regular	
	Bright Brass	0	120	62	Regular	
	Big Band Brass	0	113	62	Regular	
	Mellow Brass	0	116	62	Regular	
	Big Brass	0	121	62	Regular	
	Small Brass	0	117	62	Regular	
	Sforzando	0	125	62	Regular	
	Soft Brass	0	123	62	Regular	
	High Brass	0	115	62	Regular	
	Breath Brass	0	116	61	Regular	
	Pop Brass	0	118	62	Regular	
	Full Horns	0	114	62	Regular	
Mellow Horns	0	119	62	Regular		
Trumpet Ens	0	122	62	Regular		
Tb Section	0	113	58	Regular		

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Piano	Grand Piano	0	113	1	Live!	
		Warm Grand	0	114	1	Live!	
		Bright Piano	0	112	2	Live!	
		Ballad Stack	0	114	3	Regular	
		Honky Tonk	0	122	4	Natural!	
		Honky Tonk	0	112	4	Regular	
		Octave Piano 1	0	113	4	Live!	
		Octave Piano 2	0	114	4	Live!	
		MIDI Grand	0	112	3	Regular	
		Harpichord	0	112	7	Live!	
		E.Piano	Jazz Chorus	0	118	6	Regular
			Hyper Tines	0	113	6	Regular
			Venus EP	0	114	6	Regular
			Polaris EP	0	115	5	Regular
	Super DX		0	117	6	Regular	
	DX Modern		0	112	6	Regular	
	Phase EP		0	120	5	Regular	
	Modern EP		0	115	6	Regular	
	Funk EP		0	112	5	Regular	
	New Tines		0	116	6	Regular	
	Chorus Bell		0	120	6	Regular	
	Stereo Clavi		0	114	8	Regular	
	Organ		Dance Organ	0	113	18	Regular
			Click Organ	0	112	18	Regular
		Reed Organ	0	112	21	Regular	

CVP-605

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
Legacy	Brass	Smooth Trombone	0	118	58	Regular
		Hybrid Comp	0	119	63	Regular
		Hybrihorn	0	113	61	Regular
		Synth Brass	0	112	63	Regular
		Hybripad	0	114	61	Regular
		Brass Hit	0	126	62	Regular
	Trumpet	Solo Trumpet	0	112	57	Regular
		Jazz Trumpet	0	116	57	Regular
		Muted Trumpet	0	112	60	Regular
		Flugel Horn	0	113	57	Regular
Solo Trombone		0	112	58	Regular	
Trombone		0	116	58	Regular	
Soft Trombone		0	115	58	Regular	
Mellow Trombone		0	114	58	Regular	
Tuba 2		0	112	59	Regular	
Saxophone		Soprano Sax	0	112	65	Regular
	Alto Sax	0	112	66	Regular	
	Saxophone	104	0	67	Sweet!	
	Tenor Sax	0	112	67	Regular	
	Growl Sax	0	118	67	Regular	
	Sax Stack	0	124	67	Regular	
	Saxy Mood	0	120	67	Regular	
Flute&Clarinet	Woodwinds Ens	0	113	67	Regular	
Guitar	Vintage Amp	0	115	30	Regular	
	70s Solid Guitar	104	1	28	Cool!	
	Warm Solid	104	2	28	Cool!	
	Clean Solid	104	3	28	Cool!	
	Muted Guitar	0	112	29	Regular	
	Funk Guitar	0	113	29	Regular	
	Solid Chord	0	121	28	Regular	
	Solid Guitar	0	118	28	Regular	
	Tremolo Guitar	0	113	28	Regular	
	Wah Guitar	0	122	28	Regular	
	Slapback	104	0	28	Cool!	
	Chorus Guitar	0	124	28	Regular	
	Vintage Trem	0	120	28	Regular	
	Deep Chorus	0	114	28	Regular	
	Bright Clean	0	116	28	Regular	
	Electric 12Str	0	119	28	Regular	
	Vintage Lead	0	125	28	Cool!	
	Crunch Guitar	0	113	31	Regular	
	Heavy Stack	0	114	31	Regular	
	Power Chord	0	117	31	Regular	
	Half Drive	104	0	30	Cool!	
	Guitar Hero	104	0	31	Cool!	
	Heavy Rock	104	1	31	Cool!	
	Smooth Lead	0	119	27	Regular	
	Power Lead	0	115	31	Cool!	
	Rock Guitar	0	116	30	Regular	
	Voodoo Lead	0	116	31	Regular	
	Lead Guitar	0	114	30	Regular	
	Distortion Guitar	0	112	31	Regular	
	Overdrive Guitar	0	112	30	Regular	
	Feedback Guitar	0	113	30	Regular	
	DX Jazz Guitar	0	117	27	Regular	
	Folk Guitar	0	112	26	Regular	
	Campfire Guitar	0	115	26	Regular	
	18String	0	119	26	Regular	
	Bass	Click Bass	0	115	39	Regular
		Punchy Bass	0	117	39	Regular
		Analog Bass	0	112	40	Regular
		DX Funk Bass	0	113	38	Regular
		Dry Synth Bass	0	116	40	Regular
	Perc&Drum	80s Synth Bass	0	115	40	Regular
		HiQ Bass	0	113	39	Regular
		Standard Kit 1	127	0	1	Drums
		Standard Kit 2	127	0	2	Drums
		Rock Kit	127	0	17	Drums
	Accordion	Arabic Kit	126	0	36	SFX Kit
		Vibraphone	0	112	12	Regular
		Accordion	0	116	22	Regular
		Small Accordion	0	115	22	Regular

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Accordion	Ballroom Acc	0	112	24	Regular	
		Soft Accordion	0	114	22	Regular	
		Tutti Accordion	0	113	22	Regular	
		Musette	0	112	22	Regular	
		Pad	Psycho Pad	0	118	102	Regular
	Pad	Far East	0	112	98	Regular	
		Disclosure	0	116	90	Regular	
		Mystery	0	113	98	Regular	
		Sirius	0	114	102	Regular	
		S&H Groove	0	115	102	Regular	
		Velo Ashrami	0	116	102	Regular	
		Evening Stars	0	117	102	Regular	
		Angel Vibes	0	114	99	Regular	
		Glass Pad	0	114	94	Regular	
		DX Pad	0	112	93	Regular	
		Symbiont	0	113	89	Regular	
		Dark Moon	0	113	90	Regular	
		Ionosphere	0	115	95	Regular	
		Millennium	0	117	89	Regular	
		Atmosphere	0	112	100	Regular	
		Equinox	0	112	95	Regular	
		Fantasia	0	112	89	Regular	
		Stargate	0	114	89	Regular	
		Area 51	0	112	90	Regular	
		Digital Pad	0	115	94	Regular	
		Dunes	0	114	90	Regular	
		Messenger	0	116	96	Regular	
		Wave 2001	0	112	96	Regular	
		Xenon Pad	0	112	92	Regular	
		Synth	Pro Lead	0	113	84	Regular
			Funky Lead	0	121	82	Regular
			Portatone	0	112	85	Regular
			Adrenaline	0	113	85	Regular
			Stardust	0	112	99	Regular
			Aero Lead	0	112	84	Regular
			Mini Lead	0	114	81	Regular
			Sun Bell	0	113	99	Regular
			Hi Bias	0	116	81	Regular
			Vinyl Lead	0	115	81	Regular
			Pan Lead	0	122	81	Regular
			String Bells	0	124	89	Regular
			Padbells	0	126	89	Regular
			Big Tune	0	118	90	Regular
			Trumpet Saw	0	125	82	Regular
			Paraglide	0	114	85	Regular
			Robolead	0	124	82	Regular
			Fargo	0	119	82	Regular
			Big Lead	0	113	82	Regular
			Warp	0	117	82	Regular
			Impact	0	113	88	Regular
Under Heim	0		112	88	Regular		
Crystal Eyes	0		125	89	Regular		
Melody Maker	0		117	90	Regular		
Attack Saw	0		126	82	Regular		
Perc Square	0		123	81	Regular		
Square Lead	0		112	81	Regular		
Saw Lead	0		112	82	Regular		
Pop Lead	0		120	81	Regular		
Bright Mini	0		125	81	Regular		
Blaster	0		114	82	Regular		
Tiny Lead	0		118	81	Regular		
StyleVoices	Piano		Concert Grand [Sty]	0	122	1	Natural!
			Grand Piano [Sty]	0	122	2	Natural!
			Bright Piano [Sty]	0	123	1	Natural!
			Mellow Piano [Sty]	0	124	1	Natural!
			Rock Piano [Sty]	0	124	3	Natural!
			Studio Grand [Sty]	0	115	1	Live!
			Pop Grand 1 [Sty]	104	6	1	Natural!
			Pop Grand 2 [Sty]	104	5	1	Live!
			Rock Piano [Sty]	104	4	1	Live!
			Ambient Piano [Sty]	104	3	1	Live!
Upright Piano [Sty]	104		13	1	Natural!		

CVP-605

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
StyleVoices	Piano	Pop Upright [Sty]	104	13	2	Natural!	
		70s Ballad Piano [Sty]	104	14	1	Natural!	
		Chill Out Piano [Sty]	104	15	1	Natural!	
		Honky Tonk Upright [Sty]	104	13	4	Natural!	
		Saloon Upright [Sty]	104	14	2	Natural!	
		Upright 1octave [Sty]	104	14	4	Natural!	
		Upright 2octave [Sty]	104	15	4	Natural!	
		Grand Piano 1octave [Sty]	0	123	4	Natural!	
		Grand Piano 2octave [Sty]	0	124	4	Natural!	
		Ballad Grand 1 [Sty]	104	4	5	Natural!	
		Ballad Grand 2 [Sty]	104	5	5	Natural!	
		Grand Pad Layer [Sty]	104	5	3	Natural!	
		Cocktail Piano [Sty]	104	0	4	Live!	
		MIDI GrandPad [Sty]	104	1	3	Live!	
		MIDI GrandSyn [Sty]	104	1	1	Live!	
		MIDI Grand [Sty]	104	0	3	Live!	
		Piano & EP [Sty]	0	122	3	Natural!	
		Piano Orchestra [Sty]	104	2	1	Live!	
		Piano & Strings [Sty]	0	125	1	Natural!	
		Suitcase EP [Sty]	0	118	5	Cool!	
		Vintage EP [Sty]	0	116	5	Regular	
		Electric Piano 1 [Sty]	0	119	5	Cool!	
		Electric Piano 2 [Sty]	0	122	5	Natural!	
		Stage EP [Sty]	0	117	5	Regular	
		Funky EP [Sty]	0	123	5	Natural!	
		Tremolo Suitcase EP [Sty]	0	113	5	Cool!	
		Tremolo Stage EP [Sty]	0	124	5	Natural!	
		Smooth Tine [Sty]	0	119	6	Regular	
		CP80 Stage [Sty]	0	113	3	Regular	
		Guitar&Bass	Single Coil [Mega]	8	3	4	MegaVoice
			Jazz Guitar [Mega]	8	0	7	MegaVoice
			Nylon Guitar [Mega]	8	0	1	MegaVoice
			Steel Guitar [Mega]	8	0	2	MegaVoice
	12String Guitar [Mega]		8	1	3	MegaVoice	
	Hi String Guitar [Mega]		8	0	3	MegaVoice	
	Solid Guitar 1 [Mega]		8	1	4	MegaVoice	
	Solid Guitar 2 [Mega]		8	2	4	MegaVoice	
	Clean Guitar [Mega]		8	0	4	MegaVoice	
	Overdrive Guitar [Mega]		8	0	5	MegaVoice	
	Distortion Guitar [Mega]		8	0	6	MegaVoice	
	Vintage Round [Mega]		8	1	18	MegaVoice	
	Vintage Flat [Mega]		8	2	18	MegaVoice	
	Vintage Pick [Mega]		8	1	19	MegaVoice	
	Acoustic Bass [Mega]		8	0	17	MegaVoice	
	Strings&Vocal	Electric Bass [Mega]	8	0	18	MegaVoice	
Pick Bass [Mega]		8	0	19	MegaVoice		
Fretless Bass [Mega]		8	0	20	MegaVoice		
Large Strings [Mega]		8	0	50	MegaVoice		
Small Strings [Mega]	8	0	49	MegaVoice			
Brass&Woodwind	Trumpet [Mega]	8	0	65	MegaVoice		
	Brass [Mega]	8	0	57	MegaVoice		
	Tenor Sax [Mega]	8	0	83	MegaVoice		

CVP-609/605

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Piano	GrandPiano	0	0	1	Regular	
		GrndPianoKSP	0	1	1	Regular	
		MellowGrPno	0	18	1	Regular	
		PianoStrings	0	40	1	Regular	
		Dream	0	41	1	Regular	
		BrightPiano	0	0	2	Regular	
		BritePnoKSP	0	1	2	Regular	
		ElecGrandPno	0	0	3	Regular	
		ElecGrPnoKSP	0	1	3	Regular	
		DetunedCP80	0	32	3	Regular	
		LayeredCP1	0	40	3	Regular	
		LayeredCP2	0	41	3	Regular	
		Honkytonk	0	0	4	Regular	
		HonkytonkKSP	0	1	4	Regular	
		EI.Piano1	0	0	5	Regular	
		EI.Piano1KSP	0	1	5	Regular	
		MellowEP1	0	18	5	Regular	
		ChorusEP1	0	32	5	Regular	
		HardEI.Piano	0	40	5	Regular	
		VXfadeEI.P1	0	45	5	Regular	
		60sEI.Piano1	0	64	5	Regular	
		EI.Piano2	0	0	6	Regular	
		EI.Piano2KSP	0	1	6	Regular	
		ChorusEP2	0	32	6	Regular	
		DXEPHard	0	33	6	Regular	
		DXLegend	0	34	6	Regular	
		DXPhaseEP	0	40	6	Regular	
		DX+AnalogEP	0	41	6	Regular	
		DXKotoEP	0	42	6	Regular	
		VXfadeEI.P2	0	45	6	Regular	
		Harpsichord	0	0	7	Regular	
		Harpsi.KSP	0	1	7	Regular	
		Harpsichord2	0	25	7	Regular	
		Harpsichord3	0	35	7	Regular	
		Clavi.	0	0	8	Regular	
		Clavi.KSP	0	1	8	Regular	
		Clavi.Wah	0	27	8	Regular	
		PulseClavi.	0	64	8	Regular	
		PierceClavi.	0	65	8	Regular	
		Chromatic Perc	Celesta	0	0	9	Regular
			Glockenspiel	0	0	10	Regular
			MusicBox	0	0	11	Regular
			Orgel	0	64	11	Regular
			Vibraphone	0	0	12	Regular
			VibesKSP	0	1	12	Regular
			HardVibes	0	45	12	Regular
			Marimba	0	0	13	Regular
			MarimbaKSP	0	1	13	Regular
			SineMarimba	0	64	13	Regular
			Balimba	0	97	13	Regular
			LogDrums	0	98	13	Regular
			Xylophone	0	0	14	Regular
			TubularBells	0	0	15	Regular
			ChurchBells	0	96	15	Regular
			Carillon	0	97	15	Regular
			Dulcimer	0	0	16	Regular
	Dulcimer2		0	35	16	Regular	
	Cimbalom		0	96	16	Regular	
	Santur		0	97	16	Regular	
	Organ		DrawbarOrgan	0	0	17	Regular
			DelDrawOrgan	0	32	17	Regular
			60sDrawOrg1	0	33	17	Regular
			60sDrawOrg2	0	34	17	Regular
		70sDrawOrg1	0	35	17	Regular	
		DrawbarOrg2	0	36	17	Regular	
		60sDrawOrg3	0	37	17	Regular	
		EvenBarOrg	0	38	17	Regular	
		16+2'2_3Org	0	40	17	Regular	
		OrganBass	0	64	17	Regular	
		70sDrawOrg2	0	65	17	Regular	
		CheezyOrgan	0	66	17	Regular	
		DrawbarOrg3	0	67	17	Regular	

CVP-609/605

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Organ	Perc.Organ	0	0	18	Regular	
		70sPercOrg1	0	24	18	Regular	
		DetPercOrgan	0	32	18	Regular	
		LightOrgan	0	33	18	Regular	
		Perc.Organ2	0	37	18	Regular	
		RockOrgan	0	0	19	Regular	
		RotaryOrgan	0	64	19	Regular	
		SlowRotary	0	65	19	Regular	
		FastRotary	0	66	19	Regular	
		ChurchOrgan	0	0	20	Regular	
		ChurchOrgan3	0	32	20	Regular	
		ChurchOrgan2	0	35	20	Regular	
		NotreDame	0	40	20	Regular	
		OrganFlute	0	64	20	Regular	
		Trem.OrganFl	0	65	20	Regular	
		ReedOrgan	0	0	21	Regular	
		PuffOrgan	0	40	21	Regular	
		Accordion	0	0	22	Regular	
		AccordIt	0	32	22	Regular	
		Harmonica	0	0	23	Regular	
		Harmonica2	0	32	23	Regular	
		TangoAccord	0	0	24	Regular	
		TangoAccord2	0	64	24	Regular	
		Guitar	NylonGuitar	0	0	25	Regular
			NylonGuitar2	0	16	25	Regular
			NylonGuitar3	0	25	25	Regular
			VelGtrHarmo	0	43	25	Regular
			Ukulele	0	96	25	Regular
			SteelGuitar	0	0	26	Regular
			SteelGuitar2	0	16	26	Regular
	12StrGuitar		0	35	26	Regular	
	Nylon&Steel		0	40	26	Regular	
	Steel&Body		0	41	26	Regular	
	Mandolin		0	96	26	Regular	
	JazzGuitar		0	0	27	Regular	
	MellowGuitar		0	18	27	Regular	
	JazzAmp		0	32	27	Regular	
	CleanGuitar		0	0	28	Regular	
	ChorusGuitar		0	32	28	Regular	
	MutedGuitar		0	0	29	Regular	
	FunkGuitar1		0	40	29	Regular	
	MuteSteelGtr		0	41	29	Regular	
	FunkGuitar2		0	43	29	Regular	
	JazzMan		0	45	29	Regular	
	Overdriven		0	0	30	Regular	
	GuitarPinch		0	43	30	Regular	
	Distortion		0	0	31	Regular	
	FeedbackGtr		0	40	31	Regular	
	FeedbackGtr2		0	41	31	Regular	
	GtrHarmonics		0	0	32	Regular	
	GtrFeedback		0	65	32	Regular	
	GtrHarmonic2		0	66	32	Regular	
	Bass		AcousticBass	0	0	33	Regular
			JazzRhythm	0	40	33	Regular
			VXUprghtBass	0	45	33	Regular
			FingerBass	0	0	34	Regular
			FingerDark	0	18	34	Regular
			FlangeBass	0	27	34	Regular
			Bass&DistEG	0	40	34	Regular
			FingerSlap	0	43	34	Regular
			FingerBass2	0	45	34	Regular
			Mod.Bass	0	65	34	Regular
			PickBass	0	0	35	Regular
		MutePickBass	0	28	35	Regular	
		FretlessBass	0	0	36	Regular	
		Fretless2	0	32	36	Regular	
		Fretless3	0	33	36	Regular	
		Fretless4	0	34	36	Regular	
		Syn.Fretless	0	96	36	Regular	
		SmthFretless	0	97	36	Regular	
		SlapBass1	0	0	37	Regular	
		ResonantSlap	0	27	37	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Bass	PunchThumb	0	32	37	Regular	
		SlapBass2	0	0	38	Regular	
		Velo.Sw.Slap	0	43	38	Regular	
		SynthBass1	0	0	39	Regular	
		SynBass1Dark	0	18	39	Regular	
		FastResoBass	0	20	39	Regular	
		AcidBass	0	24	39	Regular	
		ClaviBass	0	35	39	Regular	
		TechnoBass	0	40	39	Regular	
		Orbiter	0	64	39	Regular	
		SquareBass	0	65	39	Regular	
		RubberBass	0	66	39	Regular	
		Hammer	0	96	39	Regular	
		SynthBass2	0	0	40	Regular	
		MellowSyBass	0	6	40	Regular	
		SequenceBass	0	12	40	Regular	
		ClickSynBass	0	18	40	Regular	
		SynBass2Dark	0	19	40	Regular	
		SmoothSyBass	0	32	40	Regular	
		ModulrSyBass	0	40	40	Regular	
		DXBass	0	41	40	Regular	
		XWireBass	0	64	40	Regular	
		Strings	Violin	0	0	41	Regular
			SlwAtkViolin	0	8	41	Regular
			Viola	0	0	42	Regular
			Cello	0	0	43	Regular
			Contrabass	0	0	44	Regular
			Trem.Strings	0	0	45	Regular
			SlwAtkTremStr	0	8	45	Regular
			SuspenseStr	0	40	45	Regular
	PizzicatoStr		0	0	46	Regular	
	Orch.Harp		0	0	47	Regular	
	YangChin		0	40	47	Regular	
	Timpani		0	0	48	Regular	
	Ensemble		Strings1	0	0	49	Regular
			StereoStrings	0	3	49	Regular
			SlwAtkStrngs	0	8	49	Regular
		ArcoStrings	0	24	49	Regular	
		60'sStrings	0	35	49	Regular	
		Orchestra	0	40	49	Regular	
		Orchestra2	0	41	49	Regular	
		TremOrchestra	0	42	49	Regular	
		Velo.Strings	0	45	49	Regular	
		Strings2	0	0	50	Regular	
		S.SlowStrngs	0	3	50	Regular	
		LegatoStrngs	0	8	50	Regular	
		WarmStrings	0	40	50	Regular	
		Kingdom	0	41	50	Regular	
		70'sStrings	0	64	50	Regular	
		Strings3	0	65	50	Regular	
		SynStrings1	0	0	51	Regular	
		ResoStrings	0	27	51	Regular	
		SynStrings4	0	64	51	Regular	
		SynStrings5	0	65	51	Regular	
		SynStrings2	0	0	52	Regular	
		ChoirAahs	0	0	53	Regular	
		StereoChoir	0	3	53	Regular	
		ChoirAahs2	0	16	53	Regular	
		MellowChoir	0	32	53	Regular	
	ChoirStrings	0	40	53	Regular		
	VoiceOohs	0	0	54	Regular		
	SynthVoice	0	0	55	Regular		
	SynthVoice2	0	40	55	Regular		
	Choral	0	41	55	Regular		
	AnalogVoice	0	64	55	Regular		
	OrchestraHit	0	0	56	Regular		
	OrchestraHit2	0	35	56	Regular		
	Impact	0	64	56	Regular		
	Brass	Trumpet	0	0	57	Regular	
		Trumpet2	0	16	57	Regular	
		BriteTrumpet	0	17	57	Regular	
		WarmTrumpet	0	32	57	Regular	

CVP-609/605

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Brass	Trombone	0	0	58	Regular	
		Trombone2	0	18	58	Regular	
		Tuba	0	0	59	Regular	
		Tuba2	0	16	59	Regular	
		MutedTrumpet	0	0	60	Regular	
		FrenchHorn	0	0	61	Regular	
		Fr.HornSolo	0	6	61	Regular	
		FrenchHorn2	0	32	61	Regular	
		HornOrchestr	0	37	61	Regular	
		BrassSection	0	0	62	Regular	
		Tp&TbSection	0	35	62	Regular	
		BrassSect2	0	40	62	Regular	
		HighBrass	0	41	62	Regular	
		MellowBrass	0	42	62	Regular	
		SynthBrass1	0	0	63	Regular	
		QuackBrass	0	12	63	Regular	
		ResoSynBrass	0	20	63	Regular	
		PolyBrass	0	24	63	Regular	
		SynthBrass3	0	27	63	Regular	
		JumpBrass	0	32	63	Regular	
		AnaVelBrass1	0	45	63	Regular	
		AnalogBrass1	0	64	63	Regular	
		SynthBrass2	0	0	64	Regular	
		SoftBrass	0	18	64	Regular	
		SynthBrass4	0	40	64	Regular	
		ChoirBrass	0	41	64	Regular	
		AnaVelBrass2	0	45	64	Regular	
		AnalogBrass2	0	64	64	Regular	
		Reed	SopranoSax	0	0	65	Regular
			AltoSax	0	0	66	Regular
			SaxSection	0	40	66	Regular
			HyperAltoSax	0	43	66	Regular
			TenorSax	0	0	67	Regular
			BreathyTenor	0	40	67	Regular
			SoftTenorSax	0	41	67	Regular
			TenorSax2	0	64	67	Regular
			BaritoneSax	0	0	68	Regular
			Oboe	0	0	69	Regular
			EnglishHorn	0	0	70	Regular
			Bassoon	0	0	71	Regular
	Clarinet		0	0	72	Regular	
	Pipe		Piccolo	0	0	73	Regular
			Flute	0	0	74	Regular
			Recorder	0	0	75	Regular
			PanFlute	0	0	76	Regular
			BlownBottle	0	0	77	Regular
		Shakuhachi	0	0	78	Regular	
		Whistle	0	0	79	Regular	
		Ocarina	0	0	80	Regular	
		Synth.Lead	SquareLead	0	0	81	Regular
			SquareLead2	0	6	81	Regular
	LMSquare		0	8	81	Regular	
	Hollow		0	18	81	Regular	
	Shroud		0	19	81	Regular	
	Mellow		0	64	81	Regular	
	SoloSine		0	65	81	Regular	
	SineLead		0	66	81	Regular	
	SawtoothLead		0	0	82	Regular	
	SawtoothLd2		0	6	82	Regular	
	ThickSaw		0	8	82	Regular	
	DynamicSaw		0	18	82	Regular	
	DigitalSaw		0	19	82	Regular	
	BigLead		0	20	82	Regular	
	HeavySynth		0	24	82	Regular	
	WaspSynth		0	25	82	Regular	
	PulseSaw		0	40	82	Regular	
	Dr.Lead		0	41	82	Regular	
	VelocityLead		0	45	82	Regular	
	Seq.Analog		0	96	82	Regular	
	CalliopeLead		0	0	83	Regular	
	PureLead		0	65	83	Regular	
	ChiffLead		0	0	84	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Synth.Lead	Rubby	0	64	84	Regular	
		CharangLead	0	0	85	Regular	
		DistortedLd	0	64	85	Regular	
		WireLead	0	65	85	Regular	
		VoiceLead	0	0	86	Regular	
		SynthAahs	0	24	86	Regular	
		VoxLead	0	64	86	Regular	
		FifthsLead	0	0	87	Regular	
		BigFive	0	35	87	Regular	
		Bass&Lead	0	0	88	Regular	
		Big&Low	0	16	88	Regular	
		Fat&Perky	0	64	88	Regular	
		SoftWhirl	0	65	88	Regular	
		Synth.Pad	NewAgePad	0	0	89	Regular
			Fantasy	0	64	89	Regular
			WarmPad	0	0	90	Regular
			ThickPad	0	16	90	Regular
			SoftPad	0	17	90	Regular
			SinePad	0	18	90	Regular
			HornPad	0	64	90	Regular
			RotaryStrngs	0	65	90	Regular
			PolySynthPad	0	0	91	Regular
			PolyPad80	0	64	91	Regular
			ClickPad	0	65	91	Regular
	AnalogPad		0	66	91	Regular	
	SquarePad		0	67	91	Regular	
	ChoirPad		0	0	92	Regular	
	Heaven		0	64	92	Regular	
	Itopia		0	66	92	Regular	
	CCPad		0	67	92	Regular	
	BowedPad		0	0	93	Regular	
	Glacier		0	64	93	Regular	
	GlassPad		0	65	93	Regular	
	MetallicPad		0	0	94	Regular	
	TinePad		0	64	94	Regular	
	PanPad		0	65	94	Regular	
	HaloPad		0	0	95	Regular	
	SweepPad		0	0	96	Regular	
	Shwimmer		0	20	96	Regular	
	Converge		0	27	96	Regular	
	PolarPad		0	64	96	Regular	
	Celestial		0	66	96	Regular	
	Synth.Effect		Rain	0	0	97	Regular
			ClaviPad	0	45	97	Regular
			HarmoRain	0	64	97	Regular
			AfricanWind	0	65	97	Regular
			Carib	0	66	97	Regular
			SoundTrack	0	0	98	Regular
			Prologue	0	27	98	Regular
		Ancestral	0	64	98	Regular	
		Crystal	0	0	99	Regular	
		SynthDr.Comp	0	12	99	Regular	
		Popcorn	0	14	99	Regular	
		TinyBells	0	18	99	Regular	
		RoundGlocken	0	35	99	Regular	
		GlockenChime	0	40	99	Regular	
		ClearBells	0	41	99	Regular	
		ChorusBells	0	42	99	Regular	
		SynthMallet	0	64	99	Regular	
		SoftCrystal	0	65	99	Regular	
		LoudGlocken	0	66	99	Regular	
		ChristmasBel	0	67	99	Regular	
		VibeBells	0	68	99	Regular	
		DigitalBells	0	69	99	Regular	
		AirBells	0	70	99	Regular	
		BellHarp	0	71	99	Regular	
		Gamelimba	0	72	99	Regular	
		Atmosphere	0	0	100	Regular	
		WarmAtmos.	0	18	100	Regular	
		HollwRelease	0	19	100	Regular	
		NylonElPiano	0	40	100	Regular	
		NylonHarp	0	64	100	Regular	

CVP-609/605

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Synth.Effect	HarpVox	0	65	100	Regular	
		Atmos.Pad	0	66	100	Regular	
		Planet	0	67	100	Regular	
		Brightness	0	0	101	Regular	
		FantasyBells	0	64	101	Regular	
		Smokey	0	96	101	Regular	
		Goblins	0	0	102	Regular	
		GoblinsSynth	0	64	102	Regular	
		Creepier	0	65	102	Regular	
		RingPad	0	66	102	Regular	
		Ritual	0	67	102	Regular	
		ToHeaven	0	68	102	Regular	
		Night	0	70	102	Regular	
		Glisten	0	71	102	Regular	
		BellChoir	0	96	102	Regular	
		Echoes	0	0	103	Regular	
		Echoes2	0	8	103	Regular	
		EchoPan	0	14	103	Regular	
		EchoBells	0	64	103	Regular	
		BigPan	0	65	103	Regular	
		SynthPiano	0	66	103	Regular	
		Creation	0	67	103	Regular	
		StarDust	0	68	103	Regular	
		Reso&Panning	0	69	103	Regular	
		Sci-Fi	0	0	104	Regular	
		Starz	0	64	104	Regular	
		Ethnic	Sitar	0	0	105	Regular
			DetunedSitar	0	32	105	Regular
			Sitar2	0	35	105	Regular
			Tambra	0	96	105	Regular
			Tamboura	0	97	105	Regular
			Banjo	0	0	106	Regular
			MutedBanjo	0	28	106	Regular
	Rabab		0	96	106	Regular	
	Gopichant		0	97	106	Regular	
	Oud		0	98	106	Regular	
	Shamisen		0	0	107	Regular	
	Koto		0	0	108	Regular	
	Taisho-kin		0	96	108	Regular	
	Kanoon		0	97	108	Regular	
	Kalimba		0	0	109	Regular	
Bagpipe	0		0	110	Regular		
Fiddle	0		0	111	Regular		
Shanai	0		0	112	Regular		
Shanai2	0		64	112	Regular		
Pungi	0		96	112	Regular		
Hichiriki	0	97	112	Regular			
Percussive	TinkleBell	0	0	113	Regular		
	Bonang	0	96	113	Regular		
	Altair	0	97	113	Regular		
	GamelanGongs	0	98	113	Regular		
	StereoGamlan	0	99	113	Regular		
	RamaCymbal	0	100	113	Regular		
	AsianBells	0	101	113	Regular		
	Agogo	0	0	114	Regular		
	SteelDrums	0	0	115	Regular		
	GlassPerc.	0	97	115	Regular		
	ThaiBells	0	98	115	Regular		
	Woodblock	0	0	116	Regular		
	Castanets	0	96	116	Regular		
	TaikoDrum	0	0	117	Regular		
	GranCassa	0	96	117	Regular		
	MelodicTom	0	0	118	Regular		
	MelodicTom2	0	64	118	Regular		
	RealTom	0	65	118	Regular		
	RockTom	0	66	118	Regular		
	SynthDrum	0	0	119	Regular		
	AnalogTom	0	64	119	Regular		
	ElectroPerc.	0	65	119	Regular		
	Rev.Cymbal	0	0	120	Regular		
SoundEffect	GtrFretNoise	0	0	121	Regular		
	BreathNoise	0	0	122	Regular		

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type		
			MSB	LSB	Prg			
GM&XG	SoundEffect	Seashore	0	0	123	Regular		
		BirdTweet	0	0	124	Regular		
		TelephonRing	0	0	125	Regular		
		Helicopter	0	0	126	Regular		
		Applause	0	0	127	Regular		
		Gunshot	0	0	128	Regular		
		CuttingNoise	64	0	1	Regular		
		CuttingNoiz2	64	0	2	Regular		
		StringSlap	64	0	4	Regular		
		Fl.KeyClick	64	0	17	Regular		
		Shower	64	0	33	Regular		
		Thunder	64	0	34	Regular		
		Wind	64	0	35	Regular		
		Stream	64	0	36	Regular		
		Bubble	64	0	37	Regular		
		Feed	64	0	38	Regular		
		Dog	64	0	49	Regular		
		Horse	64	0	50	Regular		
		BirdTweet2	64	0	51	Regular		
		Ghost	64	0	55	Regular		
		Maou	64	0	56	Regular		
		PhoneCall	64	0	65	Regular		
		DoorSqueak	64	0	66	Regular		
		DoorSlam	64	0	67	Regular		
		ScratchCut	64	0	68	Regular		
		ScratchSplit	64	0	69	Regular		
		WindChime	64	0	70	Regular		
		TelphonRing2	64	0	71	Regular		
		CarEngineIgn	64	0	81	Regular		
		CarTiresSql	64	0	82	Regular		
		CarPassing	64	0	83	Regular		
		CarCrash	64	0	84	Regular		
		Siren	64	0	85	Regular		
		Train	64	0	86	Regular		
		JetPlane	64	0	87	Regular		
		Starship	64	0	88	Regular		
		Burst	64	0	89	Regular		
		RollrCoaster	64	0	90	Regular		
		Submarine	64	0	91	Regular		
		Laugh	64	0	97	Regular		
		Scream	64	0	98	Regular		
		Punch	64	0	99	Regular		
		Heartbeat	64	0	100	Regular		
		FootSteps	64	0	101	Regular		
		MachineGun	64	0	113	Regular		
		LaserGun	64	0	114	Regular		
		Explosion	64	0	115	Regular		
		Firework	64	0	116	Regular		
		GM2	Piano	GrandPiano	121	0	1	Regular
				GrandPianoW	121	1	1	Regular
				GrandPianoD	121	2	1	Regular
				BrightPiano	121	0	2	Regular
				BrightPianoW	121	1	2	Regular
				ElecGrandPno	121	0	3	Regular
				ElecGrandPW	121	1	3	Regular
				Honkytonk	121	0	4	Regular
				HonkytonkW	121	1	4	Regular
				El.Piano1	121	0	5	Regular
				DetunedEP1	121	1	5	Regular
				EP1VeloMix	121	2	5	Regular
				60'sEl.Piano	121	3	5	Regular
				El.Piano2	121	0	6	Regular
				DetunedEP2	121	1	6	Regular
				EP2VeloMix	121	2	6	Regular
				EPLegend	121	3	6	Regular
				EPPHase	121	4	6	Regular
				Harpsichord	121	0	7	Regular
Harpsi.OctMx	121			1	7	Regular		
HarpsichordW	121			2	7	Regular		
Harpsi.KOff	121			3	7	Regular		
Clavi.	121			0	8	Regular		
PulseClavi.	121			1	8	Regular		

CVP-609/605

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM2	Chromatic Perc	Celesta	121	0	9	Regular	
		Glockenspiel	121	0	10	Regular	
		MusicBox	121	0	11	Regular	
		Vibraphone	121	0	12	Regular	
		VibraphoneW	121	1	12	Regular	
		Marimba	121	0	13	Regular	
		MarimbaW	121	1	13	Regular	
		Xylophone	121	0	14	Regular	
		TubularBells	121	0	15	Regular	
		ChurchBells	121	1	15	Regular	
		Carillon	121	2	15	Regular	
		Dulcimer	121	0	16	Regular	
		Organ	DrawbarOrgan	121	0	17	Regular
			DetDrawOrgan	121	1	17	Regular
			It60'sOrgan	121	2	17	Regular
	DrawbarOrg2		121	3	17	Regular	
	Perc.Organ		121	0	18	Regular	
	DetPercOrgan		121	1	18	Regular	
	Perc.Organ2		121	2	18	Regular	
	RockOrgan		121	0	19	Regular	
	ChurchOrgan		121	0	20	Regular	
	ChrchrOrgOctM		121	1	20	Regular	
	DetChurchOrg		121	2	20	Regular	
	ReedOrgan		121	0	21	Regular	
	PuffOrgan		121	1	21	Regular	
	Accordion		121	0	22	Regular	
	Accordion2		121	1	22	Regular	
	Guitar	NylonGuitar	121	0	25	Regular	
		Ukulele	121	1	25	Regular	
		NylonGtrKoff	121	2	25	Regular	
		NylonGuitar2	121	3	25	Regular	
		SteelGuitar	121	0	26	Regular	
		12StrGuitar	121	1	26	Regular	
		Mandolin	121	2	26	Regular	
		Steel&Body	121	3	26	Regular	
		JazzGuitar	121	0	27	Regular	
		PedlSteelGtr	121	1	27	Regular	
		CleanGuitar	121	0	28	Regular	
		DetCleanGtr	121	1	28	Regular	
		MidToneGtr	121	2	28	Regular	
		MutedGuitar	121	0	29	Regular	
		FunkGuitar	121	1	29	Regular	
Bass	MutedV-SwGtr	121	2	29	Regular		
	JazzMan	121	3	29	Regular		
	Overdriven	121	0	30	Regular		
	GuitarPinch	121	1	30	Regular		
	Distortion	121	0	31	Regular		
	FeedbackGtr	121	1	31	Regular		
	DstRhythmGtr	121	2	31	Regular		
	GtrHarmonics	121	0	32	Regular		
	GtrFeedback	121	1	32	Regular		
	AcousticBass	121	0	33	Regular		
	FingerBass	121	0	34	Regular		
	FingerSlap	121	1	34	Regular		
	PickBass	121	0	35	Regular		
	FretlessBass	121	0	36	Regular		
	SlapBass1	121	0	37	Regular		
SlapBass2	121	0	38	Regular			
SynthBass1	121	0	39	Regular			
WarmSyBass	121	1	39	Regular			
ResoSynhBass	121	2	39	Regular			
ClaviBass	121	3	39	Regular			
Hammer	121	4	39	Regular			
SynthBass2	121	0	40	Regular			
AttackBass	121	1	40	Regular			
RubberBass	121	2	40	Regular			
AttackPulse	121	3	40	Regular			
Strings	Violin	121	0	41	Regular		
	SlwAtkViolin	121	1	41	Regular		
	Viola	121	0	42	Regular		

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM2	Strings	Cello	121	0	43	Regular	
		Contrabass	121	0	44	Regular	
		Trem.Strings	121	0	45	Regular	
		PizzicatoStr	121	0	46	Regular	
		Orch.Harp	121	0	47	Regular	
		YangChin	121	1	47	Regular	
		Timpani	121	0	48	Regular	
		Ensemble	Strings1	121	0	49	Regular
			StringsBrass	121	1	49	Regular
			60'sStrings	121	2	49	Regular
	Strings2		121	0	50	Regular	
	SynStrings1		121	0	51	Regular	
	SynStrings3		121	1	51	Regular	
	SynStrings2		121	0	52	Regular	
	ChoirAahs		121	0	53	Regular	
	ChoirAahs2		121	1	53	Regular	
	VoiceOohs		121	0	54	Regular	
	Humming		121	1	54	Regular	
	SynthVoice		121	0	55	Regular	
	AnalogVoice		121	1	55	Regular	
	OrchestraHit		121	0	56	Regular	
	BassHitPlus		121	1	56	Regular	
	6thHit	121	2	56	Regular		
	EuroHit	121	3	56	Regular		
	Brass	Trumpet	121	0	57	Regular	
		DarkTpSoft	121	1	57	Regular	
		Trombone	121	0	58	Regular	
		Trombone2	121	1	58	Regular	
		BriteTrombon	121	2	58	Regular	
		Tuba	121	0	59	Regular	
		MutedTrumpet	121	0	60	Regular	
		MuteTrumpet2	121	1	60	Regular	
		FrenchHorn	121	0	61	Regular	
		FrenchHorn2	121	1	61	Regular	
		BrassSection	121	0	62	Regular	
		BrassSect2	121	1	62	Regular	
		SynthBrass1	121	0	63	Regular	
		SynthBrass3	121	1	63	Regular	
		AnaSynBrass1	121	2	63	Regular	
	JumpBrass	121	3	63	Regular		
	SynthBrass2	121	0	64	Regular		
	SynthBrass4	121	1	64	Regular		
	AnaSynBrass2	121	2	64	Regular		
	Reed	SopranoSax	121	0	65	Regular	
		AltoSax	121	0	66	Regular	
		TenorSax	121	0	67	Regular	
		BaritoneSax	121	0	68	Regular	
		Oboe	121	0	69	Regular	
		EnglishHorn	121	0	70	Regular	
		Bassoon	121	0	71	Regular	
		Clarinet	121	0	72	Regular	
		Pipe	Piccolo	121	0	73	Regular
			Flute	121	0	74	Regular
	Recorder		121	0	75	Regular	
	PanFlute		121	0	76	Regular	
	BlownBottle		121	0	77	Regular	
	Shakuhachi		121	0	78	Regular	
	Whistle		121	0	79	Regular	
	Ocarina		121	0	80	Regular	
	Synth.Lead		SquareLead	121	0	81	Regular
			SquareLead2	121	1	81	Regular
		SineLead	121	2	81	Regular	
		SawtoothLead	121	0	82	Regular	
		SawtoothLd2	121	1	82	Regular	
		SawPulseLead	121	2	82	Regular	
		DoubiSawLead	121	3	82	Regular	
		Seq.Analog	121	4	82	Regular	
		CalliopeLead	121	0	83	Regular	
		ChiffLead	121	0	84	Regular	
		CharangLead	121	0	85	Regular	
		WireLead	121	1	85	Regular	
		VoiceLead	121	0	86	Regular	

CVP-609/605

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM2	Synth.Lead	FifthsLead	121	0	87	Regular	
		Bass&Lead	121	0	88	Regular	
		SoftWhirl	121	1	88	Regular	
	Synth.Pad	NewAgePad	121	0	89	Regular	
		WarmPad	121	0	90	Regular	
		SinePad	121	1	90	Regular	
		PolySynthPad	121	0	91	Regular	
		ChoirPad	121	0	92	Regular	
		ItopiaPad	121	1	92	Regular	
		BowedPad	121	0	93	Regular	
		MetallicPad	121	0	94	Regular	
		HaloPad	121	0	95	Regular	
		SweepPad	121	0	96	Regular	
		Synth.Effect	Rain	121	0	97	Regular
			SoundTrack	121	0	98	Regular
	Crystal		121	0	99	Regular	
	SynthMallet		121	1	99	Regular	
	Atmosphere		121	0	100	Regular	
	Brightness		121	0	101	Regular	
	Goblins		121	0	102	Regular	
	Echoes		121	0	103	Regular	
	EchoBell		121	1	103	Regular	
	EchoPan		121	2	103	Regular	
	Sci-Fi		121	0	104	Regular	
	Ethnic		Sitar	121	0	105	Regular
			Sitar2	121	1	105	Regular
		Banjo	121	0	106	Regular	
		Shamisen	121	0	107	Regular	
		Koto	121	0	108	Regular	
		TaishoKoto	121	1	108	Regular	
		Kalimba	121	0	109	Regular	
		Bagpipe	121	0	110	Regular	
		Fiddle	121	0	111	Regular	
		Shanai	121	0	112	Regular	
	Percussive	TinkleBell	121	0	113	Regular	
		Agogo	121	0	114	Regular	
		SteelDrums	121	0	115	Regular	
		Woodblock	121	0	116	Regular	
		Castanets	121	1	116	Regular	
		TaikoDrum	121	0	117	Regular	
		ConcertBD	121	1	117	Regular	
		MelodicTom	121	0	118	Regular	
		MelodicTom2	121	1	118	Regular	
		SynthDrum	121	0	119	Regular	
		RhythmBoxTom	121	1	119	Regular	
		ElectricDrum	121	2	119	Regular	
		Rev.Cymbal	121	0	120	Regular	
		SoundEffect	GtrFretNoise	121	0	121	Regular
	GtrCutNoise		121	1	121	Regular	
	StringSlap		121	2	121	Regular	
	BreathNoise		121	0	122	Regular	
	Fl.KeyClick		121	1	122	Regular	
	Seashore		121	0	123	Regular	
	Rain		121	1	123	Regular	
	Thunder		121	2	123	Regular	
	Wind		121	3	123	Regular	
	Stream		121	4	123	Regular	
	Bubble		121	5	123	Regular	
	BirdTweet		121	0	124	Regular	
	Dog		121	1	124	Regular	
	HorseGallop		121	2	124	Regular	
	BirdTweet2		121	3	124	Regular	
	TelephonRing		121	0	125	Regular	
	TelRing2		121	1	125	Regular	
	DoorCreaking		121	2	125	Regular	
	Door		121	3	125	Regular	
	Scratch		121	4	125	Regular	
	WindChime		121	5	125	Regular	
	Helicopter		121	0	126	Regular	
	CarEngine		121	1	126	Regular	
	CarStop		121	2	126	Regular	
	CarPass		121	3	126	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
GM2	SoundEffect	CarCrash	121	4	126	Regular
		Siren	121	5	126	Regular
		Train	121	6	126	Regular
		Jetplane	121	7	126	Regular
		Starship	121	8	126	Regular
		BurstNoise	121	9	126	Regular
		Applause	121	0	127	Regular
		Laughing	121	1	127	Regular
		Screaming	121	2	127	Regular
		Punch	121	3	127	Regular
		HeartBeat	121	4	127	Regular
		Footsteps	121	5	127	Regular
		Gunshot	121	0	128	Regular
		MachineGun	121	1	128	Regular
		Lasergun	121	2	128	Regular
		Explosion	121	3	128	Regular
	Drum	StandardSet	120	0	1	Drums
		RoomSet	120	0	9	Drums
		PowerSet	120	0	17	Drums
		ElectroSet	120	0	25	Drums
		AnalogSet	120	0	26	Drums
		JazzSet	120	0	33	Drums
		BrushSet	120	0	41	Drums
		OrchestraSet	120	0	49	Drums
		SFXSet	120	0	57	SFX Kit

Mega Voice Map / Sound-Zuordnungen der Mega Voices / Carte des voix Mega / Mapa de Mega Voice

CVP-609	CVP-605	MSB	LSB	PC# (1-128)	Voice Name	Velocity Switch Points (under BS)												above C6	above C8
		8	0	1	Mega NylonGuitar	1-20	21-40	41-60	61-75	76-90	91-105	106-120	121-127	1-127	1-127				
		8	0	2	Mega SteelGuitar	open soft	open med	open hard	dead	mute	hammer	slide	harmonics	strum noise	fret noise				
		8	0	3	Mega HiStringGtr	open soft	open med	open hard	dead	mute	hammer	slide	harmonics	strum noise	fret noise				
		8	0	3	Mega 12StringGtr	1-89	1-71	soft	1-115	72-115	hard	90-127	116-127	1-127	1-127				
		8	1	3	Mega Element1(Steel)	1-89	soft	1-89	med	hard	90-127	90-127	hard	1-127	1-127				
		8	0	4	Mega CleanGuitar	1-20	21-40	41-60	61-75	76-90	91-105	106-120	121-127	1-127	1-127				
		8	0	4	Mega SolidGuitar1	open soft	open hard	slap	dead	mute	hammer	slide	pick harmonics	strum noise	fret noise				
		8	1	4	Mega SolidGuitar1	open soft	open hard	slap	dead	mute	hammer	slide	pick harmonics	strum noise	fret noise				
		8	2	4	Mega SolidGuitar2	open soft	open med	open hard	dead	mute	hammer	slide	pick harmonics	strum noise	fret noise				
		8	3	4	Mega SingleCoil	1-20	21-40	41-60	61-75	76-90	91-105	106-120	121-127	1-127	1-127				
		8	3	4	Mega SingleCoil	open soft	open med	open hard	dead	mute	hammer	slide	pick harmonics	strum noise	fret noise				
		8	4	4	Mega FingerGtr	1-20	21-40	41-60	61-75	76-90	91-105	106-120	121-127	1-127	1-127				
		8	4	4	Mega FingerGtr	open soft	open med	open hard	dead	mute	hammer	slide	pick harmonics	strum noise	fret noise				
		8	5	4	Mega FingerSlapGtr	1-20	21-40	41-60	61-75	76-90	91-105	106-120	121-127	1-127	1-127				
		8	5	4	Mega FingerSlapGtr	open soft	open med	open hard	dead	mute	hammer	slide	pick harmonics	strum noise	fret noise				
		8	6	4	Mega VintagePickGtr	1-20	21-40	41-60	61-75	76-90	91-105	106-120	121-127	1-127	1-127				
		8	6	4	Mega VintagePickGtr	open soft	open med	open hard	dead	mute	hammer	slide	pick harmonics	strum noise	fret noise				
		8	7	4	Mega VintageSlapGtr	1-20	21-40	41-60	61-75	76-90	91-105	106-120	121-127	1-127	1-127				
		8	7	4	Mega VintageSlapGtr	open soft	open med	open hard	dead	mute	hammer	slide	pick harmonics	strum noise	fret noise				
		8	8	4	Mega SlapAmpGtr	1-20	21-30	31-40	41-50	51-60	61-67	68-75	76-82	83-90	91-105				
		8	8	4	Mega SlapAmpGtr	open soft	open med	open hard	open amp	open slap line	dead mtp	dead mtp	mute mtp	mute mtp	hammer				
		8	8	4	Mega SlapAmpGtr	open soft	open med	open hard	open amp	open slap line	dead mtp	dead mtp	mute mtp	mute mtp	hammer				
		8	0	5	Mega OverdriveGtr	1-55	open	56-120	56-120	56-120	56-120	56-120	56-120	1-127	1-127				
		8	0	5	Mega OverdriveGtr	open	open	open	open	open	open	open	open	open	open				
		8	0	6	Mega DistortionGtr	1-55	open	56-120	56-120	56-120	56-120	56-120	56-120	1-127	1-127				
		8	0	6	Mega DistortionGtr	open	open	open	open	open	open	open	open	open	open				

CVP-609	CVP-605	MSB	LSB	PC# (1-128)	Voice Name	Velocity Switch Points (under B5)												above C6	above C8
						1-20	21-40	41-60	61-75	76-90	91-105	106-120	121-127	1-20	21-40	41-60	61-75		
○	○	8	0	7	Mega JazzGuitar	open soft	open med	open hard	dead soft	dead hard	hammer	slide	pick harmonics	1-127	strum noise	1-127	fret noise		
○	○	8	0	17	Mega AcousticBass	open soft	open soft	open hard	open hard	dead	81-120	121-127	harmonics	1-127	EFX				
○	○	8	0	18	Mega ElectricBass	open soft	open soft	open hard	open hard	dead	81-120	121-127	harmonics	1-127	EFX				
○	○	8	1	18	Mega VintageRound	open soft	open soft	open hard	open hard	dead	81-120	121-127	harmonics	1-127	EFX				
○	○	8	2	18	Mega VintageFlat	open soft	open soft	open hard	open hard	dead	81-120	121-127	harmonics	1-127	EFX				
○	○	8	0	19	Mega PickBass	1-40	open	41-80	mute	81-120	121-127	harmonics	1-127	EFX					
○	○	8	1	19	Mega VintagePick	1-40	open	41-80	mute	81-120	121-127	harmonics	1-127	EFX					
○	○	8	0	20	Mega FretlessBass	1-80	open	open	dead	81-120	121-127	harmonics	1-127	EFX					
○	○	8	0	49	Mega SmallStrings	1-20	21-40	41-60	61-80	81-95	96-110	111-120	121-127	glissando down					
○	○	8	1	49	Mega ClassicalStrings	p	mf	f	legato	spicato f	spicato ff	tremolo	glissando down						
○	○	8	0	50	Mega LargeStrings	1-20	21-40	41-60	61-80	81-95	96-110	111-120	121-127	glissando down					
○	○	8	1	50	Mega RealStrings	p	mf	f	legato	spicato f	spicato ff	tremolo	glissando down						
○	○	8	0	52	Mega MaleVoiceChoir	1-15	16-30	31-45	46-60	61-75	76-90	91-105	106-127	Aah mf legato					
○	○	8	0	55	Mega GospelChoir	Ooh p	Ooh p legato	Ooh mf	Ooh mf legato	Aah p	Aah p legato	Aah mf	Aah mf legato						
○	○	8	0	57	Mega Brass	1-15	16-30	31-45	46-60	61-75	76-90	91-105	106-127	Aaa legato					
○	○	8	0	65	Mega Trumpet	Hmm	Hmm legato	Wow	Wow legato	Hey	Hey legato	Aaa	Aaa legato						
○	○	8	0	65	Mega Trumpet	1-20	21-40	41-60	61-80	81-90	91-100	101-110	111-120	121-127	Ad libs EFX				
○	○	8	0	65	Mega Trumpet	p	mf	f	attack	scoops	shake	falls fast mf	glissando up						
○	○	8	0	65	Mega Trumpet	1-20	21-40	41-60	61-80	81-100	101-110	111-120	121-127	glissando up					
○	○	8	0	65	Mega Trumpet	mf	f	ff	legato	straight	shake	falls	glissando up						

CVP-609	CVP-605	MSB	LSB	PC# (1-128)	Voice Name	Velocity Switch Points (under B5)												above C6	above C8
						1-20	21-40	41-60	61-80	81-100	101-127	1-127							
O	O	8	0	83	Mega TenorSax	mp		f	legato	growl	falls				valve noise (C6 - B6 key on noise C7 - B7 key off noise)	1-127	breath noise		
O	-	8	0	101	PopHaa	1-10	11-20	41-50	61-70	81-90	101-110	110-127							
						Haa p	Aa p legato	Haa f	Haa vib f	Aa vib f legato	Waa p	Waa vib p	Waa f	Waa vib f					
O	-	8	0	102	PopDaa	1-10	11-20	41-50	61-70	81-90	101-110	110-127							
						Daa p	Aa p legato	Daa f	Daa vib f	Aa vib f legato	Waa p	Waa vib p	Waa f	Waa vib f					
O	-	8	0	103	PopBaa	1-10	11-20	41-50	61-70	81-90	101-110	110-127							
						Baa p	Aa p legato	Baa f	Baa vib f	Aa vib f legato	Yaa p	Yaa vib p	Yaa f	Yaa vib f					
O	-	8	0	106	PopHoo	1-10	11-20	41-50	61-70	81-90	101-110	110-127							
						Hoo p	Oo p legato	Hoo f	Hoo vib f	Oo vib f legato	Yoo p	Yoo vib p	Yoo f	Yoo vib f					
O	-	8	0	107	PopDoo	1-10	11-20	41-50	61-70	81-90	101-110	110-127							
						Doo p	Oo p legato	Doo f	Doo vib f	Oo vib f legato	Yoo p	Yoo vib p	Yoo f	Yoo vib f					
O	-	8	0	104	PopShoo	1-10	11-20	41-50	61-70	81-90	101-110	110-127							
						Shoo p	Oo p legato	Shoo f	Shoo vib f	Oo vib f legato	Yoo p	Yoo vib p	Yoo f	Yoo vib f					

CVP-609	CVP-605	MSB	LSB	PC# (1-128)	Voice Name	Velocity Switch Points (under B5)										above C6	above C8		
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100			101-110	110-127
O	—	8	0	111	PopHee	Hee vib p	Ee vib p legato	Hee vib p	Ee vib p legato	Hee vib p legato	Ee vib p legato	Hee vib p	Ee vib p legato	Hee vib p	91-100	Wee vib p	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127	above C6
						Hee vib p	Hee vib p	Hee vib p	Hee vib p	Hee vib p	Hee vib p	Hee vib p	Hee vib p	Hee vib p	Hee vib p	Hee vib p	Hee vib p	Hee vib p	Hee vib p
O	—	8	0	108	PopBee	1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127	above C6
						Bee vib p	Ee vib p legato	Bee vib p	Ee vib p legato	Bee vib p	Ee vib p legato	Bee vib p	Ee vib p legato	Bee vib p	Ee vib p legato	Bee vib p	Ee vib p legato	Bee vib p	Ee vib p legato
O	—	8	0	116	PopHaa L2	1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127	above C6
						Haa p	Aa p legato2	Haa vib p	Aa vib p legato2	Haa f	Aa f legato2	Haa vib f	Aa vib f legato2	Haa f	Aa f legato2	Haa vib f	Aa vib f legato2	Waa p	Waa vib p
O	—	8	0	121	PopHoo L2	1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127	above C6
						Hoo p	Oo p legato2	Hoo vib p	Oo vib p legato2	Hoo f	Oo f legato2	Hoo vib f	Oo vib f legato2	Hoo f	Oo f legato2	Hoo vib f	Oo vib f legato2	Yoo p	Yoo vib p
O	—	8	0	126	PopHee L2	1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127	above C6
						Hee vib p	Ee vib p legato2	Hee vib p	Ee vib p legato2	Hee vib p	Ee vib p legato2	Hee vib p	Ee vib p legato2	Hee vib p	Ee vib p legato2	Hee vib p	Ee vib p legato2	Hee vib p	Hee vib p

Drum/key Assignment List / Liste der Tastenzuordnungen der Schlaginstrumente / Liste d'assignation instrument de batterie/touche du clavier / Lista de asignación de teclas/batería

CVP-609		○ (Live!)		○ (Live!)		○		○		○	
CVP-605		○		○		○		○		○	
		Standard Kit 1		Standard Kit 2		Hit Kit		Room Kit		(Legacy) Rock Kit	
Bank Select MSB (0-127)		127		127		127		127		127	
Bank Select LSB (0-127)		0		0		0		0		0	
Program Change (0-127)		0		1		4		8		16	
Program Change (1-128)		1		2		5		9		17	
MIDI	Keyboard	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp
Note#	Note	(*1)	(*2)								
13	C#-1	C#1	3								
14	D-1	D1	3								
15	D#-1	D#1									
16	E-1	E1									
17	F-1	F1	4								
18	F#-1	F#1	4								
19	G-1	G1									
20	G#-1	G#1									
21	A-1	A1									
22	A#-1	A#1									
23	B-1	B1									
24	C0	C2									
25	C#0	C#2									
26	D0	D2	●								
27	D#0	D#2									
28	E0	E2	●								
29	F0	F2	●								
30	F#0	F#2									
31	G0	G2			Snare Soft 2		Snare Electro			Snare Noisy	
32	G#0	G#2									
33	AD	A2					Kick Tight L				
34	A#0	A#2			Open Rim Shot H Short		Snare Pitched				
35	B0	B2					Kick Wet				
36	C1	C3			Kick Short		Kick Tight H			Kick 2	Kick Gate
37	C#1	C#3			Side Stick Light		Stick Ambient				
38	D1	D3			Snare		Snare Ambient		Snare Snappy		Snare Rock
39	D#1	D#3									
40	E1	E3			Snare Tight		Snare Tight 2		Snare Tight Snappy		Snare Rock Tight
41	F1	F3			Floor Tom L		Hybrid Tom 1		Tom Room 1		Tom Rock 1
42	F#1	F#3	1		Hi-Hat Closed		Hi-Hat Closed 2	1			
43	G1	G3			Floor Tom H		Hybrid Tom 2		Tom Room 2		Tom Rock 2
44	G#1	G#3	1		Hi-Hat Pedal		Hi-Hat Pedal 2	1			
45	A1	A3			Low Tom		Hybrid Tom 3		Tom Room 3		Tom Rock 3
46	A#1	A#3	1		Hi-Hat Open		Hi-Hat Open 2	1			
47	B1	B3			Mid Tom L		Hybrid Tom 4		Tom Room 4		Tom Rock 4
48	C2	C4			Mid Tom H		Hybrid Tom 5		Tom Room 5		Tom Rock 5
49	C#2	C#4			Crash Cymbal 1						
50	D2	D4			High Tom		Hybrid Tom 6		Tom Room 6		Tom Rock 6
51	D#2	D#4			Ride Cymbal 1						
52	E2	E4			Chinese Cymbal						
53	F2	F4			Ride Cymbal Cup						
54	F#2	F#4			Tambourine		Tambourine Light				
55	G2	G4			Splash Cymbal						
56	G#2	G#4			Cowbell						
57	A2	A4			Crash Cymbal 2						
58	A#2	A#4			Vibraslap						
59	B2	B4			Ride Cymbal 2						
60	C3	C5			Bongo H						
61	C#3	C#5			Bongo L						
62	D3	D5			Conga H Mute						
63	D#3	D#5			Conga H Open						
64	E3	E5			Conga L						
65	F3	F5			Timbale H						
66	F#3	F#5			Timbale L						
67	G3	G5			Agogo H						
68	G#3	G#5			Agogo L						
69	A3	A5			Cabasa						
70	A#3	A#5			Maracas						
71	B3	B5	●		Samba Whistle H						
72	C4	C6	●		Samba Whistle L						
73	C#4	C#6			Guiro Short						
74	D4	D6	●		Guiro Long						
75	D#4	D#6			Claves						
76	E4	E6			Wood Block H						
77	F4	F6			Wood Block L						
78	F#4	F#6			Cuica Mute						
79	G4	G6			Cuica Open						
80	G#4	G#6	2		Triangle Mute						
81	A4	A6	2		Triangle Open						
82	A#4	A#6			Shaker						
83	B4	B6			Jingle Bells						
84	C5	C7			Bell Tree						
85	C#5	(C#7)									
86	D5	(D7)									
87	D#5	(D#7)									
88	E5	(E7)									
89	F5	(F7)									
90	F#5	(F#7)									
91	G5	(G7)									

Same as Standard Kit 1

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-609	○	○	○	○	○ (Live!)
CVP-605	○	○	○	○	○

		Electro Kit		Analog Kit		Dance Kit		Jazz Kit		Brush Kit	
Bank Select MSB (0-127)		127		127		127		127		127	
Bank Select LSB (0-127)		0		0		0		0		0	
Program Change (0-127)		24		25		27		32		40	
Program Change (1-128)		25		26		28		33		41	
MIDI	Keyboard	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp
Note#	Note	(*1)	(*2)	Off	Grp	Off	Grp	Off	Grp	Off	Grp
13	C#-1	C#1									
14	D-1	D1									
15	D#-1	D#1									
16	E-1	E1									
17	F-1	F1									
18	F#-1	F#1									
19	G-1	G1									
20	G#-1	G#1									
21	A-1	A1									
22	A#-1	A#1									
23	B-1	B1									
24	C0	C2									
25	C#0	C#2									
26	D0	D2									
27	D#0	D#2									
28	E0	E2	Reverse Cymbal	●	Reverse Cymbal	●	Reverse Cymbal	●			
29	F0	F2									
30	F#0	F#2	Hi Q 2		Hi Q 2		Hi Q 2				
31	G0	G2	Snare Snappy Electro		Snare Noisy 4		Snare Techno		Snare Jazz H		Brush Slap 2
32	G#0	G#2					Snare Dance 1				
33	A0	A2	Kick 3		Kick 3		Kick Techno Q				
34	A#0	A#2					Rim Gate				Open Rim Shot Light
35	B0	B2	Kick Gate		Kick Analog Short		Kick Techno L				
36	C1	C3	Kick Gate Heavy		Kick Analog		Kick Techno		Kick Jazz		Kick Jazz
37	C#1	C#3			Side Stick Analog		Side Stick Analog		Side Stick Light		Side Stick Light
38	D1	D3	Snare Noisy 2		Snare Analog		Snare Clap		Snare Jazz L		Brush Slap 3
39	D#1	D#3					Dance Clap				
40	E1	E3	Snare Noisy 3		Snare Analog 2		Snare Dry		Snare Jazz M		Brush Tap 2
41	F1	F3	Tom Electro 1		Tom Analog 1		Tom Analog 1				Tom Brush 1
42	F#1	F#3			Hi-Hat Closed Analog	1	Hi-Hat Closed 3	1			
43	G1	G3	Tom Electro 2		Tom Analog 2		Tom Analog 2				Tom Brush 2
44	G#1	G#3			Hi-Hat Closed Analog 2	1	Hi-Hat Closed Analog 3	1			
45	A1	A3	Tom Electro 3		Tom Analog 3		Tom Analog 3				Tom Brush 3
46	A#1	A#3			Hi-Hat Open Analog	1	Hi-Hat Open 3	1			
47	B1	B3	Tom Electro 4		Tom Analog 4		Tom Analog 4				Tom Brush 4
48	C2	C4	Tom Electro 5		Tom Analog 5		Tom Analog 5				Tom Brush 5
49	C#2	C#4			Crash Analog		Crash Analog				
50	D2	D4	Tom Electro 6		Tom Analog 6		Tom Analog 6				Tom Brush 6
51	D#2	D#4									
52	E2	E4									
53	F2	F4									
54	F#2	F#4					Tambourine Analog				
55	G2	G4									
56	G#2	G#4			Cowbell Analog		Cowbell Dance				
57	A2	A4									
58	A#2	A#4					Vibraslap Analog				
59	B2	B4					Ride Analog				
60	C3	C5					Bongo Analog H				
61	C#3	C#5					Bongo Analog L				
62	D3	D5			Conga Analog H		Conga Analog H				
63	D#3	D#5			Conga Analog M		Conga Analog M				
64	E3	E5			Conga Analog L		Conga Analog L				
65	F3	F5									
66	F#3	F#5									
67	G3	G5									
68	G#3	G#5									
69	A3	A5									
70	A#3	A#5			Maracas 2		Maracas 2				
71	B3	B5									
72	C4	C6									
73	C#4	C#6									
74	D4	D6									
75	D#4	D#6			Claves 2		Claves 2				
76	E4	E6					Dance Perc 3				
77	F4	F6					Dance Perc 4	●			
78	F#4	F#6	Scratch H 2		Scratch H 2		Dance Breath 1				
79	G4	G6	Scratch L 2		Scratch L 2		Dance Breath 2	●			
80	G#4	G#6									
81	A4	A6									
82	A#4	A#6									
83	B4	B6									
84	C5	C7									
85	C#5	(C#7)									
86	D5	(D7)									
87	D#5	(D#7)									
88	E5	(E7)									
89	F5	(F7)									
90	F#5	(F#7)									
91	G5	(G7)									

Same as Standard Kit 1

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-609	○ (Live!)	○ (Live!)	○	○	○
CVP-605	—	○	○	○	○

CVP-609		CVP-605		Real Brushes	Symphony Kit	Hip Hop Kit	Break Kit	Analog T8 Kit			
Bank Select MSB (0-127)	127	0	0	42	49	57	58	59			
Bank Select LSB (0-127)	0	0	0	41	48	56	57	58			
Program Change (0-127)	41	48	56	57	58	59	58	59			
Program Change (1-128)	42	49	57	58	59	58	59	59			
MIDI	Keyboard	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp		
Note#	Note	Note	Note	Note	Note	Note	Note	Note	Note		
13	C#-1	C#1									
14	D-1	D1									
15	D#-1	D#1									
16	E-1	E1									
17	F-1	F1									
18	F#-1	F#1									
19	G-1	G1									
20	G#-1	G#1				Hi-Hat Closed T8 2	4		Snare Hammer		
21	A-1	A1				Tom T8 3		Snare Break 8	Kick ZapHard		
22	A#-1	A#1				Hi-Hat Open T8 2	4	Snare Break 9	Snare Garg L		
23	B-1	B1	Vintage Tip			Tom T8 6		Hi-Hat Closed Break 1	Kick TekPower		
24	C0	C2	Vintage Swirl 1	●		Crash T8		Hi-Hat Closed Break 2	Kick Slimy		
25	C#0	C#2	Vintage Slap 1			Triangle Mute	1	Kick Break Deep	Kick T8 1		
26	D0	D2	Vintage Swirl 2	●		Triangle Open	1	Snare Hip	Snare Analog CR		
27	D#0	D#2	Vintage Slap 2			Bell Tree		Snare Lo-Fi	Snare T8 4		
28	E0	E2	Vintage Tap Swirl	●		Tambourine RX5		Snare Clappy	Snare Clap Analog		
29	F0	F2	Vintage Slap Swirl	●		Tambourine RX5 2		Snare LdwH Mono	Snare T8 5		
30	F#0	F#2	Vintage Swirl 3	●		Kick HipHop 9		Snare Rock Roll	Tom T8 3		
31	G0	G2	Vintage Slap 3	●		Hi-Hat Closed Tek	3	Snare Gate 1	Snare T8 5		
32	G#0	G#2				Kick Gate		Snare Mid	Kick T8 3		
33	A0	A2	Kick Soft L		Kick Soft 2	Hi-Hat Open Lo-Fi	3	Snare Break Rim	Snare T8 4		
34	A#0	A#2	Open Rim Shot Real Brushes			Kick Gran Casa Open		Kick Break Heavy	Kick T8 2		
35	B0	B2	Kick Soft H		Gran Cassa	Hi-Hat Reverse Drum&Bass		Snare Hip Rim 4	Snare T8 3		
36	C1	C3	Kick Jazz Ambience		Gran Cassa Mute	Kick HipHop 1		Kick Break 2	T8 Kick Bass		
37	C#1	C#3	Stick Brushse			Kick Analog CR		Kick Break 1	Kick T8 1		
38	D1	D3	Vintage Slap 4			Snare Analog Sm Rim		Snare Hip Rim 1	Snare T8 Rim		
39	D#1	D#3	Clap Power			Snare HipHop 1		Snare Break 3	Snare T8 2		
40	E1	E3	Vintage Slap 5			Snare Clappy		Snare Break 1	Clap T9		
41	F1	F3	Tom Real Brushes 1		Band Snare 2	Snare HipHop 2		Snare Break 2	Snare T8 1		
42	F#1	F#3	Hi-Hat Closed Real Brushes	1		Tom Break 1		Tom Break 1	Tom T8 1		
43	G1	G3	Tom Real Brushes 2			Hi-Hat Closed Hip	2	Hi-Hat Closed Rock Soft	1	Hi-Hat Closed T8	1
44	G#1	G#3	Hi-Hat Pedal Real Brushes	1		Low Tom		Tom Break 2	Tom T8 2		
45	A1	A3	Tom Real Brushes 3			Hi-Hat Pedal Hip	2	Hi-Hat Pedal Rock	1	Hi-Hat Pedal T8	1
46	A#1	A#3	Hi-Hat Open Real Brushes	1		Mid Tom L		Tom Break 3	Tom T8 3		
47	B1	B3	Tom Real Brushes 4			Hi-Hat Open Hip	2	Hi-Hat Half Open Rock	1	Hi-Hat Open T8	1
48	C2	C4	Tom Real Brushes 5			High Tom		Tom Break 4	Tom T8 4		
49	C#2	C#4	Crash Cymbal Real Brushes		Hand Cymbal	Ride Cymbal 3		Tom Break 5	Tom T8 6		
50	D2	D4	Tom Real Brushes 6			Crash Cymbal 3		Crash Cymbal 2	Crash T8		
51	D#2	D#4	Ride Cymbal Real Brushes		Hand Cymbal Short	Shaker 2		Tom Break 6	Tom T8 7		
52	E2	E4	CHINE CYM Real Brushes			Scratch Bass Drum Forward		Ride Cymbal 3	Ride T9		
53	F2	F4	Ride Cup Real Brushes			Scratch Bass Drum Reverse		Chinese Cymbal 2	Chinese Cymbal 2		
54	F#2	F#4				Kick HipHop 2		Ride Cymbal Cup 2	Ride Cymbal Cup 2		
55	G2	G4	Splash Cymbal Real Brushes			Snare HipHop Rim 2		Tambourine 1 Hit	Tambourine RX5		
56	G#2	G#4				HipHop Clap 2		Crash Cymbal 3			
57	A2	A4	Crash Cymbal Real Brushes		Hand Cymbal 2	HipHop Snap 1		Cowbell 1	Cowbell T8		
58	A#2	A#4				Snare HipHop 3			Crash Cymbal 4		
59	B2	B4	Ride Cup Real Brushes		Hand Cymbal Short 2	Electric Clap 2		Cowbell RX11			
60	C3	C5				Kick Hip Deep					
61	C#3	C#5				Kick HipHop 3					
62	D3	D5				Snare HipHop Rim 3			Conga T8 5		
63	D#3	D#5				Snare HipHop 5			Conga T8 4		
64	E3	E5				Electric Clap 1			Conga T8 3		
65	F3	F5				Conga H Tip			Conga T8 2		
66	F#3	F#5				Conga H Open Slap			Conga T8 1		
67	G3	G5				Handbell H					
68	G#3	G#5				Kick HipHop 4					
69	A3	A5				HipHop Clap 3			Bongo 2 H		
70	A#3	A#5				HipHop Snap 2			Bongo 2 L		
71	B3	B5				Snare HipHop Rim 5			Conga Open		
72	C4	C6				HipHop flex 1			Glass H		
73	C#4	C#6				HipHop flex 2			Glass L		
74	D4	D6				Shaker 2					
75	D#4	D#6				Kick HipHop 5			Maracas Slur		
76	E4	E6				Snare HipHop Rim 4			Timbale H		
77	F4	F6				Snare HipHop 6			Timbale L		
78	F#4	F#6				Snare HipHop 11			Scratch H 2		
79	G4	G6				Kick HipHop 10			Scratch Down		
80	G#4	G#6				Snare HipHop 7			Clave		
81	A4	A6				Hi-Hat Closed Break 3			Clave		
82	A#4	A#6				HipHop Clap 7			Hi Q 1		
83	B4	B6				Snare T8 1			Hi Q 2		
84	C5	C7				Snare T8 1 H			Scratch L		
85	C#5 (C#7)	(C#7)				HipHop Clap 7			Scratch L 2		
86	D5 (D7)	(D7)				Snare T8 1					
87	D#5 (D#7)	(D#7)				Snare T8 1 H					
88	E5 (E7)	(E7)				HipHop Clap 7					
89	F5 (F7)	(F7)				Snare T8 1					
90	F#5 (F#7)	(F#7)				Hi-Hat Closed T8 2					
91	G5 (G7)	(G7)				Tom T8 2					

Same as Standard Kit 1

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-609	○	○	○	○ (Live!)	—
CVP-605	○	—	—	○	○

		Analog T9 Kit		House Kit		Drum Machine		Studio Kit		Power Kit 1	
Bank Select MSB (0-127)		127		127		127		127		127	
Bank Select LSB (0-127)		0		0		0		0		0	
Program Change (0-127)		59		60		61		86		87	
Program Change (1-128)		60		61		62		87		88	
MIDI	Keyboard	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp
Note#	Note	(*1)	(*2)	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp
13	C#-1	C#1				W Kick	●				
14	D-1	D1				Disco Fx	●				
15	D#-1	D#1				White Noise Down 1	●				
16	E-1	E1				Pink Noise Down 1	●				
17	F-1	F1				White Noise Down 2	● 4				
18	F#-1	F#1				Pink Noise Down 2	● 4				
19	G-1	G1	Snare Drum&Bass 1			White Noise Up 2	●	Snare Drum&Bass 1			
20	G#-1	G#1	Kick Break 2			White Noise Up 1	●	Kick Break 2			
21	A-1	A1	Snare Distortion			Pink Noise Up	●	Snare Distortion			
22	A#-1	A#1	Kick TekPower			White Noise Up Release	●	Kick TekPower			
23	B-1	B1	Kick Distortion RM			Pink Noise Up Release	●	Kick Distortion RM			
24	C0	C2	Kick T9 2			Kick T9 4		Bass Drum Hard Long			
25	C#0	C#2	Snare Analog CR			Snare T8 Rim		Bass Drum TekPower			
26	D0	D2	Snare T9 5			Snare T8 5		Bass Drum Distortion 5			
27	D#0	D#2	Clap Analog Sm			Hand Clap		Bass Drum Distortion 3			
28	E0	E2	Snare T9 Gate			Snare Garg L		Bass Drum Distortion 1	●		
29	F0	F2	Snare Rock Roll	●				Bass Drum Drum&Bass 1			
30	F#0	F#2	Snare T9 3			Snare T9 3		Bass Drum Blip			
31	G0	G2	Snare T9 4			Snare T8 1		Bass Drum Analog Sm		Snare Studio L	Snare Soft Power 1
32	G#0	G#2	Snare T9 Gate			Snare T9 5		Kick T8 2			
33	A0	A2	Kick T9 4			Kick T9 1		Kick T8 3		Kick Amb H	Kick Amb+
34	A#0	A#2	Snare T9 5			Snare T9 Gate		Kick T9 HD 3			Open Rim Power 1
35	B0	B2	Kick T9 1			Kick T9 2		Kick T9 2		Kick Amb L	Kick Power Open
36	C1	C3	Kick T9 3			Kick T9 5		Kick T9 4		Kick Studio	Kick Power Closed
37	C#1	C#3	Snare T9 Rim			Snare T9 Rim		Snare T9 Rim			Side Stick Power
38	D1	D3	Snare T9 1			Snare T9 1		Snare T9 1		Snare Studio M	Snare Power
39	D#1	D#3	Clap T9			Clap T9		Clap T9			Hand Clap Power
40	E1	E3	Snare T9 2			Snare T9 2		Snare T9 4		Snare Studio L	Snare Rough
41	F1	F3	Tom T9 1			Tom T9 1		Tom T9 1			Tom Power 1
42	F#1	F#3	Hi-Hat Closed T9	1		Hi-Hat Closed T8	1	Hi-Hat Closed T9	1		Hi-Hat Closed Power
43	G1	G3	Tom T9 2			Tom T9 2		Tom T9 2			Tom Power 2
44	G#1	G#3	Hi-Hat Pedal T9	1		Hi-Hat Pedal T9	1	Hi-Hat Pedal T9	1		Hi-Hat Pedal Power
45	A1	A3	Tom T9 3			Tom T9 3		Tom T9 3			Tom Power 3
46	A#1	A#3	Hi-Hat Open T9	1		Hi-Hat Open T9	1	Hi-Hat Open T9	1		Hi-Hat Open Power
47	B1	B3	Tom T9 4			Tom T9 4		Tom T9 4			Tom Power 4
48	C2	C4	Tom T9 5			Tom T9 5		Tom T9 5			Tom Power 5
49	C#2	C#4	Crash T9			Crash T9		Crash T9			
50	D2	D4	Tom T9 6			Tom T9 6		Conga T8 1			Tom Power 6
51	D#2	D#4	Ride T9			Ride T9		Ride T9			
52	E2	E4	Chinese Cymbal 2			Crash Cymbal 4		Conga T8 2			
53	F2	F4	Ride Cymbal Cup 2			Ride Cymbal Cup 2		Analog Click			
54	F#2	F#4	Tambourine RX5			Tambourine Hit		Clave T8 1			
55	G2	G4	Crash Cymbal 3			Crash Cymbal 3		Maracas T8			
56	G#2	G#4	Cowbell 1			Cowbell 1		Tambourine Analog CR			
57	A2	A4	Crash Cymbal 4					Analog Shaker			
58	A#2	A#4	Cowbell T8			Cowbell T8		Cowbell T8			
59	B2	B4	Ride Cymbal 3			Ride Cymbal 3		Cowbell Analog CR			
60	C3	C5	Conga T8 5			Bongo H Open 1 finger		Snare T8 1			
61	C#3	C#5	Conga T8 4			Bongo L Open 3 finger		Snare T8 2			
62	D3	D5	Conga Tip			Conga High Tip		Snare T8 3			
63	D#3	D#5	Conga Open Slap			Conga High Slap Open		Snare Analog CR			
64	E3	E5	Conga Open			Conga High Open 2		Snare Jungle 1			
65	F3	F5						Snare D&B 1			
66	F#3	F#5						Snare Hip 1			
67	G3	G5	Analog Click					Snare R&B 1			
68	G#3	G#5	Conga T8 1					Snare R&B 2			
69	A3	A5				Cabasa 1		Snare Hip 1			
70	A#3	A#5	Maracas Slur			Maracas Slur		Snare Wood			
71	B3	B5	FxGun 2	●		Vox Drum L		Snare Timbre			
72	C4	C6	FxGun 1	●		Vox Drum H		Hi-Hat Closed T8 1	5		
73	C#4	C#6	Scratch H 2	●				Hi-Hat Open T8 1	5		
74	D4	D6	Scratch Down	●				Hi-Hat Closed T8 2	6		
75	D#4	D#6	Hi Q 3					Hi-Hat Open T8 2	6		
76	E4	E6	Hi Q 1					Hi-Hat Pedal Acoustic	7		
77	F4	F6	Hi Q 2					Hi-Hat Closed Acoustic	7		
78	F#4	F#6	Scratch L			Cuica H		Hi-Hat Open Acoustic	7		
79	G4	G6	Scratch L 2			Cuica L		Hi-Hat Closed Lo-Fi	2		
80	G#4	G#6						Hi-Hat Open Lo-Fi	2		
81	A4	A6						Hi-Hat Closed Syn	8		
82	A#4	A#6	Analog Shaker			Analog Shaker		Hi-Hat Open Syn	8		
83	B4	B6	Sleigh Bell			Sleigh Bell		Analog Shaker			
84	C5	C7				Wind Chime		Tambourine RX5			
85	C#5	(C#7)	Snare Piccolo			Snare Break Roll		Tambourine RX5			
86	D5	(D7)	Snare T8 5			Noise Burst		Electric Cow			
87	D#5	(D#7)	Snare Rock Roll Distortion			Vox Bell		Conga T8 3			
88	E5	(E7)	Snare Brush Mute			Snare R&B 1		Electric Triangle			
89	F5	(F7)	Kick Blip Hard			Vox Aik		Clave T8 2			
90	F#5	(F#7)	Snare Jungle 1			Udu High		Analog Shaker			
91	G5	(G7)	Kick Sustain			Filter Kick		Electric Clap 1			

Same as Standard Kit 1

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-609		—	○ (Live!)	○ (Live!)	○ (Live!)	○ (Live!)					
CVP-605		○	—	—	○	○					
Bank Select MSB (0-127)		PowerKit2		Live! Power Kit 1		Live! Power Kit 2		Acoustic Kit		Rock Kit	
127		127		127		127		127		127	
0		0		0		0		0		0	
88		88		88		88		89		90	
89		88		89		89		90		91	
MIDI	Keyboard	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp
Note#	Note	(*1)	(*2)	Off	Grp	Off	Grp	Off	Grp	Off	Grp
13	C#-1										
14	D-1										
15	D#-1										
16	E-1										
17	F-1										
18	F#-1										
19	G-1										
20	G#-1										
21	A-1										
22	A#-1										
23	B-1										
24	C0										
25	C#0										
26	D0										
27	D#0										
28	E0										
29	F0										
30	F#0										
31	G0										
32	G#0										
33	A0										
34	A#0										
35	B0										
36	C1										
37	C#1										
38	D1										
39	D#1										
40	E1										
41	F1										
42	F#1										
43	G1										
44	G#1										
45	A1										
46	A#1										
47	B1										
48	C2										
49	C#2										
50	D2										
51	D#2										
52	E2										
53	F2										
54	F#2										
55	G2										
56	G#2										
57	A2										
58	A#2										
59	B2										
60	C3										
61	C#3										
62	D3										
63	D#3										
64	E3										
65	F3										
66	F#3										
67	G3										
68	G#3										
69	A3										
70	A#3										
71	B3										
72	C4										
73	C#4										
74	D4										
75	D#4										
76	E4										
77	F4										
78	F#4										
79	G4										
80	G#4										
81	A4										
82	A#4										
83	B4										
84	C5										
85	C#5										
86	D5										
87	D#5										
88	E5										
89	F5										
90	F#5										
91	G5										

Same as Standard Kit 1

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-609		○ (Live!)		○		○		○ (Live!)		○ (Live!)	
CVP-605		○		○		○		—		—	
Bank Select MSB (0-127)		127		126		126		126		126	
Bank Select LSB (0-127)		0		0		0		0		0	
Program Change (0-127)		91		0		1		2		3	
Program Change (1-128)		92		1		2		3		4	
MIDI		Keyboard		Key Off (*1)		Alt Grp (*2)		Key Off		Alt Grp	
Note#	Note	Note				Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp
13	C#-1	C#1									
14	D-1	D1									
15	D#-1	D#1									
16	E-1	E1									
17	F-1	F1									
18	F#-1	F#1									
19	G-1	G1									
20	G#-1	G#1									
21	A-1	A1									
22	A#-1	A#1									
23	B-1	B1									
24	C0	C2									
25	C#0	C#2									
26	D0	D2	Brush Swirl 2			●					
27	D#0	D#2									
28	E0	E2									
29	F0	F2	Snare Roll Rock			●					
30	F#0	F#2									
31	G0	G2	SnareTight								
32	G#0	G#2									
33	A0	A2	Kick Genuine								
34	A#0	A#2	Rim Real								
35	B0	B2	Kick Real 1								
36	C1	C3	Kick Real 2				Cutting Noise	●	Phone Call	●	Cutting Noise
37	C#1	C#3	Stick Real				Cutting Noise 2	●	Door Squeak	●	Cutting Noise 2
38	D1	D3	Snare Real 1					●	Door Slam	●	Door Slam 2
39	D#1	D#3	Clap Power				String Slap	●	Scratch Cut	●	String Slap
40	E1	E3	Snare Real 2					●	Scratch H 3	●	Scratch H 3
41	F1	F3	Tom Real 1					●	Wind Chime	●	Wind Chime
42	F#1	F#3	Hi-Hat Closed Real			1		●	Telephone Ring 2	●	Telephone Ring 2
43	G1	G3	Tom Real 2								
44	G#1	G#3	Hi-Hat Pedal Real			1					
45	A1	A3	Tom Real 3								
46	A#1	A#3	Hi-Hat Open Real			1					
47	B1	B3	Tom Real 4								
48	C2	C4	Tom Real 5								
49	C#2	C#4	Crash Cymbal Real 1								
50	D2	D4	Tom Real 6								
51	D#2	D#4	Ride Cymbal Real 1								
52	E2	E4	CHINE CYM Real				Flute Key Click	●	Car Engine Ignition	●	Flute Key Click
53	F2	F4	Ride Cup Real					●	Car Tires Squeal	●	Car Tires Squeal
54	F#2	F#4						●	Car Passing	●	Car Passing
55	G2	G4	Splash Cymbal Real					●	Car Crash	●	Car Crash
56	G#2	G#4						●	Siren	●	Siren 2
57	A2	A4	Crash Cymbal Real 2					●	Train	●	Train 2
58	A#2	A#4						●	Jet Plane	●	Jet Plane 2
59	B2	B4	Ride Cymbal Real 2					●	Starship	●	Starship
60	C3	C5						●	Burst	●	Burst
61	C#3	C#5						●	Roller Coaster	●	Roller Coaster
62	D3	D5						●	Submarine	●	Submarine
63	D#3	D#5									
64	E3	E5									
65	F3	F5									
66	F#3	F#5									
67	G3	G5									
68	G#3	G#5					Shower	●	Laugh	●	Shower 2
69	A3	A5					Thunder	●	Scream	●	Thunder 2
70	A#3	A#5					Wind	●	Punch	●	Wind 2
71	B3	B5					Stream	●	Heart Beat	●	Stream 2
72	C4	C6					Bubble	●	Foot Steps	●	Bubble 2
73	C#4	C#6					Feed	●		●	Feed
74	D4	D6									
75	D#4	D#6									
76	E4	E6									
77	F4	F6									
78	F#4	F#6									
79	G4	G6									
80	G#4	G#6									
81	A4	A6									
82	A#4	A#6									
83	B4	B6									
84	C5	C7					Dog	●	Machine Gun	●	Dog
85	C#5	(C#7)					Horse	●	Laser Gun	●	Horse
86	D5	(D7)					Bird Tweet 2	●	Explosion	●	Bird Tweet 2
87	D#5	(D#7)						●	Firework	●	Firework
88	E5	(E7)									
89	F5	(F7)									
90	F#5	(F#7)					Ghost	●		●	Ghost
91	G5	(G7)					Maou	●		●	Maou

Same as Standard Kit 1

*Actual Keyboard Notes are one octave lower than the ones described in the above list.

*1 Key Off: Keys marked ● stop sounding the instant they are released.

No Sound

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

CVP-609		○	○	○ (Live!)	○ (Live!)	○ (Live!)						
CVP-605		○	○	○	○	○						
Bank Select MSB (0-127)		Noises Kit		Arabic Kit		Cuban Kit		Pop Latin Kit		Turkish Kit		
Bank Select LSB (0-127)		126		126		126		126		126		
Program Change (0-127)		0		0		0		0		0		
Program Change (1-128)		8		35		40		43		67		
MIDI		9		36		41		44		68		
Note#	Note	Keyboard Note	Key Off (*1)	Alt Grp (*2)	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp	Key Off	Alt Grp
13	C#-1	C#1										
14	D-1	D1										
15	D#-1	D#1										
16	E-1	E1										
17	F-1	F1										
18	F#-1	F#1										
19	G-1	G1										
20	G#-1	G#1										
21	A-1	A1										
22	A#-1	A#1										
23	B-1	B1										
24	C0	C2										
25	C#0	C#2										
26	D0	D2										
27	D#0	D#2										
28	E0	E2										
29	F0	F2										
30	F#0	F#2										
31	G0	G2										
32	G#0	G#2										
33	A0	A2										
34	A#0	A#2										
35	B0	B2										
36	C1	C3	White Noise	●								
37	C#1	C#3	Pink Noise	●								
38	D1	D3	White Noise Down 1	●								
39	D#1	D#3	White Noise Down 2	●								
40	E1	E3	White Noise Up 1	●								
41	F1	F3	White Noise Up 2	●								
42	F#1	F#3	White Noise Up 3	●								
43	G1	G3	White Noise Up Release	●								
44	G#1	G#3	Pink Noise Up	●								
45	A1	A3	Pink Noise Up Release	●								
46	A#1	A#3	Pink Noise Up LFO	●								
47	B1	B3	Pink Noise Up LFO	●								
48	C2	C4										
49	C#2	C#4										
50	D2	D4										
51	D#2	D#4										
52	E2	E4										
53	F2	F4										
54	F#2	F#4										
55	G2	G4										
56	G#2	G#4										
57	A2	A4										
58	A#2	A#4										
59	B2	B4										
60	C3	C5										
61	C#3	C#5										
62	D3	D5										
63	D#3	D#5										
64	E3	E5										
65	F3	F5										
66	F#3	F#5										
67	G3	G5										
68	G#3	G#5										
69	A3	A5										
70	A#3	A#5										
71	B3	B5										
72	C4	C6										
73	C#4	C#6										
74	D4	D6										
75	D#4	D#6										
76	E4	E6										
77	F4	F6										
78	F#4	F#6										
79	G4	G6										
80	G#4	G#6										
81	A4	A6										
82	A#4	A#6										
83	B4	B6										
84	C5	C7										
85	C#5	(C#7)										
86	D5	(D7)										
87	D#5	(D#7)										
88	E5	(E7)										
89	F5	(F7)										
90	F#5	(F#7)										
91	G5	(G7)										

Same as Standard Kit 1

1 Key Off: Keys marked ● stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-609	○ (Live!)	○ (Live!)
CVP-605	—	—

		Vocal Effects Kit		Gospel AdLibs	
Bank Select MSB (0-127)		126		126	
Bank Select LSB (0-127)		0		0	
Program Change (0-127)		109		110	
Program Change (1-128)		110		111	
MIDI	Keyboard	Key Off	Alt Grp	Key	Alt
Note#	Note	(*1)	(*2)	Off	Grp
13	C#-1	C#1			
14	D-1	D1			
15	D#-1	D#1			
16	E-1	E1			
17	F-1	F1			
18	F#-1	F#1			
19	G-1	G1			
20	G#-1	G#1			
21	A-1	A1			
22	A#-1	A#1			
23	B-1	B1			
24	C0	C2			
25	C#0	C#2			
26	D0	D2			
27	D#0	D#2			
28	E0	E2			
29	F0	F2			
30	F#0	F#2			
31	G0	G2			
32	G#0	G#2			
33	A0	A2			
34	A#0	A#2			
35	B0	B2			
36	C1	C3	Male "Ha" 01	●	
37	C#1	C#3	Female "Ha" 01	●	
38	D1	D3	Male "Ha" 02	●	
39	D#1	D#3	Male "Ha" 03	●	
40	E1	E3	Male "Bh" 01	●	
41	F1	F3	Female "Bh" 01	●	
42	F#1	F#3	Male "Kh" 01	●	
43	G1	G3	Female "Kh" 01	●	
44	G#1	G#3	Male "Ph" 01	●	
45	A1	A3	Female "Ph" 01	●	
46	A#1	A#3	Male "Th" 01	●	
47	B1	B3	Female "Th" 01	●	
48	C2	C4	Male "Bh" 02	●	C'mon
49	C#2	C#4	Female "Bh" 02	●	Hoo!
50	D2	D4	Male "Kh" 02	●	Aha!
51	D#2	D#4	Female "Kh" 02	●	Oh Yeah
52	E2	E4	Male "Ph" 02	●	Yayayayah
53	F2	F4	Female "Ph" 02	●	Put Your Hands Together
54	F#2	F#4	Male "Th" 02	●	C'mon Now
55	G2	G4	Female "Th" 02	●	Heeey
56	G#2	G#4	Male "Ha" 04	●	Everybody Now
57	A2	A4	Female "Ha" 02	●	Clap Your Hands, Everybody C'mon
58	A#2	A#4	Male "Ha" 05	●	With All Your Soul
59	B2	B4	Male "Ha" 06	●	Stand Up On Your Feet
60	C3	C5	Male "Bh" 03	●	Uhh Yeah
61	C#3	C#5	Female "Bh" 03	●	Aaoh
62	D3	D5	Male "Kh" 03	●	Come On!
63	D#3	D#5	Female "Kh" 03	●	Yeah!
64	E3	E5	Male "Ph" 03	●	Alright Now!
65	F3	F5	Female "Ph" 03	●	One
66	F#3	F#5	Male "Th" 03	●	Two
67	G3	G5	Female "Th" 03	●	Three
68	G#3	G#5	Male "Bh" 04	●	Four
69	A3	A5	Female "Bh" 04	●	One!
70	A#3	A#5	Male "Kh" 04	●	Two!
71	B3	B5	Female "Kh" 04	●	Three!
72	C4	C6	Male "Ph" 04	●	Four!
73	C#4	C#6	Female "Ph" 04	●	Five!
74	D4	D6	Male "Th" 04	●	Six!
75	D#4	D#6	Female "Th" 04	●	Seven!
76	E4	E6			Eight!
77	F4	F6			Clap!
78	F#4	F#6			Gospel Clap 1
79	G4	G6			Gospel Clap 2
80	G#4	G#6			
81	A4	A6			
82	A#4	A#6			
83	B4	B6			
84	C5	C7			
85	C#5	(C#7)			
86	D5	(D7)			
87	D#5	(D#7)			
88	E5	(E7)			
89	F5	(F7)			
90	F#5	(F#7)			
91	G5	(G7)			

No Sound

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

Style List / Liste der Styles / Liste des styles / Lista de estilos

CVP-609

Category	Sub Category	Style Name	
Pop&Rock	Pop	Standard 8Beat	
		Easy Pop	
		Cool 8Beat	
		Jersey Pop	
		Classic 8Beat	
		West Coast Pop	
		Live 8Beat	
		Contemp Pop	
		Uptempo 8Beat	
		Straight 8Pop	
		00s Boy Band	
		Pop Evergreen	
		80s Boy Band	
		Pop Shuffle	
		80s Pop	
		90s Guitar Pop	
		80s Guitar Pop	
		90s Pop Shuffle	
		80s 8Beat	
		Classic 16Beat	
		Chart Guitar Pop	
		Brit Pop	
		Chart Piano Shfl	
		Brit Pop Swing	
		Chart Rock Shfl	
		8Beat Modern	
		Chart Pop 1	
		8Beat Gtr Pop	
		Chart Pop 2	
		8Beat	
		Scand Pop Shuffle	
		Rock	Stadium Rock
			80s Pop Rock
			Hard Rock
			80s Power Rock
			Contemp Rock
			80s Synth Rock
			Acoustic Rock
			Standard Rock
			Brit Rock Pop
			Funk Pop Rock
			Power Rock
			Caribbean Rock
	Slow Rock		
	Rock Shuffle		
	Soft Rock		
	70s Pop& Rock		70s Piano Rock
			70s Pop Duo 1
			70s Glam Piano
			70s Pop Duo 2
			70s Cool Ballad
			70s Rock
			70s Easy Pop
			70s Rock Bros
			70s Swing Piano
		70s Rock Shuffle	
		70s 8Beat	
		Glam Piano Rock	
		Vintage Gtr Pop	
		Croco Twist	
		60s Pop& Rock	60s Rising Pop
			Surf Rock
			60s Underground
	Beach Rock		
	60s Vintage Pop		
	Bubblegum Pop		
	60s Vintage Rock		
60s Piano Pop			
60s Pop Rock			
60s Chart Swing			

Category	Sub Category	Style Name	
Pop&Rock	60s Pop& Rock	60s Guitar Pop	
		60s 8Beat	
		60s Rock & Roll	
		50s Rock& Roll	50s Rock & Roll
			Skiffle
			Rock & Roll 1
	Oldies R&R		
	Rock & Roll 2		
	Piano R&R		
	Rock & Roll Shfl		
	Pop& Rock Ballad		Boy Band Ballad
			Vocal Pop Ballad
			70s Piano Pop Bld
			Acoustic 8Bt Bld
		70s R&B Pop Bld	
		Modern 16Bt Bld	
		70s Chart Ballad	
		Orch Rock Ballad	
		Mod 6-8 Piano Bld	
		Big Rock Ballad	
		80s Analog Ballad	
		80s Movie Ballad	
		80s EP Ballad	
		90s Cool Ballad	
		80s Smooth Bld	
		90s Rock Ballad	
		80s Piano Ballad	
		8Beat Ballad 1	
		80s Synth Piano	
		8Beat Ballad 2	
		Modern Pop Bld	
		Elec Org Ballad	
		Modern Orch Bld	
		EP Ballad	
		Light Ballad	
		Guitar Ballad	
		Epic Ballad	
		Organ Ballad	
	Pop Ballad		
	Piano Ballad		
	Contemp Pop Bld		
	Power Ballad 1		
	Contemp Rock Bld		
	Power Ballad 2		
	Acoustic Ballad		
	Pop Gtr Ballad		
	Chart Ballad		
	Pop Piano Ballad		
	Unplugged		
	Pop Waltz		
	16Beat Ballad		
	Slow & Easy		
	16Beat Pop		
	Slow Orch Bld		
	6-8 Modern		
	Love Song		
	8Beat Piano Ballad		
	Worship	Worship Slow	
		Worship 6-8	
		Worship Med	
		Worship Irish Rk	
		Worship Fast	
	Worship Power Bld		
	Soul	Live Soul Band	
		Detroit Pop 1	
		70s Chart Soul	
		Detroit Pop 2	
Motor City			
Soul Beat			
Frankly Soul			

Category	Sub Category	Style Name
Pop&Rock	Soul	Soul Brothers
		UK Soul Pop
		Soul Shuffle
		Kool Funk
		Kool Shuffle
		Soul
		Lovely Shuffle
	Disco	Pop Legend
		70s Disco 1
		Funk Disco
		70s Disco 2
		Saturday Night
		70s Disco Funk
		Mallorca Disco
		80s Disco
		Movie Disco
		90s Disco
		Disco Fox Rock
		Synth Pop
		Disco House
		80s Synth Disco
		Disco Philly
		Disco Chocolate
		Disco Teens
	Disco Hands	
	Dance	Global DJ's
		Clubdance 1
		Ibiza 2010
		Clubdance 2
		Electronica
		Club House
		Dancefloor
		Funky House
		Dancehall
		Retro Pop
	Dream Dance	
	Deep House Pop	
	French Club	
	Dirty Pop	
	Techno Party	
	Garage	
	Modern R&B	Cool R&B
		New R&B
		Soul R&B
		New R&B Ballad
		R&B Soul Ballad
		Modern R&B
		Chart R&B
		Analog Ballad
		Pop R&B
		Groundbeat
	US Hip Hop	
	Classic Hip Hop	
	Euro Hip Hop	
	Modern Hip Hop	
	New Hip Hop	
	Trip Hop	
	Chill Out	Chill Performer
		Chillout 1
		Coudy Bay
		Chillout 2
		Night Walk
	Chillout Cafe	
	Play 4 Sofa	
	Ethereal Synth	
	Angel Sun	
	Trance	Trance Pop
Celtic Trance		
Euro Trance		
6-8 Trance		

CVP-609

Category	Sub Category	Style Name	
Country& Blues	Modern Country	Country Blues	
		Mod Bluegrass	
		Modern Pickin'	
		Country 8Beat	
		Cali Country	
		Country Hits	
		70s Chart Cntry	
		Country Strum	
		70s Country Pop	
		Country Pop	
		New Country	
		Country Rock	
		Singer Song Writer	
		Country Brothers	
		Modern Cntry Pop	
		Country Straits	
		Hully Gully	
		Trad Country	Bluegrass
			Country 2-4
			Hoedown
	Country Shuffle		
	Pickin' Swing		
	Country Swing 1		
	Easy Country		
	Country Swing 2		
	Cntry Sing-along		
	Country Two Step		
	Finger Pickin'		
	Folk Pop		
	Country Ballad		Country Ballad
			Mod Country Bld 1
		Country Rock Bld	
		Mod Country Bld 2	
	Blues	Country Waltz	
		6-8 Rock	
		Let's Funk	
		6-8 Soul	
		Modern Shuffle	
		Slow Blues	
		Soul Swing	
		Shuffle Blues	
		Piano Blues 1	
		Blues Rock	
		Piano Blues 2	
		Blueberry Blues	
		Gospel	Hollywood Gospel
	Gospel Party		
	Amazing Gospel		
	Gospel Funk		
	Southern Gospel		
	Gospel Brothers		
	Gospel Sisters		
	Gospel Ballad		
	Gospel Swing		

Category	Sub Category	Style Name	
Standards& Jazz	Jazz Combo	Jazz Ballad	
		Boogie Woogie	
		Jazz Club	
		2Beat Swing	
		Big Band	Big Band Jazz
			40s Swing Ballad
			The Jazz Singers
			Classic Big Band
			Modern Big Band
			Swingin' Boogie
			Mod Big Band Shfl
			Moonlight Ballad
			Mod Big Band Bld
			Afro Cuban
	Big Band Fast 1		
	Orch Big Band 1		
	Big Band Fast 2		
	Orch Big Band 2		
	Big Band Med 1		
	Swingin' Big Band		
	Big Band Med 2		
	30s Big Band		
	Jump Jive		
	40s Big Band		
	Orchestra Swing	Orchestra Swing 1	
		Dreamy Ballad	
		Orchestra Swing 2	
		Easy Swing	
		Cool Jazz Ballad	
		MOR Swing	
		Easy Listening	
		Organ Groove	
		Midnight Swing	
		LA Cool Swing	
	Jazz Waltz	Orchestral Ballad	
		Jazz Waltz Slow	
		MOR Waltz	
		Jazz Waltz Med	
		Five-Four	
		Jazz Waltz Fast 1	
		Jazz Waltz	
		Jazz Waltz Fast 2	
		Dixie& Trad Jazz	Saloon Piano
			Ragtime 1
	Stride 1		
	Ragtime 2		
	Stride 2		
	Piano Rag 1		
	Dixieland 1		
	Piano Rag 2		
	Dixieland 2		
	Charleston		
	Fusion	70s Scat Legend	
		Jazz Funk	
Fusion Shuffle			
Jazz Pop			
Entertainment		Movie&Show	Movie Soundtrack
			On Broadway
	Choir Soundtrack		
	Big Screen Classic		
	Ethereal Movie		
	Secret Service		
	Blockbuster		
	Animation Ballad		
	Sci-fi March		
	Ani Fantasy		
	Movie Swing 1		
	Movie Ballad		
	Movie Swing 2		
	Movie Panther		

Category	Sub Category	Style Name	
Entertainment	Movie&Show	Wild West	
		Showtune	
		Tap Dance Swing	
		Musical	
		Broadway Ballad	
		70s TV Theme	
		Easy Listening	Easy Ballad
			6-8 Slow Rock 1
			Classic Piano Bld
			6-8 Slow Rock 2
			Romantic Waltz
			6-8 Orchestral
			Guitar Serenade
			12-8 Ballad
	Romantic Ballad		
	Pop Classics		
	Sing-a-long Piano		
	French 50s		
	Pub Piano		
	Tijuana		
	Piano Orch Ballad		
	Ballroom	Viennese Waltz 1	
		Slowfox	
		Viennese Waltz 2	
		Foxtrot	
		English Waltz	
		Vocal Foxtrot	
		Slow Waltz	
		Swingfox	
		Vocal Waltz	
		Quickstep	
		Tango 1	
		Rumba	
		Tango 2	
		Jive	
	Organ	Pasodoble	
		Beguine	
		Samba	
		Twist	
		Cha Cha Cha	
		Swing Waltz	
		Piano Beguine	
		Piano Cha Cha	
		Piano Rumba	
		9-8 Waltz	
		Euro Pop Organ	
		Organ Cha Cha	
		Organ Bossa	
		Organ Rumba	
	Organ Swing		
	Theatre Foxtrot		
	Organ Quickstep		
	Theatre March		
	Organ Samba		
Theatre Quickstep			
Holiday	Christmas Swing 1		
	Christmas Shuffle		
	Christmas Swing 2		
	Christmas Ballad		
	Christmas Waltz		
	Celtic Xmas		
	Schlager	Disco Fox	
		Schlager Palace	
		German Rock	
		Schlager Fever	
		Mallorca Party	
		Soft Schlager	
		Party Arena	
		Apres Ski Hit	
Alpen Schlager			

CVP-609

Category	Sub Category	Style Name			
Entertainment	Schlager	Synth Pop Duo			
		Alp Ballad 1			
		Schlager 6-8			
		Alp Ballad 2			
		Schlager Alp			
		Schlager Waltz			
		Schlager Beat			
		Schlager Shuffle			
		Schlager Polka			
		Schlager Fox			
		Schlager Rock			
		Scand Country 1			
		70s French Hit			
		Scand Country 2			
		Schlager Italia			
		Scand Shuffle			
		Schlager Pop			
		Scand Slow Rock			
		Schlager Rumba			
		Scand Bugg			
		Schlager Samba			
		Alp Rock			
		Party Polka			
		8Beat Adria			
		Polka Pop			
		Latin&World	Brazil	Jazz Samba	
				Lounge Bossa	
				Brazilian Samba	
				Slow Bar Bossa	
				Bossa Brazil	
				Slow Bossa	
				Fast Bossa	
				Orchestral Bossa	
				Bossa Nova	
				Big Band Samba	
				Piano Bossa	
				Piano Samba	
				Cuba	Salsa
					Big Band Salsa
Cuban Son					
Big Band Mambo					
Guaguanco					
Guitar Rumba					
Danzon					
Guajira					
Mexico	Banda Polka				
	Mariachi Waltz				
	Banda Vals				
	Mexican Dance				
	Norteno				
Bolero Lento					
Caribbean	Bomba				
	Sheriff Reggae				
	Cumbia				
	Happy Reggae				
	Merengue				
	Calypso				
	Bachata				
	Rumba Island				
	Zouk				
	Caribbean				
	Vallenato 4-4				
	European		Flamenco		
Italian Mazurka					
Rumba Flamenco					
Italian Tango					
Pop Flamenco					
Sirtaki					
Spanish Paso					
Tarantella					

Category	Sub Category	Style Name	
Latin&World	Latin Pop	Pop Bossa 1	
		Latin Party Pop	
		Pop Bossa 2	
		Latin Disco 1	
		Pop Latin	
		Latin Disco 2	
		Pop Latin Ballad	
		Rock Cha Cha	
		Pop Rumba	
		Celtic	Celtic Dance 3-4
			Strathspey
			Irish Hymn 1
			Jig
			Irish Hymn 2
			Reel
			Irish Dance
			Scottish Polka
			Celtic Dance
			Scand Schottis
			World
	J-Pop Hit 1		
	Turkish Euro 2		
	J-Pop Hit 2		
	Oriental Pop		
	Hawaiian		
	Classic	String Adagio	
		Choral Symphony	
		String Concerto	
		Classical Menuet	
		Baroque Air	
		Classical Serenad	
		Baroque Concerto	
		Green Fantasia	
		Ethereal Voices	
		Romantic Ballet	
		Arpeggio 1	
		Traditional 1	
		Arpeggio 2	
		Traditional 2	
		Arpeggio 3	
		Traditional 3	
		Orchestral Bolero	
		Moonlight 6-8	
		Orchestral March	
		Ethereal Hymn	
		Nocturne	
		Learning 2-4	
		Trad Waltz	Bohemian Waltz
			German Waltz
			French Waltz
			French Musette
			Highland Waltz
			Alpen Land 3-4
Italian Waltz			
Ober Walzer 1			
Scand Waltz			
Ober Walzer 2			
Scand Hambo			
Waltz			
Piano Slow Waltz			
March&Polka	Ober Polka 1		
	Brass Band Hymn		
	Ober Polka 2		
	Brass Band		
	Zither Polka		
	US March		
	Italian Polka		
	German March 1		
Orchestral Polka			
German March 2			

Category	Sub Category	Style Name
Latin&World	March&Polka	6-8 March
		Piano March 1
		6-8 Piano March
		Piano March 2
		Alpen Land 4-4
4 Stroke		

CVP-605

Category	Sub Category	Style Name	
Pop&Rock	Pop	Standard 8Beat	
		80s Boy Band	
		Cool 8Beat	
		80s Pop	
		Classic 8Beat	
		80s Guitar Pop	
		Live 8Beat	
		90s Guitar Pop	
		Uptempo 8Beat	
		West Coast Pop	
		Chart Guitar Pop	
		Brit Pop	
		Chart Piano Shfl	
		Brit Pop Swing	
		Chart Rock Shfl	
		Classic 16Beat	
		Chart Pop 1	
		8Beat Modern	
		Chart Pop 2	
		8Beat Gtr Pop	
		8Beat	
		Scand Pop Shuffle	
		Rock	Hard Rock
			80s Power Rock
			Standard Rock
			80s Pop Rock
			Contemp Rock
			80s Synth Rock
			Acoustic Rock
			Funk Pop Rock
			Brit Rock Pop
			Power Rock
			Soft Rock
	Rock Shuffle		
	Slow Rock		
	70s Pop& Rock		70s Glam Piano
			70s Pop Duo
			70s Swing Piano
			70s 8Beat
			Glam Piano Rock
			Vintage Gtr Pop
	60s Pop& Rock		60s Vintage Pop
		Bubblegum Pop	
		60s Vintage Rock	
		60s Piano Pop	
		60s Pop Rock	
		60s Guitar Pop	
	50s Rock& Roll	60s 8Beat	
		60s Rock & Roll	
		Rock & Roll 1	
		Skiffle	
		Rock & Roll 2	
		Oldies R&R	
	Pop& Rock Ballad	Rock & Roll Shfl	
		Piano R&R	
		Modern Pop Bld	
		80s EP Ballad	
		Modern 16Bt Bld	
		80s Smooth Bld	
		Mod 6-8 Piano Bld	
		80s Analog Ballad	
		Modern Orch Bld	
		90s Cool Ballad	
		Acoustic 8Bt Bld	
		90s Rock Ballad	
		8Beat Ballad 1	
		EP Ballad	
		8Beat Ballad 2	
		Light Ballad	
		70s Chart Ballad	
		Epic Ballad	
		80s Synth Piano	
		Organ Ballad	
		Contemp Pop Bld	

Category	Sub Category	Style Name		
Pop&Rock	Pop& Rock Ballad	Piano Ballad		
		Pop Ballad		
		Unplugged		
		Pop Gtr Ballad		
		Contemp Rock Bld		
		Pop Piano Ballad		
		Pop Waltz		
		Power Ballad 1		
		16Beat Ballad		
		Power Ballad 2		
		6-8 Modern		
		Love Song		
		8Beat Piano Ballad		
		Worship	Worship Slow	
			Worship Fast	
			Worship Med	
			Worship 6-8	
			Soul	Live Soul Band
				Detroit Pop 1
		70s Chart Soul		
		Detroit Pop 2		
		Frankly Soul		
		Motor City		
		Soul Brothers		
	Lovely Shuffle			
	Kool Funk			
	Kool Shuffle			
	Soul			
	Disco	Funk Disco		
		70s Disco 1		
		Saturday Night		
		70s Disco 2		
		Movie Disco		
		70s Disco Funk		
		Synth Pop		
		80s Disco		
		80s Synth Disco		
		90s Disco		
		Disco Fox Rock		
		Disco House		
		Disco Philly		
		Disco Chocolate		
		Disco Teens		
		Disco Hands		
		Dance	Global DJ's	
			Clubdance 1	
	Ibiza 2010			
	Clubdance 2			
	Electronica			
	Club House			
	Dancefloor			
	Funky House			
	Dancehall			
	Retro Pop			
	Dream Dance			
	Garage			
	Modern R&B		New R&B	
			New R&B Ballad	
		Soul R&B		
		R&B Soul Ballad		
		Chart R&B		
		Groundbeat		
		Analog Ballad		
		US Hip Hop		
		Pop R&B		
		Classic Hip Hop		
		Euro Hip Hop		
		Modern Hip Hop		
		New Hip Hop		
		Trip Hop		
	Chill Out	Chill Performer		
		Angel Sun		
		Coudy Bay		
		Chillout 1		

Category	Sub Category	Style Name		
Pop&Rock	Chill Out	Night Walk		
		Chillout 2		
		Play 4 Sofa		
		Chillout Cafe		
		Trance	Trance Pop	
			Celtic Trance	
			Euro Trance	
			6-8 Trance	
			Country& Blues	Modern Country
	Country 8Beat			
	70s Chart Cntry			
	Country Hits			
	70s Country Pop			
	Country Strum			
	New Country			
	Country Pop			
	Country Brothers			
	Country Rock			
	Modern Cntry Pop			
	Hully Gully			
	Trad Country	Bluegrass		
		Country 2-4		
		Hoedown		
		Country Shuffle		
		Easy Country		
		Country Swing		
		Finger Pickin'		
		Cntry Sing-along		
		Folk Pop		
		Country Two Step		
		Country Ballad		Country Ballad
				Mod Country Bld 1
				Country Rock Bld
				Mod Country Bld 2
				Country Waltz
	Blues			
	Blues	Modern Shuffle		
		6-8 Rock		
		Slow Blues		
		6-8 Soul		
		Shuffle Blues		
		Piano Blues 1		
		Blues Rock		
		Piano Blues 2		
		Blueberry Blues		
		Gospel	Southern Gospel	
			Gospel Brothers	
			Gospel Sisters	
			Gospel Swing	
			Standards& Jazz	Jazz Combo
		Modern Jazz Bld 1		
	Jazz Guitar Club			
	Modern Jazz Bld 2			
	Instrumental Jazz			
	Organ Combo			
	Cool Piano Jazz			
	French Jazz			
	Bebop			
	Piano Boogie			
	Piano Swing 1			
	Jazz Ballad			
	Piano Swing 2			
	Jazz Club			
	Boogie Woogie			
	2Beat Swing			
	Big Band	Classic Big Band		
		Orch Big Band 1		
		Modern Big Band		
		Orch Big Band 2		
		Mod Big Band Shfl		
		Big Band Fast 1		
		Moonlight Ballad		
		Big Band Fast 2		
		Mod Big Band Bld		
		Afro Cuban		


CVP-605

Category	Sub Category	Style Name		
Standards& Jazz	Big Band	Jump Jive		
		40s Big Band		
	Orchestra Swing	Orchestra Swing 1		
		Dreamy Ballad		
		Orchestra Swing 2		
		Easy Swing		
		Cool Jazz Ballad		
		MOR Swing		
		Easy Listening		
		Organ Groove		
		Midnight Swing		
		Jazz Waltz	Jazz Waltz Slow	
	MOR Waltz			
	Jazz Waltz Med			
	Five-Four			
	Jazz Waltz Fast 1			
	Jazz Waltz			
	Jazz Waltz Fast 2			
	Dixie& Trad Jazz		Saloon Piano	
			Stride 1	
			Ragtime	
		Stride 2		
		Charleston		
		Piano Rag 1		
		Dixieland 1		
		Piano Rag 2		
		Dixieland 2		
		Fusion	Jazz Funk	
	Jazz Pop			
	Entertainment	Movie&Show	Movie Soundtrack	
			Ani Fantasy	
			Blockbuster	
			Animation Ballad	
			Ethereal Movie	
			Movie Ballad	
			Sci-fi March	
			Movie Swing 1	
			Secret Service	
			Movie Swing 2	
			Wild West	
			Broadway Ballad	
			Showtune	
Movie Panther				
Tap Dance Swing				
70s TV Theme				
Musical				
Easy Listening			Easy Ballad	
			6-8 Slow Rock	
			Classic Piano Bld	
			6-8 Orchestral	
			Guitar Serenade	
			12-8 Ballad	
			Pop Classics	
			French 50s	
			Pub Piano	
			Tijuana	
			Piano Orch Ballad	
			Ballroom	Viennese Waltz
				Quickstep
				English Waltz
Tango				
Slowfox				
Pasodoble				
Foxtrot				
Samba				
Swingfox				
Cha Cha Cha				
Rumba				
Piano Beguine				
Jive				
Piano Cha Cha				
Beguine				
Piano Rumba				
Twist				

Category	Sub Category	Style Name		
Entertainment	Ballroom	9-8 Waltz		
		Organ	Euro Pop Organ	
			Organ Cha Cha	
			Organ Bossa	
			Organ Rumba	
			Organ Swing	
			Organ Quickstep	
			Organ Samba	
			Holiday	Christmas Swing
				Christmas Shuffle
				Christmas Waltz
		Schlager		Disco Fox
			Alp Ballad 1	
			German Rock	
			Alp Ballad 2	
			Schlager Fever	
			Schlager 6-8	
			Mallorca Party	
	Schlager Fox			
	Alpen Schlager			
	Schlager Waltz			
	Scand Country 1			
	Schlager Italia			
	Scand Country 2			
	Schlager Shuffle			
	Scand Shuffle			
	Schlager Polka			
	Scand Slow Rock			
	Schlager Alp			
	Scand Bugg			
	Schlager Beat			
	Schlager Rock			
	70s French Hit			
	Schlager Pop			
	Party Polka			
	Schlager Rumba			
	Polka Pop			
	Schlager Samba			
	8Beat Adria			
	Latin&World	Brazil	Brazilian Samba	
			Slow Bar Bossa	
			Bossa Nova	
			Orchestral Bossa	
			Slow Bossa	
			Piano Bossa	
			Fast Bossa	
			Piano Samba	
			Cuba	Salsa
				Cuban Son
		Danzon		
		Guitar Rumba		
		Guajira		
Mexico		Norteno		
		Bolero Lento		
		Mariachi Waltz		
Caribbean		Bomba		
		Sheriff Reggae		
		Cumbia		
		Happy Reggae		
	Merengue			
	Calypso			
	Bachata			
	Rumba Island			
	Zouk			
	European	Flamenco		
Italian Mazurka				
Rumba Flamenco				
Sirtaki				
Pop Flamenco				
Tarantella				
Spanish Paso				
Latin Pop	Pop Bossa			
	Latin Party Pop			
	Pop Latin			

Category	Sub Category	Style Name	
Latin&World	Latin Pop	Latin Disco	
		Pop Latin Ballad	
		Rock Cha Cha	
	Celtic	Irish Hymn 1	
		Jig	
		Irish Hymn 2	
		Reel	
		Irish Dance	
	World	Scottish Polka	
		Turkish Euro 1	
		J-Pop Hit 1	
		Turkish Euro 2	
		J-Pop Hit 2	
		Oriental Pop	
		Hawaiian	
		Classic	Green Fantasia
			Ethereal Hymn
			Romantic Ballet
	Arpeggio 1		
	Baroque Air		
	Arpeggio 2		
	Orchestral Bolero		
	Arpeggio 3		
	Orchestral March		
	Nocturne		
	Traditional 1		
	Moonlight 6-8		
	Traditional 2		
	Learning 2-4		
	Traditional 3		
	Trad Waltz	Bohemian Waltz	
		Scand Waltz	
		German Waltz	
		French Musette	
		French Waltz	
		Ober Walzer	
		Highland Waltz	
		Waltz	
		Italian Waltz	
		Piano Slow Waltz	
	March&Polka	Ober Polka	
		US March	
Zither Polka			
German March			
Italian Polka			
6-8 March			
Piano March 1			
6-8 Piano March			
Piano March 2			
4 Stroke			

Chord Types Recognized in the Fingered Mode / Im Fingered-Modus erkannte Akkordarten / Types d'accords reconnus en mode Fingered / Tipos de acordes reconocidos en el modo Fingered (digitado)



Chord Name [Abbreviation]	Normal Voicing	Display for root "C"
1+8	1+8	C1+8
1+5	1+5	C1+5
Major [M]	1+3+5	C
Sixth [6]	1+(3)+5+6	C6
Major seventh [M7]	1+3+(5)+7	CM7
Major seventh flatted fifth [M7 b5]	1+3+ b5+7	CM7(b5)
Major seventh add sharp eleventh [M7(# 11)]	1+(2)+3+ # 4+5+7	CM7(# 11)
Add ninth [(add9)]	1+2+3+5	Cadd9
Major seventh ninth [M7_9]	1+2+3+(5)+7	CM7(9)
Sixth ninth [6_9]	1+2+3+(5)+6	C6(9)
Flatted fifth [(b5)]	1+3+ b5	C b5
Augmented [aug]	1+3+ #5	Caug
Seventh augmented [7aug]	1+3+ #5+ b7	C7aug
Major seventh augmented [M7aug]	1+(3)+ #5+7	CM7aug
Minor [m]	1+ b3+5	Cm
Minor sixth [m6]	1+ b3+5+6	Cm6
Minor seventh [m7]	1+ b3+(5)+ b7	Cm7
Minor seventh flatted fifth [m7 b5]	1+ b3+ b5+ b7	Cm7(b5)
Minor add ninth [m(add9)]	1+2+ b3+5	Cm add9
Minor seventh ninth [m7(9)]	1+2+ b3+(5)+ b7	Cm7(9)
Minor seventh eleventh [m7(11)]	1+(2)+ b3+4+5+(b7)	Cm7(11)
Minor major seventh flatted fifth [mM7 b5]	1+ b3+ b5+7	CmM7(b5)
Minor major seventh [mM7]	1+ b3+(5)+7	CmM7
Minor major seventh ninth [mM7(9)]	1+2+ b3+(5)+7	CmM7(9)
Diminished [dim]	1+ b3+ b5	Cdim
Diminished seventh [dim7]	1+ b3+ b5+6	Cdim7
Seventh [7]	1+3+(5)+ b7	C7
Seventh suspended fourth [7sus4]	1+4+5+ b7	C7sus4
Seventh ninth [7(9)]	1+2+3+(5)+ b7	C7(9)
Seventh add sharp eleventh [7(# 11)]	1+(2)+3+ # 4+5+ b7	C7(# 11)
Seventh add thirteenth [7(13)]	1+3+(5)+6+ b7	C7(13)
Seventh flatted fifth [7 b5]	1+3+ b5+ b7	C7(b5)
Seventh flatted ninth [7(b9)]	1+ b2+3+(5)+ b7	C7(b9)
Seventh add flatted thirteenth [7(b 13)]	1+3+5+ b6+ b7	C7(b 13)
Seventh sharp ninth [7(# 9)]	1+ #2+3+(5)+ b7	C7(# 9)
Suspended fourth [sus4]	1+4+5	Csus4
One plus two plus five [sus2]	1+2+5	Csus2
cancel	1+ b2+2	Cancel

* Notes in parentheses can be omitted.

Effect Type List / Liste der Effekttypen / Liste des types d'effet / Lista de tipos de efecto

Reverb Block

Category	Type	Description	MSB	LSB
REVERB	BASIC HALL	Reverb simulating the acoustics of a hall. Standard setting.	1	21
	LIGHT HALL	Reverb simulating the acoustics of a hall. Light setting.	1	22
	BALLAD HALL	Reverb simulating the acoustics of a hall. For ballad type music.	1	19
	PIANO HALL	Reverb simulating the acoustics of a hall. For piano sound.	1	20
	HALL1	Reverb simulating the acoustics of a hall.	1	0
	HALL2		1	16
	HALL3		1	17
	HALL4		1	18
	HALL5		1	1
	HALL M		1	6
	HALL L		1	7
	ATMO HALL	A unique long reverb with atmosphere.	1	23
	VOCAL HALL1	Reverb suitable for vocals.	1	27
	VOCAL HALL2		1	28
	ACOSTIC ROOM	Reverb simulating the acoustics of a room. Standard setting.	2	20
	DRUMS ROOM	Reverb simulating the acoustics of a room. For drum sounds.	2	21
	PERC ROOM	Reverb simulating the acoustics of a room. For percussion sounds.	2	22
	ROOM1	Reverb simulating the acoustics of a room.	2	16
	ROOM2		2	17
	ROOM3		2	18
	ROOM4		2	19
	ROOM5		2	0
	ROOM6		2	1
	ROOM7		2	2
	ROOM S		2	5
	ROOM M		2	6
	ROOM L		2	7
	STAGE1	Reverb suitable for a solo instrument.	3	16
	STAGE2		3	17
	STAGE3		3	0
	STAGE4		3	1
	PLATE1	Reverb simulating a plate reverb unit.	4	16
	PLATE2		4	17
	PLATE3		4	0
	GM PLATE		4	7
	TUNNEL	Simulates a cylindrical space expanding to left and right.	17	0
	CANYON	A hypothetical acoustic space which extends without limit.	18	0
	BASEMENT	A bit of initial delay followed by reverb with a unique resonance.	19	0
	LARGE HALL	Reverb simulating the acoustics of a hall.	1	2
	MEDIUM HALL		1	3
WARM ROOM	Reverb simulating the acoustics of a warm room.	2	3	
WHITE ROOM	A unique short reverb with a bit of initial delay.	16	0	
WOODY ROOM	Reverb simulating the acoustics of a wood-built room.	2	4	
RICH PLATE	Reverb simulating a rich plate reverb unit.	4	1	
---	NO EFFECT	No effect.	0	0

Chorus Block

Category	Type	Description	MSB	LSB	
REVERB	HALL1	Reverb simulating the acoustics of a hall.	1	0	
	HALL2		1	16	
	HALL3		1	17	
	HALL4		1	18	
	HALL5		1	1	
	HALL M		1	6	
	HALL L		1	7	
	ATMO HALL	A unique long reverb with atmosphere.	1	23	
	ACOSTIC ROOM	Reverb simulating the acoustics of a room. Standard setting.	2	20	
	DRUMS ROOM	Reverb simulating the acoustics of a room. For drum sounds.	2	21	
	PERC ROOM	Reverb simulating the acoustics of a room. For percussion sounds.	2	22	
	ROOM1	Reverb simulating the acoustics of a room.	2	16	
	ROOM2		2	17	
	ROOM3		2	18	
	ROOM4		2	19	
	ROOM5		2	0	
	ROOM6		2	1	
	ROOM7		2	2	
	ROOM S		2	5	
	ROOM M		2	6	
	ROOM L		2	7	
	STAGE1	Reverb suitable for a solo instrument.	3	16	
	STAGE2		3	17	
	STAGE3		3	0	
	STAGE4		3	1	
	PLATE1	Reverb simulating a plate reverb unit.	4	16	
PLATE2	4		17		
PLATE3	4		0		
GM PLATE	4		7		
DELAY	TEMPO DELAY1	Tempo-synchronized delay.	21	0	
	TEMPO DELAY2		21	16	
	TEMPO ECHO	Tempo-synchronized echo.	21	8	
	TEMPO CROSS1	Tempo-synchronized cross delay.	22	0	
	TEMPO CROSS2		22	16	
	TEMPO CROSS3		22	17	
TEMPO CROSS4	22		18		
ER/KARAOKE	KARAOKE1	Echo for karaoke.	20	0	
	KARAOKE2		20	1	
	KARAOKE3		20	2	
	ER1	This effect isolates only the early reflection components of the reverb.	9	0	
	ER2		9	1	
CHORUS	CHORUS1	Conventional chorus program with rich, warm chorusing.	66	17	
	CHORUS2		66	8	
	CHORUS3		66	16	
	CHORUS4		66	1	
	CHORUS5		65	2	
	CHORUS6		65	0	
	CHORUS7		65	1	
	CHORUS8		65	8	
	CHORUS FAST		65	16	
	CHORUS LITE		65	17	
	GM CHORUS1		65	3	
	GM CHORUS2		65	4	
	GM CHORUS3		65	5	
	GM CHORUS4		65	6	
	FB CHORUS		65	7	
	CELESTE1		A 3-phase LFO adds modulation and spaciousness to the sound.	66	0
	CELESTE2			66	2
	SYMPHONIC1		Adds more stages to the modulation of Celeste.	68	16
	SYMPHONIC2	68		0	
	ENS DETUNE1	Chorus effect without modulation, created by adding a slightly pitch-shifted sound.	87	0	
	ENS DETUNE2		87	16	
	FLANGER	FLANGER1	Creates a sound similar to that of a jet airplane.	67	8
FLANGER2		67		16	
FLANGER3		67		17	
FLANGER4		67		1	
FLANGER5		67		0	
GM FLANGER		67		7	
T_FLANGER		Tempo-synchronized flanger.	107	0	

Chorus Block

Category	Type	Description	MSB	LSB
PHASER	PHASER1	Cyclically modulates the phase to add modulation to the sound.	72	0
	PHASER2		72	8
	PHASER3		72	19
	T_PHASER1	Tempo-synchronized phaser.	108	0
	T_PHASER2		108	16
	EP PHASER1	Cyclically modulates the phase to add modulation to the sound. For electric piano.	72	17
	EP PHASER2		72	18
EP PHASER3	72		16	
PITCH CHANGE	PITCH CHG1	Changes the pitch of the input signal.	80	16
	PITCH CHG2		80	0
	PITCH CHG3		80	1
ROTARY SP	DUAL ROT BRT	Simulates a rotary speaker.	99	16
	DUAL ROT WRM		99	17
	DUAL ROT SP1		99	0
	DUAL ROT SP2		99	1
	ROTARY SP1		69	16
	ROTARY SP2		71	17
	ROTARY SP3		71	18
	ROTARY SP4		70	17
	ROTARY SP5		66	18
	ROTARY SP6		69	0
	ROTARY SP7		71	22
	2WAY ROT SP		86	0
TREMOLO	TREMOLO1	Rich Tremolo effect with both volume and pitch modulation.	70	16
	TREMOLO2		71	19
	TREMOLO3		70	0
	EP TREMOLO		70	18
	GT TREMOLO1		71	20
	GT TREMOLO2		70	19
	VIBE VIBRATE	Vibraphone effect.	119	0
T_TREMOLO	Tempo-synchronized rich Tremolo effect with both volume and pitch modulation.	120	0	
SPATIAL	AUTO PAN1	Several panning effects that automatically shift the sound position (left, right, front, back).	71	16
	AUTO PAN2		71	0
	AUTO PAN3		71	1
	EP AUTOPAN	71	21	
	T_AUTO PAN1	Tempo-synchronized auto pan.	121	0
	T_AUTO PAN2		121	1
---	NO EFFECT	No effect.	0	0

Effect Block

CVP-609	CVP-605	XG Block Name
●	●	XG Variation Block
●	●	XG Insertion1 Block
●	●	XG Insertion2 Block
●	●	XG Insertion3 Block
●	●	XG Insertion4 Block
●	●	XG Insertion5 Block
●	●	XG Insertion6 Block (only for MIC & Song)
●	●	XG Insertion7 Block (only for Style)
●	●	XG Insertion8 Block (only for Style)

CVP-609	CVP-605	Category	Type	Description	MSB	LSB
●	●	REVERB	HALL1	Reverb simulating the acoustics of a hall.	1	0
●	●		HALL2		1	16
●	●		HALL3		1	17
●	●		HALL4		1	18
●	●		HALL5		1	1
●	●		HALL M		1	6
●	●		HALL L		1	7
●	●		ATMO HALL	A unique long reverb with atmosphere.	1	23
●	●		ACOSTIC ROOM	Reverb simulating the acoustics of a room. Standard setting.	2	20
●	●		DRUMS ROOM	Reverb simulating the acoustics of a room. For drum sounds.	2	21
●	●		PERC ROOM	Reverb simulating the acoustics of a room. For percussion sounds.	2	22
●	●		ROOM1	Reverb simulating the acoustics of a room.	2	16
●	●		ROOM2		2	17
●	●		ROOM3		2	18
●	●		ROOM4		2	19
●	●		ROOM5		2	0
●	●		ROOM6		2	1
●	●		ROOM7		2	2
●	●		ROOM S	2	5	
●	●		ROOM M	2	6	
●	●		ROOM L	2	7	
●	●		STAGE1	Reverb suitable for a solo instrument.	3	16
●	●		STAGE2		3	17
●	●		STAGE3		3	0
●	●		STAGE4		3	1
●	●		PLATE1	Reverb simulating a plate reverb unit.	4	16
●	●		PLATE2		4	17
●	●		PLATE3		4	0
●	●		GM PLATE		4	7
●	●		TUNNEL	Simulates a cylindrical space expanding to left and right.	17	0
●	●		CANYON	A hypothetical acoustic space which extends without limit.	18	0
●	●		BASEMENT	A bit of initial delay followed by reverb with a unique resonance.	19	0
●	●		WHITE ROOM	A unique short reverb with a bit of initial delay.	16	0
●	●	DELAY	DELAY LCR1	Produces three delayed sounds: L, R and C (center).	5	16
●	●		DELAY LCR2		5	0
●	●		DELAY LR	Produces two delayed sounds: L and R. Two feedback delays are provided.	6	0
●	●		ECHO	Two delayed sounds (L and R), and independent feedback delays for L and R.	7	0
●	●		CROSS DELAY1	The feedback of the two delayed sounds is crossed.	8	0
●	●		CROSS DELAY2		8	16
●	●		TEMPO DELAY1	Tempo-synchronized delay.	21	0
●	●		TEMPO DELAY2		21	16
●	●		TEMPO ECHO	Tempo-synchronized echo.	21	8
●	●		TEMPO CROSS1	Tempo-synchronized cross delay.	22	0
●	●		TEMPO CROSS2		22	16
●	●		TEMPO CROSS3		22	17
●	●		TEMPO CROSS4		22	18
●	●	ER/KARAOKE	KARAOKE1	Echo for karaoke.	20	0
●	●		KARAOKE2		20	1
●	●		KARAOKE3		20	2
●	●		ER1	This effect isolates only the early reflection components of the reverb.	9	0
●	●		ER2		9	1
●	●		GATE REVERB1	Simulation of gated reverb.	10	0
●	●	GATE REVERB2	10		16	
●	●	REVERS GATE	Simulation of gated reverb played back in reverse.	11	0	
●	●	CHORUS	CHORUS1	Conventional chorus program with rich, warm chorusing.	66	17
●	●		CHORUS2		66	8
●	●		CHORUS3		66	16

Effect Block

CVP-609	CVP-605	Category	Type	Description	MSB	LSB	
●	●	CHORUS	CHORUS4	Conventional chorus program with rich, warm chorusing.	66	1	
●	●		CHORUS5		65	2	
●	●		CHORUS6		65	0	
●	●		CHORUS7		65	1	
●	●		CHORUS8		65	8	
●	●		CHORUS FAST		65	16	
●	●		CHORUS LITE		65	17	
●	●		GM CHORUS1		65	3	
●	●		GM CHORUS2		65	4	
●	●		GM CHORUS3		65	5	
●	●		GM CHORUS4		65	6	
●	●		FB CHORUS		65	7	
●	●		CELESTE1		A 3-phase LFO adds modulation and spaciousness to the sound.	66	0
●	●		CELESTE2	66		2	
●	●		SYMPHONIC1	Adds more stages to the modulation of Celeste.	68	16	
●	●		SYMPHONIC2		68	0	
●	●		ENS DETUNE1	Chorus effect without modulation, created by adding a slightly pitch-shifted sound.	87	0	
●	●		ENS DETUNE2		87	16	
●	●		AMB CHORUS	Chorus which added early reflection sound.	65	9	
●	●		AMB CELESTE	Celeste which added early reflection sound.	66	9	
●	●	AMB SYMPHONIC	Symphonic which added early reflection sound.	68	9		
●	●	FLANGER	FLANGER1	Creates a sound similar to that of a jet airplane.	67	8	
●	●		FLANGER2		67	16	
●	●		FLANGER3		67	17	
●	●		FLANGER4		67	1	
●	●		FLANGER5		67	0	
●	●		GM FLANGER		67	7	
●	●		VIN.FLANGER1	This simulates an analog flanger, giving a strong vintage flavor to the sound.	124	1	
●	●		VIN.FLANGER2		124	16	
●	●		V_FLANGER	A simulation of an analog flanger effect. The LFO has a random setting.	104	0	
●	●		T_FLANGER	Tempo-synchronized flanger.	107	0	
●	●		DYN FLANGER	Dynamically controlled flanger.	110	0	
●	●		AMB FLANGER	Flanger which added early reflection sound.	67	9	
●	●		PHASER	PHASER1	Cyclically modulates the phase to add modulation to the sound.	72	0
●	●	PHASER2		72		8	
●	●	PHASER3		72		19	
●	●	VIN.PHASER1		This simulates an analog phaser, giving a strong vintage flavor to the sound. It is effective in mono.	124	2	
●	●	VIN.PHASER2			124	17	
●	●	VIN.PHASER ST1		124	3		
●	●	VIN.PHASER ST2		This simulates an analog phaser, giving a strong vintage flavor to the sound. It is effective in stereo.	124	18	
●	●	VIN.PHASER ST3			124	19	
●	●	VIN.PHASER ST4			124	20	
●	●	T_PHASER1		Tempo-synchronized phaser.	108	0	
●	●	T_PHASER2			108	16	
●	●	EP PHASER1		Cyclically modulates the phase to add modulation to the sound. For electric piano.	72	17	
●	●	EP PHASER2			72	18	
●	●	EP PHASER3	72		16		
●	●	DYN PHASER	Dynamically controlled phaser.	111	0		
●	●	DISTORTION	V_DIST WARM	Distortion which simulates the sound of a vintage tube, fuzz effect, etc.	98	22	
●	●		V_DIST CLS H		98	23	
●	●		V_DIST CLS S		98	20	
●	●		V_DIST METAL		98	24	
●	●		V_DIST CRUNC		98	18	
●	●		V_DIST BLUES		98	21	
●	●		V_DIST EDGY		98	19	
●	●		V_DIST SOLID		98	25	
●	●		V_DST CLEAN1		98	17	
●	●		V_DST CLEAN2		98	26	
●	●		V_DIST TWIN		98	16	
●	●		V_DIST ROCA		103	18	
●	●		V_DST JZ CLN		98	27	
●	●		V_DST FUSION		103	19	
●	●		ST AMP SOLID		Stereo amp simulator.	75	29
●	●		ST AMP CRUNC			75	30
●	●		ST AMP BLUES			75	28
●	●		ST AMP CLEAN			75	27
●	●		ST AMP HARP			75	31
●	●		V_DIST HARD	Distortion which simulates the sound of a vintage tube, fuzz effect, etc.	98	0	
●	●		V_DIST SOFT		98	2	

Effect Block

CVP-609	CVP-605	Category	Type	Description	MSB	LSB	
●	●	DISTORTION	DIST HARD1	Hard-edge distortion.	75	16	
●	●		DIST HARD2		75	22	
●	●		DIST SOFT1	Soft, warm distortion.	75	17	
●	●		DIST SOFT2		75	23	
●	●		DIST HEAVY	Heavy distortion.	73	0	
●	●		OVERDRIVE	Adds mild distortion to the sound.	74	0	
●	●		ST DIST	Stereo distortion.	73	8	
●	●		ST OD	Stereo overdrive.	74	8	
●	●		ST DIST HARD	Hard-edge stereo distortion.	75	18	
●	●		ST DIST SOFT	Soft, warm soft distortion.	75	19	
●	●		AMP SIM1	A simulation of a guitar amp.	75	0	
●	●		AMP SIM2		75	1	
●	●		ST AMP1		Stereo amp simulator.	75	20
●	●		ST AMP2			75	21
●	●		ST AMP3			75	8
●	●		ST AMP4			75	24
●	●		ST AMP5			75	25
●	●		ST AMP6	75		26	
●	●		DISTORTION+	DST+DELAY1	Distortion and Delay are connected in series.	95	16
●	●			DST+DELAY2		95	0
●	●	OD+DELAY1		Overdrive and Delay are connected in series.	95	17	
●	●	OD+DELAY2			95	1	
●	●	CMP+DST+DLY1		Compressor, Distortion and Delay are connected in series.	96	16	
●	●	CMP+DST+DLY2			96	0	
●	●	CMP+OD+DLY1		Compressor, Overdrive and Delay are connected in series.	96	17	
●	●	CMP+OD+DLY2			96	1	
●	●	V_DST H+DLY		V Distortion Hard and Delay are connected in series.	98	1	
●	●	V_DST S+DLY		V Distortion Soft and Delay are connected in series.	98	3	
●	●	DST+TDLY		Distortion and Tempo Delay are connected in series.	100	0	
●	●	OD+TDLY		Overdrive and Tempo Delay are connected in series.	100	1	
●	●	COMP+DIST1		Since a Compressor is included in the first stage, steady distortion can be produced regardless of changes in input level.	73	16	
●	●	COMP+DIST2			73	1	
●	●	CMP+DST+TDL		Compressor, Distortion and Tempo Delay are connected in series.	101	0	
●	●	CMP+OD+TDLY1		Compressor, Overdrive and Tempo Delay are connected in series.	101	1	
●	●	CMP+OD+TDLY2			101	16	
●	●	CMP+OD+TDLY3			101	17	
●	●	CMP+OD+TDLY4			101	18	
●	●	CMP+OD+TDLY5			101	19	
●	●	CMP+OD+TDLY6	101		20		
●	●	V_DST H+TDL1	V Distortion Hard and Tempo Delay are connected in series.	103	0		
●	●	V_DST H+TDL2		103	17		
●	●	V_DST S+TDL1	V Distortion Soft and Tempo Delay are connected in series.	103	1		
●	●	V_DST S+TDL2		103	16		
●	●	REAL DIST	MLT DS SOLO	Multi effector for guitar. Setting for guitar solo.	95	32	
●	●		MLT DS BASIC	Multi effector for guitar. Setting for basic distortion.	95	33	
●	●		MLT OD CHO	Multi effector for guitar. Setting for overdrive & chorus.	95	34	
●	●		MLT CR WAH	Multi effector for guitar. Setting for crunch & wah.	95	35	
●	●		MLT OLD DLY	Multi effector for guitar. Setting for vintage delay.	95	36	
●	●		VINTAGE ECHO	Multi effector for guitar. Setting for vintage echo.	95	37	
●	●		ST AMP DS	Stereo distortion for guitar. Setting for distortion sound.	96	32	
●	●		ST AMP OD	Stereo distortion for guitar. Setting for overdrive sound.	96	33	
●	●		ST AMP VT	Stereo distortion for guitar. Setting for vintage sound.	96	34	
●	●		ST AMP HV	Stereo distortion for guitar. Setting for heavy sound.	96	35	
●	●		AMP1 CLASSIC	British combo amp simulator. Setting for classic sound.	97	32	
●	●		AMP1 TOP BST	British combo amp simulator. Setting for "TOP BOOST" sound.	97	33	
●	●		AMP1 CUSTOM	British combo amp simulator. Setting for custom sound.	97	34	
●	●		AMP1 HEAVY	British combo amp simulator. Setting for heavy sound.	97	35	
●	●		AMP2 BLUES	British combo amp simulator. Setting for blues sound.	98	32	
●	●		AMP2 HEAVY1	British stack amp simulator. Setting for heavy sound 1.	98	33	
●	●		AMP2 HEAVY2	British stack amp simulator. Setting for heavy sound 2.	98	34	
●	●		AMP2 CLEAN	British stack amp simulator. Setting for clean sound.	98	35	
●	●		AMP2 DRT CLN	British stack amp simulator. Setting for crunch sound.	98	36	
●	●		PITCH CHANGE	PITCH CHG1	Changes the pitch of the input signal.	80	16
●	●	PITCH CHG2		80		0	
●	●	PITCH CHG3		80		1	
●	●	WAH AUTO	AUTO WAH1	Cyclically modulates the center frequency of a wah filter.	78	16	
●	●		AUTO WAH2		78	0	
●	●		V.AUTO WAH	This simulates an analog wah pedal effect, giving a strong vintage flavor to the sound. It cyclically changes the central frequency of the wah filter.	124	5	

Effect Block

CVP-609	CVP-605	Category	Type	Description	MSB	LSB
●	●	WAH AUTO	AT.WAH+DST1	Distortion can be applied to the output of Auto Wah.	78	17
●	●		AT.WAH+DST2		78	1
●	●		AT.WH+DST HD		78	21
●	●		AT.WH+DST HV		78	23
●	●		AT.WH+DST LT		78	25
●	●		AT.WAH+OD1	Overdrive distortion can be applied to the output of Auto Wah.	78	18
●	●		AT.WAH+OD2		78	2
●	●		AT.WH+OD HD		78	22
●	●		AT.WH+OD HV		78	24
●	●		AT.WH+OD LT		78	26
●	●		TEMPO AT.WAH	Tempo-synchronized Auto Wah.	79	0
●	●		T_AT.WH+DST	Tempo-synchronized Auto Wah. Distortion can be applied to the output.	79	1
●	●		T_A.WH+DSTHD		79	21
●	●		T_A.WH+DSTHV		79	23
●	●		T_A.WH+DSTLT		79	25
●	●		T_AT.WH+OD	Tempo-synchronized Auto Wah. Overdrive distortion can be applied to the output.	79	2
●	●		T_A.WH+OD HD		79	22
●	●		T_A.WH+OD HV		79	24
●	●		T_A.WH+OD LT		79	26
●	●		WAH TCH/PDL	TOUCH WAH1	Changes the center frequency of a wah filter according to the input level.	82
●	●	TOUCH WAH2		82		8
●	●	TOUCH WAH3		82		20
●	●	V.TOUCH WAH		This simulates an analog wah pedal effect, giving a strong vintage flavor to the sound. It changes the central frequency of the wah filter according to the input level.	125	2
●	●	TC.WH+DST1		Distortion can be applied to the output of Touch Wah.	82	16
●	●	TC.WH+DST2			82	1
●	●	TC.WH+DST HD			82	21
●	●	TC.WH+DST HV			82	23
●	●	TC.WH+DST LT			82	25
●	●	TC.WAH+OD1		Overdrive distortion can be applied to the output of Touch Wah.	82	17
●	●	TC.WAH+OD2			82	2
●	●	TC.WAH+OD HD			82	22
●	●	TC.WAH+OD HV			82	24
●	●	TC.WAH+OD LT			82	26
●	●	WH+DST+DLY1		Wah, Distortion and Delay are connected in series.	97	16
●	●	WH+DST+DLY2			97	0
●	●	WH+DST+TDLY		Wah, Distortion and Tempo Delay are connected in series.	102	0
●	●	WH+OD+DLY1		Wah, Overdrive and Delay are connected in series.	97	17
●	●	WH+OD+DLY2			97	1
●	●	WH+OD+TDLY1		Wah, Overdrive and Tempo Delay are connected in series.	102	1
●	●	WH+OD+TDLY2		102	16	
●	●	CLAVI TC.WAH	Clavinet Touch Wah	82	18	
●	●	EP TC.WAH	EP Touch Wah	82	19	
●	●	V.PEDAL WH B	Vintage Wah which can be controlled by "Pedal Control" parameter. (See Effect Parameter List.)	125	1	
●	●	V.PEDAL WH D		125	16	
●	●	PEDAL WAH	Changes the center frequency of a wah filter according to "Pedal Control" parameter. (See Effect Parameter List.)	122	0	
●	●	PEDAL WH+DST	Distortion can be applied to the output of Pedal Wah.	122	1	
●	●	P.WH+DIST HD		122	21	
●	●	P.WH+DIST HV		122	23	
●	●	P.WH+DIST LT		122	25	
●	●	PEDAL WH+OD		Overdrive distortion can be applied to the output of Pedal Wah.	122	2
●	●	P.WH+OD HD	122		22	
●	●	P.WH+OD HV	122		24	
●	●	P.WH+OD LT	122		26	
●	●	COMP MED	Compressor with medium setting.		83	16
●	●	COMP HEAVY	Compressor with heavy setting.	83	17	
●	●	COMP MELODY	Compressor for the Melody part.	105	16	
●	●	COMP BASS	Compressor for the Bass part.	105	17	
●	●	V.COMPRESSOR	This simulates an analog compressor, giving a vintage flavor to the sound.	124	4	
●	●	MBAND COMP	Multi-band compressor that allows you to adjust the compression effect for individual frequency bands.	105	0	
●	●	COMPRESSOR	Holds down the output level when a specified input level is exceeded. A sense of attack can also be added to the sound.	83	0	
●	●	NOISE GATE	Gates the input when the input signal falls below a specified level.	84	0	
●	●	ROTARY SP	DUAL ROT BRT	Simulates a rotary speaker.	99	16
●	●		DUAL ROT WRM		99	17
●	●		DUAL ROT SP1		99	0
●	●		DUAL ROT SP2		99	1
●	●		ROTARY SP1		69	16

Effect Block

CVP-609	CVP-605	Category	Type	Description	MSB	LSB		
●	●	ROTARY SP	ROTARY SP2	Simulates a rotary speaker.	71	17		
●	●		ROTARY SP3		71	18		
●	●		ROTARY SP4		70	17		
●	●		ROTARY SP5		66	18		
●	●		ROTARY SP6		69	0		
●	●		ROTARY SP7		71	22		
●	●		2WAY ROT SP		86	0		
●	●		DST+ROT SP		Distortion and rotary speaker connected in series.	69	1	
●	●		DST+2ROT SP		Distortion and 2-way rotary speaker connected in series.	86	1	
●	●		OD+ROT SP		Overdrive and rotary speaker connected in series.	69	2	
●	●		OD+2ROT SP		Overdrive and 2-way rotary speaker connected in series.	86	2	
●	●		AMP+ROT SP		Amp simulator and rotary speaker connected in series.	69	3	
●	●		AMP+2ROT SP		Amp simulator and 2-way rotary speaker connected in series.	86	3	
●	●		TREMLOLO		TREMLOLO1	Rich Tremolo effect with both volume and pitch modulation.	70	16
●	●				TREMLOLO2		71	19
●	●	TREMLOLO3		70	0			
●	●	EP TREMLOLO		70	18			
●	●	GT TREMLOLO1		71	20			
●	●	GT TREMLOLO2		70	19			
●	●	VIBE VIBRATE		Vibraphone effect.	119		0	
●	●	T_TREMLOLO	Tempo-synchronized rich Tremolo effect with both volume and pitch modulation.	120	0			
●	●	SPATIAL	AUTO PAN1	Several panning effects that automatically shift the sound position (left, right, front, back).	71	16		
●	●		AUTO PAN2		71	0		
●	●		AUTO PAN3		71	1		
●	●		EP AUTOPAN		71	21		
●	●		T_AUTO PAN1		121	0		
●	●		T_AUTO PAN2		121	1		
●	●		EQ/ENHANCER		EQ DISCO	Equalizer effect that boosts both high and low frequencies, as is typical in most disco music.	76	16
●	●	EQ TEL		Equalizer effect that cuts both high and low frequencies, to simulate the sound heard through a telephone receiver.	76	17		
●	●	2BAND EQ		A stereo EQ with adjustable LOW and HIGH. Ideal for drum Parts.	77	0		
●	●	3BAND EQ		A mono EQ with adjustable LOW, MID, and HIGH equalization.	76	0		
●	●	ST 3BAND EQ		A stereo EQ with adjustable LOW, MID, and HIGH equalization.	76	18		
●	●	HM ENHANCE1		Adds new harmonics to the input signal to make the sound stand out.	81	16		
●	●	HM ENHANCE2			81	0		
●	●	MISC	VCE CANCEL	Attenuates the vocal part of a CD or other source.	85	0		
●	●		AMBIENCE	Blurs the stereo positioning of the sound to add spatial width.	88	0		
●	●		TALKING MOD	Adds a vowel sound to the input signal.	93	0		
●	●		LOOP FX1	Degrades the audio quality of the input signal. Ideal for drum sounds.	94	16		
●	●		LOOP FX2		94	17		
●	●		LO-FI		94	0		
●	●		LO-FI DRUM1		94	18		
●	●		LO-FI DRUM2		94	19		
●	●		LO-FI DRUM3		76	19		
●	●		LO-FI DRUM4		76	20		
●	●		DYN FILTER		Dynamically controlled filter.	109	0	
●	●		DYN RINGMOD		Dynamically controlled Ring Modulator.	112	0	
●	●		RING MOD		An effect that modifies the pitch by applying amplitude modulation to the frequency of the input.	113	0	
●	●		ISOLATOR		Controls the level of a specified frequency band of the input signal.	115	0	
●	●		---		NO EFFECT	No effect.	0	0
●	●	---	THRU		Bypass without applying an effect.	64	0	

Parameter Chart / Parametertabelle / Tableau des paramètres / Gráfico de parâmetros

Parameter	CVP -605	CVP -609	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Home															
Voice (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–
Voice (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Voice (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Part On/Off (Main)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Part On/Off (Left)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Part On/Off (Layer)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Song (MIDI/Audio)	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Registration Area Show/Hide	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Home (MIDI Song)															
Extra On/Off	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Left On/Off	○	○	×	×	×	×	×	–	○	Guide Setting	×	×	○	Song	–
Right On/Off	○	○	×	×	×	×	×	–	○	Guide Setting	×	×	○	Song	–
Channels Show/Hide on Song Recording Window	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Home (Audio Song)															
Pitch Shift	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Time Stretch	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Vocal Cancel	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Style Control															
ACMP On/Off	○	○	×	×	×	×	×	–	×	–	×	○ (On)	○	Style	–
Auto Fill In	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Section	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Sync Start	○	○	×	×	×	×	×	–	×	–	×	○ (On)	○	Style	–
Sync Stop	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Transpose															
Transpose	○	○	×	×	×	×	×	–	×	–	×	×	○	Transpose	–
Tempo															
Master Tempo	○	○	×	×	×	×	×	–	○	Tempo	○	×	○	Tempo	–
Song															
Synchro Start	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Channel On/Off	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Registration															
Regist Memory Contents	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Items to Register Show/Hide on Registration Memory Window	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Regist Contents Name	○	○	×	×	×	×	×	–	×	–	×	×	○	–	–
One Touch Setting															
OTS Link	○	○	×	×	×	○ (On)	×	–	×	–	×	×	×	–	–
Menu															
Short Cut	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Split Point & Fingering															
Split Point (Left)	○	○	○	×	×	×	×	–	×	–	×	×	○	Style	Split Point
Split Point (Style)	○	○	○	×	×	×	×	–	○	Guide Setting	×	×	○	Style	Split Point
Fingering Type	○	○	○	×	×	×	×	–	×	–	×	×	○	Style	Fingering Type
Transpose															
Master Transpose	○	○	×	×	×	×	×	–	×	–	×	×	○	Transpose	–
Song Transpose	○	○	×	×	×	×	×	–	×	–	×	×	○	Transpose	–
Keyboard Transpose	○	○	×	×	×	×	×	–	×	–	×	×	○	Transpose	–
Transpose Assign	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Balance															
Offset Volume Style	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Volume Left	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Volume Main	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Volume Layer	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Volume Mic	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Offset Volume Song	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Piano Room															
Piano	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Environment	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Detail Setting															
Lid Position	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–

Parameter	CVP-605	CVP-609	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Touch	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Tune	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Damper Resonance	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
String Resonance	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Key Off Sampling	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Piano Lock	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Score															
View Setting															
Size	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Left On/Off	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Right On/Off	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Chord On/Off	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Lyrics On/Off	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Pedal On/Off	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Note On/Off	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Fingering On/Off	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Color On/Off	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Detail Setting															
Right Ch	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Left Ch	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Key Signature	○	○	×	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Quantize	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Note Name	○	○	○	×	×	×	×	-	○	Score Setting	×	×	×	-	-
Lyrics															
Background (*1)	○	○	○	×	×	×	×	-	○	Lyrics Setting	×	×	×	-	-
Text Viewer															
Text File	○	○	×	×	×	×	×	-	×	-	×	×	○	Text	-
Mixer															
Panel															
Filter															
Harmonic Content (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
Harmonic Content (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Harmonic Content (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Brightness (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
Brightness (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Brightness (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
EQ															
High Gain (Style) Offset	○	○	×	×	×	×	×	-	×	-	×	×	○	Style	-
High Gain (Left)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Style	-
High Gain (Main)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	-
High Gain (Layer)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	-
High Gain (Song) Offset	○	○	×	×	×	×	×	-	×	-	×	×	×	-	-
Low Gain (Style) Offset	○	○	×	×	×	×	×	-	×	-	×	×	×	-	-
Low Gain (Left)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Style	-
Low Gain (Main)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	-
Low Gain (Layer)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	-
Low Gain (Song) Offset	○	○	×	×	×	×	×	-	×	-	×	×	×	-	-
Effect															
Insertion Effect Depth (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	-
Insertion Effect Depth (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	-
Insertion Effect Depth (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	-
Insertion Effect Depth (Mic)	○	○	×	×	×	×	×	-	○	Vocal Harmony/Mic Setting	×	×	○	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Chorus/Reverb															
Reverb Depth (Style) Offset	○	○	×	×	×	×	×	-	×	-	×	×	○	Style	-
Reverb Depth (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	-
Reverb Depth (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	-
Reverb Depth (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	-
Reverb Depth (Mic)	○	○	×	×	×	×	×	-	○	Vocal Harmony/Mic Setting	×	×	○	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Reverb Depth (Song) Offset	○	○	×	×	×	×	×	-	×	-	×	×	×	-	-
Chorus Depth (Style) Offset	○	○	×	×	×	×	×	-	×	-	×	×	○	Style	-
Chorus Depth (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	-

Parameter	CVP -605	CVP -609	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Chorus Depth (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Chorus Depth (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Chorus Depth (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Chorus Depth (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
Pan/Volume															
Pan (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Pan (Left)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Pan (Main)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Pan (Layer)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Pan (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Pan (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
Volume (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Volume (Left)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Volume (Main)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Volume (Layer)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Volume (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Volume (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Style															
Filter															
Harmonic Content	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Brightness	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
EQ															
Low Gain	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
High Gain	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Effect															
Effect Depth	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Chorus/Reverb															
Reverb Depth	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Chorus Depth	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Pan/Volume															
Pan	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Volume	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Song Ch 1-8															
Song Ch 9-16															
Filter															
Harmonic Content Song Part	○	○	×	×	×	×	×	–	○	Filter	×	×	×	–	–
Brightness Song Part	○	○	×	×	×	×	×	–	○	Filter	×	×	×	–	–
EQ															
EQ Low Gain Song Part	○	○	×	×	×	×	×	–	○	EQ	×	×	×	–	–
EQ High Gain Song Part	○	○	×	×	×	×	×	–	○	EQ	×	×	×	–	–
Effect															
Effect Depth Song Part	○	○	×	×	×	×	×	–	○	Effect	×	×	×	–	–
Chorus/Reverb															
Reverb Depth Song Part	○	○	×	×	×	×	×	–	○	Effect	×	×	×	–	–
Chorus Depth Song Part	○	○	×	×	×	×	×	–	○	Effect	×	×	×	–	–
Pan/Volume															
Part Volume Song	○	○	×	×	×	×	×	–	○	Volume	×	×	×	–	–
Part Pan Song	○	○	×	×	×	×	×	–	○	Pan	×	×	×	–	–
Master															
Compressor															
On/Off		○	○	×	×	×	×	–	×	–	×	×	×	–	–
Type		○	○	×	×	×	×	–	×	–	×	×	×	–	–
Threshold Offset		○	×	×	○	×	×	–	×	–	×	×	×	–	–
Ratio Offset		○	×	×	○	×	×	–	×	–	×	×	×	–	–
Output Offset		○	×	×	○	×	×	–	×	–	×	×	×	–	–
EQ															
Type	○	○	○	×	×	×	×	–	×	–	×	×	×	–	Master EQ
Parameter	○	○	×	×	○	×	×	–	×	–	×	×	×	–	Master EQ

Parameter	CVP -605	CVP -609	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group	
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group		
Channel On/Off																
Channel On/Off (Song)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Song	<input type="checkbox"/>
Channel On/Off (Style)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style	<input type="checkbox"/>
Voice																
Voice (Style)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style	<input type="checkbox"/>
Voice (Song)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Voice	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Reverb																
Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song	Reverb Type
Return Level	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song	Reverb Return Level
Chorus																
Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song	<input type="checkbox"/>
Return Level	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song	Chorus Return Level
Assign Detail Setting																
Variation Effect Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song	<input type="checkbox"/>
Variation Effect Return Level	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song	Variation Effect (System) Return Level
Insertion Effect 1 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song	<input type="checkbox"/>
Insertion Effect 2 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song	<input type="checkbox"/>
Insertion Effect 3 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect/ Vocal Harmony/ Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song/ Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Insertion Effect 3 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song	<input type="checkbox"/>
Insertion Effect 4 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song	<input type="checkbox"/>
Insertion Effect 5 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song	<input type="checkbox"/>
Insertion Effect 6 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect/ Vocal Harmony/ Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song/ Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Insertion Effect 7 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style	<input type="checkbox"/>
Insertion Effect 8 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style	<input type="checkbox"/>
Effect Parameter (Reverb/Chorus/ Variation/Insertion 1-2)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Effect Parameter (Insertion 3)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect/ Vocal Harmony/ Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Vocal Harmony/ Mic Setting
Effect Parameter (Reverb/Chorus/ Variation/Insertion 1-5)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Effect Parameter (Insertion 6)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect/ Vocal Harmony/ Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Vocal Harmony/ Mic Setting
Effect Parameter (Insertion 7-8)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Music Finder																
Sort By	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sort Order	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Search Keyword	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Record	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Keyboard Harmony																
Harmony/Echo	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Harmony	<input type="checkbox"/>
Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Keyboard Harmony	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Harmony	<input type="checkbox"/>
Volume	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Keyboard Harmony	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Harmony	<input type="checkbox"/>
Speed	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Keyboard Harmony	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Harmony	<input type="checkbox"/>
Assign	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Keyboard Harmony	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Harmony	<input type="checkbox"/>
Chord Note Only	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Keyboard Harmony	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Harmony	<input type="checkbox"/>
Minimum Velocity	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Keyboard Harmony	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Harmony	<input type="checkbox"/>
Mic Setting																
EQ Low Frequency	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
EQ Low Gain	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
EQ Mid Frequency	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
EQ Mid Gain	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
EQ High Frequency	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Parameter	CVP -605	CVP -609	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
EQ High Gain	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Noise Gate On/Off	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Noise Gate Threshold	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Compressor On/Off	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Compressor Threshold	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Compressor Ratio	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Compressor Out	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Pitch Detect Vocal Type		○	×	×	○	×	×	-	×	-	×	×	×	-	-
Pitch Detect Background Noise Cut		○	×	×	○	×	×	-	×	-	×	×	×	-	-
Pitch Detect Speed		○	×	×	○	×	×	-	×	-	×	×	×	-	-
User Setting	○	○	○	×	○	×	×	-	×	-	×	×	×	-	-
Mic Volume	○	○	×	×	×	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Talk Setting															
Talk Setting Volume	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk Setting Pan	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk Setting Reverb Depth	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk Setting Chorus Depth	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk Setting Reduction Level	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk EQ Low Frequency	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk EQ Low Gain	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk EQ Mid Frequency	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk EQ Mid Gain	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk EQ High Frequency	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk EQ High Gain	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk Noise Gate On/Off	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk Noise Gate Threshold	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk Compressor On/Off	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk Compressor Threshold	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk Compressor Ratio	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Talk Compressor Out	○	○	×	×	○	×	×	-	×	-	×	×	×	-	-
Vocal Harmony															
On/Off	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Type	○	○	×	×	×	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Mode	○		×	×	×	×	×	-	×	-	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Mode		○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Vocal Range	○		○	×	×	×	×	-	×	-	×	×	×	-	-
Song Channel	○	○	×	×	×	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Keyboard	○	○	×	×	×	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Song Channel Mute/Play	○	○	×	×	×	×	×	-	×	-	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Balance	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Chord Source	○	○	×	×	×	×	×	-	×	-	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Chordal Type		○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Effect On/Off		○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Type		○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Depth To Lead		○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Depth To Harmony		○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Reverb Depth		○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Chorus Depth		○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting

Parameter	CVP-605	CVP-609	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Harmony Edit															
Transpose Mode		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Pitch Correct		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Session Table		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Key Root		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Key Type		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Lead Pitch Detect Speed		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony Pitch Detect Speed		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony Effect		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony Stability		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Lead Vibrato Depth		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony Vibrato Depth		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Vibrato Speed		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Vibrato Delay		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Detail Setting															
Parameters	<input type="radio"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Part Mixer															
Lead Transpose		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Lead Detune		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Lead Formant		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Lead Volume		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Lead Pan		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Lead Octave		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 1 Transpose		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 1 Detune		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 1 Formant Shift		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 1 Volume		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 1 Pan		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 1 Degree		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 2 Transpose		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 2 Detune		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 2 Formant Shift		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 2 Volume		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 2 Pan		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 2 Degree		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 3 Transpose		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 3 Detune		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Harmony 3 Formant Shift		<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Vocal Harmony/Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting

Parameter	CVP -605	CVP -609	Backup/Restore				Voice Set	Voice Set Group	Song			Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group		
Harmony 3 Volume		○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Harmony 3 Pan		○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Harmony 3 Degree		○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Harmony 1 Detune	○		×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Harmony 1 Volume	○		×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Harmony 1 Pan	○		×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Harmony 2 Detune	○		×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Harmony 2 Volume	○		×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Harmony 2 Pan	○		×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Harmony 3 Detune	○		×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Harmony 3 Volume	○		×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Harmony 3 Pan	○		×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Vocal Harmony Effect																
Parameters		○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting	
Voice Edit																
Common																
Volume (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Volume (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Volume (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-	
Touch Sense Depth (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Touch Sense Depth (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Touch Sense Depth (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-	
Touch Sense Offset (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Touch Sense Offset (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Touch Sense Offset (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-	
Part Octave (Main/Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Part Octave (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-	
Sound (1/3)																
Mono/Poly (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Mono/Poly (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Mono/Poly (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-	
EG Attack (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
EG Attack (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
EG Attack (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-	
EG Decay (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
EG Decay (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
EG Decay (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-	
EG Release (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
EG Release (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
EG Release (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-	
Vibrato Depth (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Vibrato Depth (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Vibrato Depth (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-	
Vibrato Speed (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Vibrato Speed (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Vibrato Speed (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-	
Vibrato Delay (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Vibrato Delay (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Vibrato Delay (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-	
Modulation Filter (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Modulation Filter (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Modulation Filter (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-	
Modulation Amplitude (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	
Modulation Amplitude (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-	

Parameter	CVP -605	CVP -609	Backup/Restore				Voice Set	Voice Set Group	Song			Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group		
Modulation Amplitude (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–	
Modulation LFO Pitch (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–	
Modulation LFO Pitch (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–	
Modulation LFO Pitch (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–	
Modulation LFO Filter (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–	
Modulation LFO Filter (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–	
Modulation LFO Filter (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–	
Modulation LFO Amplitude (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–	
Modulation LFO Amplitude (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–	
Modulation LFO Amplitude (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–	
Effect																
Insertion Effect On/Off (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Insertion Effect Type (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Insertion Effect On/Off (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Insertion Effect Type (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Insertion Effect On/Off (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Insertion Effect Type (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Insertion Effect Variation On/Off (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Insertion Effect Variation Value (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Insertion Effect Variation On/Off (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Insertion Effect Variation Value (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Insertion Effect Variation On/Off (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Insertion Effect Variation Value (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	–	
Vibe Rotor On/Off (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Vibe Rotor On/Off (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–	
Vibe Rotor On/Off (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	–	
EQ																
EQ Low Freq (Main)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–	
EQ Low Freq (Layer)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–	
EQ Low Freq (Left)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Style	–	
EQ High Freq (Main)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–	
EQ High Freq (Layer)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–	
EQ High Freq (Left)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Style	–	
Pedal																
Function Assign	○	○	×	×	×	×	○	Pedal	○	Keyboard Voice	×	○	○	Pedal	–	
Detail Setting	○	○	×	×	×	×	○	Pedal	○	Keyboard Voice	×	○	○	Pedal	–	
Organ Flute																
Footage (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Footage (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Footage (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–	
Type (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Type (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Type (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–	
Vibrato On/Off (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Vibrato On/Off (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Vibrato On/Off (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–	
Vibrato Depth (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–	
Vibrato Depth (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–	
Vibrato Depth (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–	
Vibrato Speed (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–	
Vibrato Speed (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–	
Vibrato Speed (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–	
Attack Footage (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Attack Footage (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Attack Footage (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–	
Attack Mode (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Attack Mode (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Attack Mode (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–	
Attack Length (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Attack Length (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Attack Length (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–	
Response (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	
Response (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–	

Parameter	CVP -605	CVP -609	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Response (Left)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	-	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Style	-
Volume (Main)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	-	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Voice	-
Volume (Layer)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	-	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Voice	-
Volume (Left)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	-	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Style	-
Style Creator															
Basic															
Pattern Length	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Tempo	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Beat	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
SFF Edit															
Play Root															
Play/Source Root	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Play/Source Chord	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
NTR/NTT															
NTR	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
NTT	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
NTT Bass	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
High Key/Note Limit															
High Key	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Note Limit Low	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Note Limit High	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
RTR															
RTR	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Song Creator															
Channel Edit															
Setup															
Setup Select	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Regist Sequence															
Regist Sequence Data	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	-	-
Regist Sequence On/Off	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Regist+ Pedal	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Regist- Pedal	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Sequence End	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	-	-
Voice Setting															
Tune															
Tuning Main	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Voice	-
Tuning Layer	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Voice	-
Tuning Left	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Style	-
Octave (Main)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Voice	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Voice	-
Octave (Layer)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Voice	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Voice	-
Octave (Left)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Voice	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Style	-
Pitch Bend Range (Main)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Voice	-
Pitch Bend Range (Layer)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Voice	-
Pitch Bend Range (Left)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Style	-
Portamento Time (Main)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Voice	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Voice	-
Portamento Time (Layer)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Voice	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Voice	-
Portamento Time (Left)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/>	Voice	<input type="radio"/>	Keyboard Voice	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Style	-
Piano															
Tuning Curve	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Key Off Sampling	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Sustain Sampling	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
String Resonance	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Voice Set															
Voice Set On/Off (Main)	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Voice Set On/Off (Layer)	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Voice Set On/Off (Left)	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Setting															
Category Button	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
SA2 Auto Articulation	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
Style Setting															
Setting															
Display Tempo	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-

Parameter	CVP -605	CVP -609	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Stop ACMP	○	○	○	×	×	×	×	-	×	-	×	×	○	Style	-
ACMP On/Off Default	○	○	○	×	×	×	×	-	×	-	×	×	○	Style	-
OTS Link Timing	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Synchro Stop Window	○	○	○	×	×	×	×	-	×	-	×	×	○	Style	-
Style Touch Response	○	○	○	×	×	×	×	-	×	-	×	×	○	Style	-
Change Behavior															
Section Set	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Tempo	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Part On/Off	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Music Finder Style Tempo	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Song Setting															
Guide															
Type	○	○	○	×	×	×	×	-	○	Guide Setting	×	×	×	-	-
Lamp	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Lamp Timing	○	○	○	×	×	×	×	-	○	Guide Setting	×	×	×	-	-
Part Ch															
Right	○	○	○	×	×	×	×	-	○	-	×	×	×	-	-
Left	○	○	○	×	×	×	×	-	○	-	×	×	×	-	-
Auto Set	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Lyrics															
Language	○	○	○	×	×	×	×	-	○	Lyrics Setting	×	×	×	-	-
Play															
Repeat Mode	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Quick Start	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
MIDI Song Fast Forward Type (*2)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
USB MIDI Song Auto Open	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Chord Detection Priority (*2)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Rec															
Audio Rec Format	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Metronome															
Metronome															
Volume	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Sound	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Time Signature	○	○	×	×	×	×	×	-	○	-	○	×	×	-	-
Tap Tempo															
Volume	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Style	-
Sound	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Style	-
Tuning															
Master Tune															
Master Tune	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Scale Tune															
Scale Type	○	○	×	×	×	×	×	-	×	-	×	×	○	Scale	-
Base Note	○	○	×	×	×	×	×	-	×	-	×	×	○	Scale	-
Tune	○	○	×	×	×	×	×	-	×	-	×	×	○	Scale	-
Part Select	○	○	×	×	×	×	×	-	×	-	×	×	○	Scale	-
Keyboard															
Keyboard															
Touch Curve	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Fixed Velocity	○	○	×	×	×	×	×	-	×	-	×	×	○	Voice	-
Touch Response Part On/Off	○	○	×	×	×	×	×	-	×	-	×	×	○	Voice	-
Left Hold	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Style	-
Assignable															
Pedal															
Function Assign	○	○	×	×	×	×	○	Pedal	○	Keyboard Voice	×	○	○	Pedal	-
Detail Setting	○	○	×	×	×	×	○	Pedal	○	Keyboard Voice	×	○	○	Pedal	-
Depends On Main Voice	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
AUX Pedal Polarity	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Fade In Time	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Fade Out Time	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Fade Out Hold Time	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Assignable															
Function Assign	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-

Parameter	CVP -605	CVP -609	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Detail Setting	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Registration Freeze															
Setting	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
MIDI															
Setting	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Preset Setting Name	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
System															
Local Control	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Clock	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Transmit Clock	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Transpose MIDI Input	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Start/Stop	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
SysEx Transmit	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
SysEx Receive	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Chord SysEx Transmit	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Chord SysEx Receive	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Transmit															
Part Select	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Ch	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Filter	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Receive															
Ch	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Part	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Filter	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
On Bass Note															
Bass (On Bass Note)	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Chord Detect															
Chord Detect	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Utility															
Speaker/Connectivity															
Headphone Switch	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
IAC	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
IAC Depth	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
AUX In Noise Gate	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Monitor Type (*1)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Content (*1)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Display															
Pop-up Display Time	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Transition Effect	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Touch Sound	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Parameter Lock															
Parameter Lock	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
System															
Language (*1)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Owner Name (*1)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Auto Power Off	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Voice Guide (*2)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Voice Guide Controller (*2)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Voice Guide Volume (*2)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Wireless LAN															
SSID	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Security	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Password	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
DHCP	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
IP Address	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Subnet Mask	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Gateway	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
DNS Server1	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
DNS Server2	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Host Name	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-

*1: Cannot be reset with Factory Reset.
*2: Version 1.20 or later.



ZE85670

C.S.G., Digital Musical Instruments Division
© 2012-2013 Yamaha Corporation

ZE85670

304MWGR**.-01B0
Printed in Indonesia