

TOOLS for NUAGE V1.5.0 for Mac Release Notes

TOOLS for NUAGE V1.5.0 for Mac consists of the following programs.

- NUAGE Workgroup Manager V1.1.1
- NUAGE Extension V1.5.0
- NUAGE HARC Extension V1.1.0
- NUAGE PT Bridge V1.1.0

Contents

[System Component Compatibility](#)

[System Requirements for Software](#)

[Main Revisions and Enhancements](#)

[Known Issue](#)

[Update History](#)

System Component Compatibility

Please make sure to use the appropriate versions of NUAGE system components which are compatible with each other, referring to the following website. Using an unsupported component combination may result in malfunction.

http://www.yamahaproaudio.com/global/en/products/daw_systems/nuage/downloads.jsp

System Requirements for Software

NOTE

Note that the system requirements may be slightly different from those described below depending on the particular operating system.

NUAGE Workgroup Manager and NUAGE Extension

OS	OS X 10.7.x, OS X 10.8.x, OS X 10.9.x
CPU	Intel dual core processor
Memory	2GB or more
Interface	Equipped with an Ethernet connector
Hard Disk	Free disk space of 130MB or more; high-speed hard disk
Others	Nuendo 6.0.4 or later, Cubase 7.0.4 or later

NUAGE PT Bridge

OS	OS X 10.7.x, OS X 10.8.x, OS X 10.9.x
CPU	Intel processor
Interface	Equipped with an Ethernet connector
Hard Disk	Free disk space of 130MB or more; high-speed hard disk
Others	Pro Tools HD 9.x, 10.x, 11.x

Main Revisions and Enhancements

V1.2.0 → V1.5.0

New Functions

- The HA gain of R series devices connected to Nuage I/O can now be controlled.
- The parameters for "Quick Controls" assigned to a channel can now be edited on the [Multi Function Display].
- You can control VST instruments on instrument tracks on the CHANNEL CONTROL page.
- You can now use the "track visibility control" function of Nuendo 6.5.
- Added a super fine mode which allows for finer adjustments of the parameters on the CHANNEL STRIP.
- Channel "Sends" can now be panned.
- You can now control the parameters of the new Nuendo 6.5 plugin (Magnetite II) and Noise Gate parameters in the SECTION CONTROL section.
- Support has been added for the improved ADR functions in Nuendo 6.5.
- You can now select an output for direct monitoring in NUAGE I/O Setup.

Improvements

- If a list does not completely fit on the [Multi Function Display], you can now drag to scroll the list on the screen.
- Now the Ethernet port for use by Avid Pro Tools can be manually selected.
- The SETUP page of Nuage Master is divided into three pages since the number of configurable settings has been increased.

Fixed Bugs

- Solved a problem in which fader's value reverts to the default value when you slide the [Touch slider bar] while holding the [CTRL] button of Nuage Fader.
- Solved a problem in which the LED and [Multi function display] did not light, when the project file was opened immediately after the first start of Nuendo.
- Solved a problem in which the order of Nuage I/O devices added to the Workgroup was

changed when NUAGE Workgroup Manager was restarted with not all of the added Nuage I/O devices being powered on.

- Solved some other minor problems.

Update History

V1.1.0 → V1.2.0

New Functions

- Added support for remote operation of AD8HR remote preamp from Nuage Master.
- Improved the EQ Band Curve display.
- Added support for marker colors in Nuendo.
- Improved parameter indications on the Multi Function Display.
- Improved pan control operations from the channel strip.

Fixed Bugs

- Solved a problem in which the cue mix monitor would be interrupted when changing the Monitor from the CONTROL ROOM section on the Nuage Master.
- Solved a problem in which the Select Track pop-up window of the DAW A may have been displayed when DAW B or DAW C was operated by using NUMERIC PAD.
- Solved a problem in which direct monitoring would be disabled if executing “Revert” of the Nuendo when direct monitoring is on.
- Solved a problem in which an invalid value would be displayed when changing the “NUAGE I/O Setup” parameters of the Nuendo by using the mouse wheel.



- Solved a problem in which [MOVE] would become dim if pressing and holding [ZOOM] when [MOVE] and [SELECT] on the Nuage Master are lit.
- Solved a problem in which no plug-in effect may have been applied if the order of the effects were rearranged when the Channel Strip rack in “Mixer” on Nuendo was displayed.

- Solved a problem in which Nuendo may have crashed if quitting Nuendo when the “NUAGE MASTER Setup” or “NUAGE FADER Setup” was displayed.
- Solved some other minor problems.

The other main fixes and enhancements for each program are explained below.

NUAGE HARC Extension

V1.0.0 → V1.0.1

- Solved some other minor problems.

Known Issue

- When logging in to a Mac with non-administrative privileges, Pro Tools may display an HUI communication error. Make sure to log in with administrative privileges.

Update History

V1.0.0 → V1.1.0

New Functions

- Added the ADR mode.
- Added the functions for configuring the buttons in the USER ASSIGNABLE section.
- Added support for remote operation of the AD8HR remote preamp.
- Added the display in the [Channel name display].
- Added display channels on the LCD.
- Added some track select operations.
- Added some Zoom In and Zoom Out operations.
- Added some editing operations.
- Added the input format when you set the Project Cursor position in the Locate function.
- The dynamics of each channel can now be operated on the DYN page of Nuage Master.
- Added the function for locking/unlocking “TEMPO” and “CLICK” in the MAIN page of the TRANSPORT page of Nuage Master.
- Key input can now be executed continuously while pressing the [Input keys] in the NUMERIC PAD section of the Nuage Master.
- Added the display of “Channel Configuration” to “Channel Information” in the upper left of the CHANNEL CONTOROL page of the Nuage Master.
- Added the “L&R” parameter, which lets you simultaneously operate “PAN” of both left and right channels, to the PAN page of Nuage Master.
- Changed so that only applicable channel strip types are displayed when “Show One Channel

Strip Type” is selected in the “Mixer” window of Nuendo.

- Changed the display of [Channel name display] in the Left Lock area or the Right Lock area.

The other main fixes and enhancements for each program are explained below.

NUAGE Workgroup Manager

V1.0.0 → V1.1.0

- Changed the "Check for Update" button to the "Update" button.

NUAGE PT Bridge

V1.0.0 → V1.0.1

- Solved the problem in which control of Pro Tools was adversely affected when the target DAW was changed quickly by using the Nuage Master or the Nuage Fader.

Company and product names that appear in this document are the trademarks or registered trademarks of their respective companies.

(C) 2013-2014 Yamaha Corporation.

TOOLS for NUAGE V1.5.0 for Mac リリースノート

TOOLS for NUAGE V1.5.0 for Mac は、以下のプログラムで構成されています。

- NUAGE Workgroup Manager V1.1.1
- NUAGE Extension V1.5.0
- NUAGE HARC Extension V1.1.0
- NUAGE PT Bridge V1.1.0

目次

[NUAGE システムコンポーネントの互換性](#)

[ソフトウェアの動作環境](#)

[主なアップデートの内容](#)

[既知の不具合](#)

[更新履歴](#)

NUAGE システムコンポーネントの互換性

NUAGE システム製品は、下記のウェブサイト参照して互換性のあるバージョンをお使いください。互換性の無いバージョンを組み合わせで使った場合、誤動作の原因になることがあります。

http://www.yamahaproaudio.com/japan/ja/products/daw_systems/nuage/downloads.jsp

ソフトウェアの動作環境

NOTE

お使いの OS によっては、下記の仕様以上の条件を満たす必要があります。

NUAGE Workgroup Manager および NUAGE Extension

OS	OS X 10.7.x, OS X 10.8.x, OS X 10.9.x
CPU	Intel デュアルコアプロセッサ
メモリー	2GB 以上
インターフェース	イーサネット端子を搭載していること
ハードディスク	130MB 以上の空き容量、高速なハードディスク
その他	Nuendo 6.0.4 以降、Cubase 7.0.4 以降

NUAGE PT Bridge

OS	OS X 10.7.x、OS X 10.8.x、OS X 10.9.x
CPU	Intel プロセッサー
インターフェース	イーサネット端子を搭載していること
ハードディスク	130MB 以上の空き容量、高速なハードディスク
その他	Pro Tools HD 9.x, 10.x, 11.x

主なアップデートの内容

V1.2.0 → V1.5.0

新機能

- Nuage I/O に接続した R シリーズの HA ゲインをコントロールできるようになりました。
- チャンネルに割り当てられている「クイックコントロール」のパラメーターを[マルチファンクションディスプレイ]で編集できるようになりました。
- CHANNEL CONTROL ページでインストゥルメントトラック上の VST インストゥルメントを操作できるようになりました。
- Nuendo 6.5 の「任意のトラックの表示/非表示」が行なえるようになりました。
- CHANNEL STRIP のパラメーターを従来よりも細かく調節できるスーパーファインモードを追加しました。
- チャンネルの「センド」パンを設定できるようになりました。
- SECTION CONTROL セクションで Nuendo 6.5 で追加されたプラグイン(Magneto II)や Noise Gate のパラメーターが操作できるようになりました。
- Nuendo 6.5 で強化された ADR の機能追加に対応しました。
- Nuage I/O Setup で、ダイレクトモニタリングの対象となる出力を選択できるようになりました。

改善点

- [マルチファンクションディスプレイ]に収まりきれないリストなどがあるとき、ドラッグして画面をスクロールできるようになりました。
- Avid Pro Tools で使用する Ethernet ポートを選択できるように手動選択を追加しました。
- Nuage Master の SETUP ページで設定できる項目が増えたため、3 ページに分割しました。

修正された不具合

- Nuage Fader の[CTRL]を押しながら[タッチスライダーバー]でスライドすると、フェーダーの値が初期値になってしまう不具合を修正しました。
- Nuendo の起動直後にプロジェクトファイルを開くと、LED が点灯せず、マルチファンクションディスプレイも消灯してしまう場合がある不具合を修正しました。

- Nuage I/O を Workgroup に複数台登録してから、そのうち何台かの電源を入れずに NUAGE Workgroup Manager を再起動すると、Nuage I/O の登録順番が変わってしまう不具合を修正しました。
- その他の軽微な不具合を修正しました。

更新履歴

V1.1.0 → V1.2.0

新機能

- Nuage Master からの AD8HR リモートコントロールに対応しました。
- EQ バンドカーブの表示に対応しました。
- Nuendo のマーカーカラーに対応しました。
- マルチファンクションディスプレイ上のパラメーター表示を改善しました。
- チャンネルストリップからのパンコントロールを改善しました。

修正された不具合

- Nuage Master の CONTROL ROOM セクションで「モニター」を切り替えたとき、キューミックスのモニターが一時的に途切れてしまう不具合を修正しました。
- DAW B または DAW C を NUMERIC PAD で操作したとき、DAW A のトラック選択機能のポップアップが表示されることがある不具合を修正しました。
- ダイレクトモニタリング中に Nuendo の「最後に保存した状態に戻す」を実行すると、ダイレクトモニタリングが無効になる不具合を修正しました。
- 「NUAGE I/O Setup」のパラメーターをマウスホイールで変更したとき、数値が正しく表示されない不具合を修正しました。



- Nuage Master の[MOVE]と[SELECT]が点灯しているとき、[ZOOM]を長押しすると[MOVE]が暗点灯する不具合を修正しました。

- Nuendo の「ミキサー」で「チャンネルストリップ」ラックを表示しているとき、エフェクトの順番を入れ替えると、エフェクトが無効になることがある不具合を修正しました。
- 「NUAGE MASTER Setup」や「NUAGE FADER Setup」の画面を表示しているとき、Nuendo を終了すると、Nuendo がクラッシュする不具合を修正しました。
- その他の軽微な不具合を修正しました。

その他の主なアップデート内容については、以下にプログラム別で説明します。

NUAGE HARC Extension

V1.0.0 → V1.0.1

- その他の軽微な不具合を修正しました。

既知の不具合

管理者権限の無いユーザアカウントで Mac へログインした場合、Pro Tools の HUI コミュニケーションエラーのメッセージが表示される場合があります。管理者権限でログインしてください。

V1.0.0 → V1.1.0

新機能

- ADR モードを追加しました。
- USER ASSIGNABLE セクションへの機能の割り当てを追加しました。
- AD8HR のリモートコントロールに対応しました。
- [チャンネルネームディスプレイ]の表示機能を追加しました。
- チャンネルの表示機能を追加しました。
- トラックの選択方法を追加しました。
- ズームに関する操作を追加しました。
- 編集に関する操作を追加しました。
- ロケート機能で「プロジェクトカーソル」の位置を入力するときの入力方法を追加しました。
- Nuage Master の DYN ページで各チャンネルのダイナミクスを操作できるように変更しました。
- Nuage Master の TRANSPORT ページの MAIN ページに「CLICK」と「TEMPO」をロック/アンロックする機能を追加しました。
- Nuage Master の[NUMERIC PAD]セクションで[入力キー]を押し続けると、連続で入力するように修正しました。
- Nuage Master の CHANNEL CONTROL ページの画面左上にある「チャンネル情報」に「チャンネル構成」の表示を追加しました。
- Nuage Master の PAN ページに左右のチャンネルの「パン」を同時に操作する「L&R」パラメーターを

追加しました。

- Nuendo のミキサー画面で「1 つのチャンネルストリップタイプを表示」オプションが選択されているとき、該当するチャンネルストリップタイプだけが表示されるように変更しました。
- レフトロックエリアまたはライトロックエリアにあるときのチャンネルの[チャンネルネームディスプレイ]の表示を変更しました。

その他の主なアップデート内容については、以下にプログラム別で説明します。

NUAGE Workgroup Manager

V1.0.0 → V1.1.0

- 「Check for Update」ボタンを「Update」ボタンに変更しました。

NUAGE PT Bridge

V1.0.0 → V1.0.1

- Nuage Master、Nuage Fader で操作対象の DAW ソフトウェアをすばやく切り替えたとき、Pro Tools をコントロールできなくなる可能性がある不具合を修正しました。

本文に掲載されている会社名および商品名等は、各社の登録商標または商標です。

(C) 2013-2014 Yamaha Corporation.